Residential Smart Inverter

ET LV 5.0-20kW

LX A5.0-30 GW14.3-BAT-LV-G10 LXU5.0-30

Solutions Manual



Copyright Statement

Copyright©GoodWe Technologies Co., Ltd. 2025. All rights reserved.

No part of this manual can be reproduced or transmitted to the public platform in any form or by any means without the prior written authorization of GoodWe Technologies Co., Ltd.

Trademarks

GOODWE and other GOODWE trademarks are trademarks of GoodWe Technologies Co.,Ltd. All other trademarks or registered trademarks mentioned in this brochure are the property of their respective owners.

NOTICE

The information in this document is subject to change due to product updates or other reasons. This document cannot replace the product labels or the safety precautions unless otherwise specified. All descriptions in the manual are for guidance only.

Table of Contents

1 About This Manual	14
1.1 Overview	···14
1.2 Applicable Model	···14
1.3 Symbol Definition	···15
2 Safety Precautions	···16
2.1 General Safety	16
2.2 personnel requirements	16
2.3 System Safety	···17
2.3.1 PV String Safety	18
2.3.2 Inverter Safety	-19
2.3.3 Battery Safety	20
2.3.4 Smart Meter Safety	22
2.4 Safety Symbols and Certification Marks	-23
2.5 EU Declaration of Conformity	25
2.5.1 Equipment with Wireless Communication Modules	25
2.5.2 No Equipment with Wireless Communication Modules (except Battery)	25
2.5.3 Battery	25
3 System Introduction	27
3.1 System Overview	27
3.2 Product Overview	-48
3.2.1 Inverter	-48

3.2.2 Battery	52
3.2.2.1 LX A5.0-30	52
3.2.2.2 GW14.3-BAT-LV-G10	52
3.2.2.3 LX U5.0-30	53
3.2.3 Smart Meter	53
3.2.4 smart dongle	55
3.3 Supported Grid Types	55
3.4 System Working Mode	56
3.5 Features	66
4 Check and Storage	71
4.1 Check Before Receiving	71
4.2 deliverables	71
4.2.1 Inverter Deliverables	71
4.2.2 Batteries Deliverables	74
4.2.2.1 Batteries Deliverables(LX A5.0-30)	74
4.2.2.2 Batteries Deliverables(GW14.3-BAT-LV-G10)	76
4.2.2.3 Batteries Deliverables(LX U5.0-30)	76
4.2.3 Busbar Deliverables	78
4.2.3.1 BCB-22-WW-0	78
4.2.3.2 BCB-32-WW-0	78
4.2.4 Smart Meter Deliverables(GM330)	78
4 3 Storage	79

5 Installation	82
5.1 System Installation and Commissioning Procedure	82
5.2 Installation Requirements	82
5.2.1 Installation Environment Requirements	82
5.2.2 Installation Space Requirements	84
5.2.3 Tool Requirements	85
5.3 Equipment Handling	87
5.4 Installing the Inverter	88
5.5 Installing the Battery System	90
5.5.1 LX A5.0-30	90
5.5.2 GW14.3-BAT-LV-G10	93
5.5.3 LX U5.0-30	94
5.6 Installing the Smart Meter	95
5 System Wirings	97
6.1 System Wiring Electrical Block Diagram	97
6.2 Detailed System Wiring Diagram	100
6.2.1 Detailed System Wiring Diagram for Single Inverter	101
6.2.2 Detailed System Wiring Diagram for Parallel System	105
6.3 Preparing Materials	108
6.3.1 Preparing Breakers	109
6.3.2 Preparing Cables	111
6.4 dismantleInverter Bottom Cover	117

	6.5 Connecting the PE cable	118
	6.6 Connecting the AC Cable	120
	6.7 Connecting the PV Cable	121
	6.8 Connecting the Battery Cable	123
	6.8.1 Connecting the Power Cable between the Inverter and Battery	142
	6.8.2 Connecting the Communication Cable between the Inverter and Battery	146
	6.9 Connecting the Meter Cable	149
	6.10 Connecting the Inverter Communication Cable	151
	6.11 Lower cover of the enclosure	156
	6.12 Installing the Battery SystemProtection Cover	156
	6.12.1 LX A5.0-30	156
	6.12.2 GW14.3-BAT-LV-G10	157
	6.12.3 LX U5.0-30	157
7	7 System Commissioning	158
	7.1 Check Before Power ON	158
	7.2 Power ON	158
	7.3 Indicators	161
	7.3.1 Inverter Indicators	161
	7.3.2 Battery Indicators	162
	7.3.2.1 LX A5.0-30	162
	7.3.2.2 LX A5.0-30、LX U5.0-30	162

	7.3.2.3 GW14.3-BAT-LV-G10	163
	7.3.3 Smart Meter Indicator	166
	7.3.4 Smart Dongle Indicator	166
3	System rapid configuration	169
	8.1 Downloading the App	169
	8.1.1 Download the SolarGo App	169
	8.1.2 Download SEMS+ APP	169
	8.2 Connect hybrid inverter (Bluetooth)	170
	8.3 Set communication parameters	171
	8.3.1 Configure privacy and security parameters	172
	8.3.2 Set WLAN/LAN parameters	175
	8.3.3 Set RS485 communication parameters	177
	8.4 System Quick Settings	177
	8.4.1 System Quick Settings (Type II)	179
	8.5 Power Plant Creation	187
9	System Commissioning	189
	9.1 Commissioning Method Overview	189
	9.2 Configuration via LCD	189
	9.2.1 LCD Overview	189
	9.2.2 Parallel system settings	192
	9.2.3 Quick Settings	193
	9 2 4 Setting Advanced Parameters	201

	9.2.5 Setting Immediate Charging	202
	9.2.6 Setting the Basic Information	203
	9.2.7 Setting Port Connection	203
	9.2.8 Viewing Device Information	207
(9.3 SolarGo APP	208
	9.3.1 App Introduction	208
	9.3.1.1 Download the Installation App	209
	9.3.1.2 Connection method	209
	9.3.1.3 Login Interface Introduction	210
	9.3.2 Connect hybrid inverter (Bluetooth)	212
	9.3.3 hybrid inverter Interface Introduction	213
	9.3.4 Set communication parameters	215
	9.3.4.1 Configure privacy and security parameters	215
	9.3.4.2 Set WLAN/LAN parameters	218
	9.3.4.3 Set RS485 communication parameters	220
	9.3.4.4 Detect WLAN	220
	9.3.5 Configure RS485 parallel system	221
	9.3.6 System Quick Settings	222
	9.3.6.1 System Quick Settings (Type II)	223
	9.3.7 Setting the Basic Information	231
	9.3.7.1 Set up lightning protection alarm function	231
	9 3 7 2 Set backup power parameters	231

9.3.7.3 Enable shadow scan function	233
9.3.7.4 Set Power scheduling parameters	234
9.3.8 Setting Advanced Parameters	237
9.3.8.1 Set three-phase unbalanced output	237
9.3.8.2 Set the BACK-UP N and PE relay switch	238
9.3.8.3 Configure DRED/Remote Shutdown/RCR/EnWG 14a functions	239
9.3.8.4 Set Export power limit parameters	240
9.3.8.4.1 Set Export power limit parameters (General)	241
9.3.8.5 Enable arc detection function	241
9.3.8.6 Set Power dispatch response parameters	242
9.3.8.7 Set custom safety parameters	244
9.3.8.7.1 Set reactive power curve	245
9.3.8.7.2 Set active power curve	249
9.3.8.7.3 Set Utility grid Protection parameters	255
9.3.8.7.4 Configure Utility grid connection parameters	256
9.3.8.7.5 Set voltagefault ride-through parameters	258
9.3.8.7.6 Set Frequencyfault ride-through parameters	260
9.3.8.8 Set PV connection mode	260
9.3.8.9 Enable unbalanced voltage output function	261
9.3.8.10 Factory Reset	262
9.3.8.11 Export parameters	263
9 3 8 11 1 Export safety parameters	263

9.3.8.11.2 Export log parameters	264
9.3.9 Enable Battery function	265
9.3.9.1 Set lithium Battery parameters	265
9.3.9.2 Set lead-acid Battery parameters	269
9.3.10 Set meter parameters	273
9.3.10.1 Electric Meter/CT Auxiliary Testing	273
9.3.11 Set generator/load control parameters	273
9.3.11.1 Set load control parameters	274
9.3.11.2 Set generator parameters	276
9.3.11.3 Set microgrid parameters	279
9.3.12 Equipment Maintenance	281
9.3.12.1 View Firmware Information/Firmware Upgrade	281
9.3.12.1.1 Regular firmware upgrade	281
9.3.12.1.2 One-click firmware upgrade	282
9.3.12.1.3 Automatic firmware upgrade	283
9.3.12.1.4 View firmware information	284
9.3.12.2 Change login password	285
10 Power Plant Monitoring	287
10.1 App Introduction	287
10.1.1 Supporting products	287
10.1.2 Download the Installation App	287
10.1.3 Connection method	288

10.1.4 Set language and Server	288
10.2 Account Management	289
10.2.1 Register an account	289
10.2.2 Login account	290
10.2.3 Switch account	291
10.2.4 Delete account	291
10.2.5 Account Permission Description	292
10.3 Set communication parameters	296
10.3.1 Set communication parameters via Bluetooth	296
10.3.2 Configure communication parameters via WiFi	299
10.4 Power Plant Monitoring	301
10.4.1 Viewing Power Plant Information	301
10.4.1.1 View all power station overview information	301
10.4.1.2 View power station details	303
10.4.1.2.1 View power station details (traditional mode)	304
10.4.1.3 Viewing Alarm Information	305
10.4.1.3.1 View all power station alarm information	305
10.4.1.3.2 View the current power station alarm information (legacy mode)	306
10.4.1.3.3 View the alarm information of the current device.	307
10.4.1.4 View power station report information	308
10.4.2 Power Plant Management	310
10 4 2 1 Power Plant Creation	310

10.4.2.2 Configure power station information	311
10.4.2.3 visitor	312
10.4.2.4 Power Plant Management photo	313
10.4.2.5 Adjust power station details page display information	314
10.4.2.6 Set PV module layout	315
10.4.2.7 Delete	316
10.4.2.8 Collection	317
10.4.3 Managing the Equipment in the Power Plant	317
10.4.3.1 New equipment	318
10.4.3.2 Edit device information	319
10.4.3.3 Delete device	320
10.4.3.4 Upgrade the firmware version of the equipment	321
10.4.4 Remote management device	322
10.4.4.1 Set hybrid inverter parameters	323
11 Maintenance	329
11.1 Power OFF the System	329
11.2 Removing the Equipment	331
11.3 Disposing of the Equipment	331
11.4 Routine Maintenance	331
11.5 fault	333
11.5.1 Viewing Fault/Alarms Information	333
11.5.2 Fault Information and Troubleshooting	333

11.5.2.1 System fault	334
11.5.2.2 Inverter fault	335
11.5.2.3 Batteryfault(LX A5.0-30)	406
11.5.2.4 Batteryfault(LX A5.0-30, LX U5.0-30)	409
11.5.2.5 Batteryfault(GW14.3-BAT-LV-G10) (Note: The original text appears to be a code or model number, which typically does not require translation. It has been retained as-is.)	413
11.5.3 fault Clear Post-Processing	416
11.5.3.1 Clear AFCIfaultWARNING	416
12 technical parameter	418
12.1 Inverter Parameters	418
12.2 Battery Technical Data	444
12.2.1 LX A5.0-30	444
12.2.2 LX U5.0-30	445
12.2.3 GW14.3-BAT-LV-G10	447
12.3 Smart Meter Technical Data	449
12.3.1 GM330	449
12.4 Smart Dongle Technical Data	450
12.4.1 WiFi/LAN Kit-20	450
12.4.2 4G Kit-CN-G20	451
13 Appendix	453
13.1 FAQ	453
13.1.1 How to perform auxiliary testing of electricity meters/CTs?	. <u>⊿</u> 53

	13.1.2 How to Upgrade the Device Version	453
	13.2 Abbreviations	454
	13.3 Explanation of Terms	457
	13.4 Battery SN code meaning	458
	13.5 National Safety Regulations	459
1	4 Contact Information	··464

1 About This Manual

1.1 Overview

The energy storage system consists of inverter, battery system, and smart meter. This manual describes the product information, installation, electrical connection, commissioning, troubleshooting and maintenance of the system. Read through this manual before installing and operating the products to understand product safety information and familiarize yourself with functions and features of the product. This manual is subject to update without notice. For more product details and latest documents, visit https://en.goodwe.com/.

1.2 Applicable Model

energy storage system includes the following products:

Product Type	Product Information	Instructions
	GW5K-ET-L-G10	Nominal output power:5.0kW
	GW6K-ET-L-G10	Nominal output power: 6.0kW
	GW8K-ET-L-G10	Nominal output power:8.0kW
Incomban	GW10K-ET-L-G10	Nominal output power:10kW
Inverter	GW12K-ET-L-G10	Nominal output power:12kW
	GW15K-ET-L-G10	Nominal output power:15kW
	GW20K-ET-L-G10	Nominal output power: 20kW
	GW12K-ET-LL-G10	Nominal output power: 12kW
Battery system	LX A5.0-30	Rated energy 5.12kWh, supports up to 30 clusters in parallel
	GW14.3-BAT-LV-G10	Rated energy 14.3kWh, supports up to 16 clusters in parallel

Product Type	Product Information	Instructions
	LX U5.0-30	Rated energy 5.12kWh, supports up to 30 clusters in parallel
Smart Meter	GM330	The monitoring module in energy storage system can detect information such as voltage and current in the system.
Smart dongle	WiFi/LAN Kit-20	The system operation information can be uploaded to the monitoring platform via WiFi or LAN signals.
	4G Kit-CN-G20 (China Only)	The system operation information can be uploaded to the monitoring platform via 4G.

1.3 Symbol Definition

ADANGER

Indicates a high-level hazard that, if not avoided, will result in death or serious injury.

!WARNING

Indicates a medium-level hazard that, if not avoided, could result in death or serious injury.

ACAUTION

Indicates a low-level hazard that, if not avoided, could result in minor or moderate injury.

NOTICE

Highlights key information and supplements the texts. Or some skills and methods to solve product-related problems to save time.

2 Safety Precautions

Please strictly follow these safety instructions in the user manual during the operation.

AWARNING

The products are designed and tested strictly to comply with related safety rules. Follow all the safety instructions and cautions before any operations. Improper operation might cause personal injury or property damage as the products are electrical equipment.

2.1 General Safety

NOTICE

- The information in this document is subject to change due to product updates or other reasons. This document cannot replace the product labels or the safety precautions unless otherwise specified. All descriptions in the manual are for guidance only.
- Before installations, read through the user manual to learn about the product and the precautions.
- All operations should be performed by trained and knowledgeable technicians who are familiar with local standards and safety regulations.
- Use insulating tools and wear personal protective equipment when operating the equipment to ensure personal safety. Wear anti-static gloves, wrist strips, and cloths when touching electronic devices to protect the equipment from damage.
- Unauthorized dismantling or modification may damage the equipment, and the damage is not covered under the warranty.
- Strictly follow the installation, operation, and configuration instructions in this manual or the user manual. The manufacturer shall not be liable for equipment damage or personal injury if you do not follow the instructions. For more warranty details, please visit https://www.goodwe.com/warrantyrelated.html.

2.2 Personal Requirements

NOTICE

- Personnel who install or maintain the equipment must be strictly trained, learn about safety precautions and correct operations.
- Only qualified professionals or trained personnel are allowed to install, operate, maintain, and replace the equipment or parts.

2.3 System Safety

!DANGER

- Disconnect the upstream switches to power off the equipment before any electrical connections. Do not work with power on. Otherwise, an electric shock may occur.
- Install a breaker at the voltage input side of the equipment to prevent personal injury or equipment damage caused by energized electrical work.
- All operations such as transportation, storage, installation, use and maintenance shall comply with applicable laws, regulations, standards and specifications.
- Perform electrical connections in compliance with local laws, regulations, standards and specifications, including cables and component specifications.
- Use the connectors included in the package to connect cables. The manufacturer shall not be liable for the equipment damage if connectors of other models are used.
- Ensure all cables are connected correctly, tightly, and securely. Inappropriate wiring may cause poor connection and damage the equipment.
- The PE cables must be connected and secured properly.
- To protect the equipment and components from damage during transportation, ensure that the transportation personnel are professionally trained. All operations during the transportation have to be recorded. The equipment shall be kept in balance to avoid falling down.
- The equipment is heavy. Please equip the corresponding personnel according to its weight, so that the equipment does not exceed the maximum weight that the personnel can carry to avoid personnel injuries.
- Keep the equipment stable to avoid dumping, which can result in equipment damage and personal injuries.

!WARNING

- Do not apply mechanical load to terminals, otherwise the terminals may be damaged.
- If the cable bears too much tension, the connection may be poor. Reserve a certain length of the cable before connecting it to corresponding ports.
- Tie the cables of the same type together, and place cables of different types at least 30mm apart. Do not place the cables entangled or crossed.
- Place the cables at least 30mm away from the heating components or heat sources, otherwise the insulation layer of the cables may be aging or broken due to high temperature.

2.3.1 PV String Safety

≜WARNING

- Ensure the module frame and mounting system are properly grounded.
- After the connection is completed, ensure that the cables are securely fastened and free from looseness. Improper wiring may result in poor contact or high impedance, and damage the Inverter.
- Use a multimeter to measure the positive and negative poles of the DC cable, ensuring correct polarity without reverse connection; and confirm that the voltage is within the allowable range.
- Use a multimeter to measure the DC cable, ensuring the positive and negative poles are correctly connected without reverse polarity. The voltage should be lower than the maximum DC input voltage. Damage caused by reverse polarity or over-voltage is not covered under the manufacturer's warranty.
- The PV string output does not support grounding. Before connecting the PV string to Inverter, ensure that the the minimum insulation resistance of the PV string meets the minimum insulation resistance requirement (R=Max.Input Voltage (V)/30mA).
- Do not connect the same PV string to multiple Inverter, as this may cause damage to the Inverter.
- The photovoltaic modules used in conjunction with Inverter must comply with the IEC 61730 Class A standard.
- When the input PV String value is high or the input current value is high, it may cause Inverter output derating.

2.3.2 Inverter Safety

WARNING

- Ensure the voltage and Frequency at the on-grid access point comply with Inverter on-grid requirements.
- It is recommended to add breaker or fuses as Protection devices on the AC side. The rating of the Protection device should be at least 1.25 times the maximum current of the AC output of Inverter.
- If the arc alarm is triggered less than 5 times within 24 hours, it can be automatically cleared. After the 5th arc alarm, the Inverter will shut down Protection, and the Inverter can only resume normal operation after the fault is cleared.
- In photovoltaic systems, if a Battery is not configured, it is not recommended to use the BACK-UP function, as it may lead to system POWER OFF risks.
- When Utility grid, voltage, and Frequency change, it may lead to Inverter output derating.

2.3.3 Battery Safety

DANGER

- Before operating any equipment in the system, ensure that the device is POWER
 OFF to prevent electric shock DANGER. During equipment operation, strictly
 adhere to all Safety Precautions in this manual and the safety labels on the
 devices.
- Do not disassemble, modify, or repair Battery or control unit without official authorization from the equipment manufacturer, as it may result in electric shock DANGER or equipment damage. beyond the manufacturer's liability shall be liable for any losses incurred.
- Do not impact, pull, drag, squeeze, or step on the equipment, and do not place the Battery in fire, otherwise there is a risk of explosion for the Battery.
- Do not place the Battery in a high-temperature environment. Ensure there are no heat sources near the Battery and that it is not exposed to direct sunlight. A fire may occur if the ambient temperature exceeds 60°C.
- Do not use if Battery or control unit has obvious defects, cracks, damage, or other conditions. Damage to Battery may result in electrolyte leakage.
- Do not move the Battery system while the Battery is in operation. If you need to replace the Battery or add Battery, please contact the after-sales service center.
- A short circuit may cause personal injury. The instantaneous high current generated by a short circuit can release a large amount of energy, potentially leading to a fire.

MARNING

- Batterycurrent may be affected by factors such as temperature, Humidity, and weather conditions, which could lead to Battery current limiting and impact load capacity.
- If the Battery fails to start, please contact the after-sales service center as soon as possible. Otherwise, the Battery may be permanently damaged.
- Please perform regular inspection and maintenance on the Battery in accordance with the maintenance requirements of Battery.

Emergency response measures for emergencies

Battery electrolyte leakage

If the Battery module leaks electrolyte, avoid contact with the leaked liquid or gas. The electrolyte is corrosive and contact may cause skin irritation and chemical burn. If accidental contact with the leaked substance occurs, please follow these steps:

- inhalation: Evacuate the contaminated area and seek immediate medical assistance.
- Eye contact: Rinse with clean water for at least 15 minutes and seek immediate medical assistance.
- Skin contact: Wash the affected area thoroughly with soap and water, and seek medical attention immediately.
- Ingestion: Induce vomiting and seek immediate medical attention.

fire

- When the Battery temperature exceeds 150°C, there is a risk of fire in the Battery, and toxic or harmful gases may be released after the Battery catches fire.
- To prevent fire hazards, ensure that carbon dioxide, Novec 1230, or FM-200 fire extinguishers are available near the equipment.
- Do not use ABC dry powder fire extinguishers for firefighting. Firefighters must wear protective clothing and self-contained breathing apparatus.

Battery triggers fire protection

For Battery equipped with fire protection function, the following actions shall be executed after the fire protection function is triggered:

- Immediately disconnect the main power switch to ensure no current passes through Battery system.
- Conduct a preliminary visual inspection of the Battery for any signs of damage, deformation, leakage, or unusual odors. Inspect the housing, connectors, and cables of the Battery.
- Use temperature sensors to monitor the Battery and its ambient temperature, ensuring there is no risk of overheating.
- Isolate and label the damaged Battery, and dispose of it properly in accordance with local regulations.

2.3.4 Smart Meter Safety

AWARNING

If the Utility gridvoltage voltage fluctuation exceeds 265V, prolonged overvoltage operation may damage the meter. It is recommended to install a fuse with a rated current of 0.5A on the voltage input side of the meter to Protection it.

2.4 Safety Symbols and Certification Marks

ADANGER

- After the equipment Installation, the labels and warning signs on the enclosure must remain clearly visible. Blocking, altering, or damaging them is prohibited.
- The following warning labels on the enclosure are for reference only. Please refer to the actual labels on the equipment.

No.	Symbol	Meaning
1		Potential DANGER exists during equipment operation. Please take protective measures when operating the equipment.
2	4	High voltage DANGER. High voltage is present during equipment operation. Ensure the equipment is POWER OFF before performing any operations.
3		The surface of Inverter is at high temperature. Do not touch during operation to avoid burns.
4		Please use the equipment properly. In extreme conditions, there is a risk of explosion.
5		Battery contains flammable materials, beware of fire.
6		The equipment contains corrosive electrolyte. Avoid contact with leaked electrolyte or vaporized gases.

No.	Symbol	Meaning
7	5min	After the equipment is power off, please wait for 5 minutes until it is fully Discharge.
8		The equipment should be kept away from open flames or ignition sources.
9	AR	The equipment shall be Keep away from children accessible areas.
10		Do not extinguish with water.
11		Before operating the equipment, please read the product manual carefully.
12	(D-D)	Wear personal protective equipment during Installation, operation, and maintenance.
13		The equipment must not be disposed of as household waste. Please handle it in accordance with local laws and regulations or return it to the equipment manufacturer.
14		grounding point
15		Recycling symbol.
16	CE	CE marking
17	TOV/Habilandard GEHTHED Townships Township	TUV Mark.

No.	Symbol	Meaning
18		RCM mark.

2.5 EU Declaration of Conformity

2.5.1 Equipment with Wireless Communication Modules

The equipment with wireless communication modules sold in the European market meets the requirements of the following directives:

- Radio Equipment Directive 2014/53/EU (RED)
- Restrictions of Hazardous Substances Directive 2011/65/EU and (EU) 2015/863 (RoHS)
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

2.5.2 Equipment without Wireless Communication Modules (Except Battery)

The equipment without wireless communication modules sold in the European market meets the requirements of the following directives:

- Electromagnetic compatibility Directive 2014/30/EU (EMC)
- Electrical Apparatus Low Voltage Directive 2014/35/EU (LVD)
- Restrictions of Hazardous Substances Directive 2011/65/EU and (EU) 2015/863 (RoHS)
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

2.5.3 Battery

The batteries sold in the European market meets the requirements of the following directives:

- Electromagnetic compatibility Directive 2014/30/EU (EMC)
- Electrical Apparatus Low Voltage Directive 2014/35/EU (LVD)
- Battery Directive 2006/66/EC and Amending Directive 2013/56/EU
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

You can download the EU Declaration of Conformity from our official website at: https://en.goodwe.com.

3 System Introduction

3.1 System Overview

The residential smart Inverter solution integrates Inverter, Battery, Smart Meter, and smart dongle devices. In the photovoltaic system, it converts solar energy into electricity to meet household power demands. The energy IoT devices in the system manage electrical appliances by monitoring the overall power status, enabling intelligent control of electricity for loads, storage in Battery, or export to Utility grid.

AWARNING

- Battery and model are selected based on the matching list of Inverter and Battery. For requirements regarding the use of Battery in the same system, such as whether model can be mixed or if capacities must be consistent, please refer to the corresponding Battery user manual of the model or contact the Battery manufacturer for relevant specifications. Compatibility list between Inverter and Battery: https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW Battery %20Compatibility%20Overview-EN.pdf.
- Due to product version upgrades or other reasons, the document content will be updated periodically. The matching relationship between Inverter and IoT products can be referenced as follows:https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW Compat ibility-list-of-GoodWe-inverters-and-IoT-products-EN.pdf.
- In a fully off-grid Inverter system, if the Battery experiences prolonged low-light or rainy weather without timely replenishment of Charge, it may lead to excessive Discharge, resulting in performance degradation or damage to the Battery. To ensure long-term stable operation of the system, complete discharge of the Battery should be avoided. The following measures are recommended:
 - 1. During off-grid operation, set the minimum SOC threshold. It is recommended to set the off-grid SOC lower limit to 30%.
 - 2. When the SOC approaches the Protection threshold, the system will automatically enter load-limiting or Protection mode.
 - 3. If there is insufficient sunlight for several consecutive days and the Battery SOC is too low, external energy sources (such as a generator or Utility grid auxiliary Charge) should be used promptly to replenish the Battery.
 - 4. Regularly check the Battery status to ensure it operates within safe working limits.
 - 5. It is recommended to perform a full charge and discharge cycle every six months to calibrate the SOC accuracy.
- For detailed networking and wiring schemes of each scenario, please refer to: 6.2. Detailed System Wiring Diagram(Page 100).


energy storage system operates in off-grid mode and can normally power the following loads:

BACK-UPport Off-grid Load Capacity Description				
Inverter model	GW5K-ET-L-G10 GW6K-ET-L-G10 GW8K-ET-L-G10 GW10K-ET-L-G10 GW12K-ET-L-G10 GW12K-ET-LL-G10		GW15K-ET-L-G10 GW20K-ET-L-G10	
Load type	single- phase	three- phase	Single- phase	three-phase
Single motor load Nominal power (kVA)	1.1	3.3	2.2	6.6
Total Nominal power (kVA) of multiple motor loads	0.4*Pn/3	0.4*Pn	0.5*Pn/3	0.5*Pn
Capacitive Load (kVA)	0.33Pn/3	0.33Pn	0.33Pn/3	0.33Pn
Half-wave load (kW)	3	-	3	-

Note:

- Pn: InverterNominal output power.
- For 2 or more units in parallel operation, the allowable total motor load Nominal power = single motor load Nominal power * number of parallel units * 80%.
- Half-wave load: Some old or non-compliantEMCStandard household appliances (such as hair dryers using half-wave rectification, small heaters, etc.).
- If the total Power of multiple motor loads calculated based on Nominal power is less than the single motor load Nominal power, the total Nominal power of multiple motor loads = the single motor load Nominal power.

General scenario



Equipm ent Type	model	Description
Inverter	GW5K-ET-L-G10 GW6K-ET-L-G10 GW8K-ET-L-G10 GW12K-ET-L-G10 GW15K-ET-L-G10 GW20K-ET-L-G10 GW12K-ET-L-G10	 Inverter supports the connection of generators or large loads. GW5K-ET-L-G10, GW6K-ET-L-G10, GW8K-ET-L-G10, GW10K-ET-L-G10, GW12K-ET-L-G10, only support single-string Battery input. GW15K-ET-L-G10 and GW20K-ET-L-G10 support dual-channel Battery input. The system supports a maximum of 6 Inverter units to form a parallel system, allowing hybrid parallel operation of Inverter with different Power segments in both grid-tied and off-grid modes. However, microgrid functionality is not supported during parallel operation. In a parallel system, if different Power models are mixed and used, set the high Power model as the Master inverter. If grid connection is required, please use the GM330 Smart Meter. In a parallel system, each Inverter requires a Installation WiFi/LAN Kit-20, with the software version requirement being V2.5 or higher. The following version requirements must be met for parallel unit networking: All Inverter software versions are consistent. The ARM software version is 02.108 or above. Inverter DSP software version is 03.3015 or higher. The SolarGo software version is 6.9.0 or above.
	LX A5.0-30	A single system supports up to 30 Battery units in parallel clusters.

Equipm ent Type	model	Description
Battery	GW14.3-BAT-LV-G10	 The single Battery The nominal charging and discharging current is 140A; the maximum Charge current is 224A, and the maximum Discharge current is 260A. Supports up to 30 clusters in parallel within the same system. Products with SN code 25C and later versions support 30 units in parallel by default. For products manufactured before 25C, if you need to meet the requirement of 30 units in parallel, please contact GoodWe After-Sales Service Center to upgrade the firmware version. View product SN code SN code meaning.
	LX U5.0-30	Up to 30 Battery can be clustered in parallel within the same system.
	Lead-acid battery	 Supports connection to AGM, GEL, and Flooded types of lead-acid Battery Calculate the number of Battery based on the lead-acid Battery voltage. The total voltage of the series-connected Battery must not exceed 60V.
Busbar	BCB-22-WW-0 BCB-32-WW-0 BCB-33-WW-0 (Purchased from GoodWe)	Please select the busbar based on the Inverter charging Discharge capacity, load size, and Battery charging Discharge capacity in the system. • BCB-22-WW-0: • When paired with the LX A5.0-30, the Battery system supports a maximum working current of 720A, a working Power of 36kW, and up to

Equipm ent Type	model	Description
		 6 Battery. When paired with the LX U5.0-30, the Battery system supports a maximum working current of 720A, a working Power of 36kW, and can connect up to 6 Inverter units and 6 Battery units. BCB-32-WW-0: When paired with the LX A5.0-30, the Battery system supports a maximum working current of 720A, a working Power of 36kW, and up to 15 Battery. When used with GW14.3-BAT-LV-G10, Battery system supports a maximum working current of 720A, a working Power of 36kW, and up to 15 Battery. When paired with the LX U5.0-30, the Battery system supports a maximum working current of 720A, a working Power of 36kW, and can connect up to 6 Inverter units and 8 Battery units. BCB-33-WW-0: Compatible with LX U5.0-30, Battery system supports a maximum working current of 720A, working Power of 36kW, with a maximum connection of 6 Inverter and 15 Battery. When the number of Battery exceeds 8, two 600A fuses must be connected in parallel. Others: Please configure according to the system Power and current on your own.

Equipm ent Type	model	Description
Smart Meter	 Built-in energy meter (shipped with Inverter) GM330 (purchased from GoodWe) 	 Built-in energy meter: Please connect the CT provided with the shipment to Inverter. CT ratio is 120A:40mA. When the built-in meter of Inverter does not meet the requirements, you can contact the dealer to purchase the GM330 Smart Meter. GM330: CT can be sourced from GoodWe or purchased independently, with a CT ratio requirement of nA/5A. nA: CT primary side input current, n range is 200-5000 5A: CT secondary side output current
Smart dongle	WiFi/LAN Kit-20	 Applicable to Inverter single-unit grid connection and parallel-unit grid connection scenarios. Configure device parameters and view operational information via Bluetooth signals for local access, while uploading system operational data to the monitoring platform through WiFi or LAN. InverterTo use one-click upgrade, operation log export, and other functions, ensure that the WiFi/LAN Kit-20 software version is V2.3 or above.


Equipm ent Type	model	Description
	4G Kit-CN-G20 (China Only)	 Only applicable to single-unit networking scenarios of Inverter. Configure device parameters and view operational information via Bluetooth signals for local access, while uploading system operational data to the monitoring platform through 4G. InverterTo use one-click upgrade or operation log export functions, ensure the 4G Kit-CN-G20 firmware version is 05 or above.
heavy load	-	Only in standalone mode does it support SG Ready heat pump connection, controlling the heat pump via dry contact signals. 1. Total large load Power < GEN port maximum output Power 2. Large Load Power + BACK-UP Power < AC Max.Input Power (Utility grid)
Generat or	-	The generator Power must be greater than the total Power of all loads in the BACKUP port.

AWARNING

- In Microgrid Scenario, the PV open-circuit voltage of Hybrid Inverter is recommended to be <0.85*PV Max.Input Voltage to prevent the system voltage from being too high under severe working conditions, which could trigger overvoltage Protection.
- When the system is under high temperature or BMS current-limiting conditions, it may result in restricted Battery charge Power, leading to excessive system voltage that triggers overvoltage Protection.
- In the microgrid scenario, ensure that the over-frequency load shedding point of grid-tied PV inverter matches that of Hybrid Inverter.
- grid-tied PV inverter If output Power limitation is required, please connect a separate meter or CT (Current Transformer) device.
- Please ensure that the over-frequency load shedding curve of grid-tied PV inverter is configured according to the following settings:
 - end power set to 0% Pn
 - Response delay time is set to 0
 - Hysteresis Function enable set to off

Microgrid scenario

When grid-tied PV inverter is connected to hybrid Inverter GENport, it constitutes a microgrid scenario.



Equipm ent Type	model	Instructions	
Hybrid Inverter	GW5K-ET-L-G10 GW6K-ET-L-G10 GW8K-ET-L-G10 GW10K-ET-L-G10 GW12K-ET-L-G10 GW15K-ET-L-G10 GW20K-ET-L-G10 GW12K-ET-L-G10	 In a microgrid scenario, the system only supports the use of one hybrid Inverter. GW5K-ET-L-G10, GW6K-ET-L-G10, GW8K-ET-L-G10, GW10K-ET-L-G10, GW12K-ET-L-G10, only support single-string Battery input. GW15K-ET-L-G10 and GW20K-ET-L-G10 support dual-channel Battery input. In microgrid scenarios, connecting generators not supported. Parallel operation does not support microgrid functionality. 	
Battery system	LX A5.0-30	A single system supports up to 30 Battery units in parallel clusters.	
	GW14.3-BAT-LV-G10	 The single Battery The nominal charging and discharging current is 140A; the maximum Charge current is 224A, and the maximum Discharge current is 260A. Supports up to 30 clusters in parallel within the same system. Products with SN code 25C and later versions support 30 units in parallel by default. For products before 25C that need to support 30 units in a cluster, please contact GoodWe Customer Service Center to upgrade the firmware version. View product SN code SN code meaning. 	
	LX U5.0-30	A single system supports up to 30 Battery units in parallel clusters.	


Equipm ent Type	model	Instructions	
	lead-acid battery	 Supports connection to AGM, GEL, and Flooded types of lead-acid Battery Calculate the number of Battery voltage based on lead-acid batteries. The total voltage of the series-connected Battery must not exceed 60V. 	
Busbar	BCB-22-WW-0 BCB-32-WW-0 BCB-33-WW-0 (Purchased from GoodWe)	Please select the busbar based on the Inverter charging Discharge capacity, load size, and Battery charging Discharge capacity in the system. • BCB-22-WW-0: • When paired with the LX A5.0-30, the Battery system supports a maximum working current of 720A, a working Power of 36kW, and up to 6 Battery units. • When paired with the LX U5.0-30, the Battery system supports a maximum working current of 720A, a working Power of 36kW, and can connect up to 6 Inverter units and 6 Battery units. • BCB-32-WW-0: • When paired with the LX A5.0-30, the Battery system supports a maximum working current of 720A, a working Power of 36kW, and up to 15 Battery. • When paired with the GW14.3-BAT-LV-G10, the Battery system supports a maximum working current of 720A, a working Power of 36kW, and up to 15 Battery. • When paired with the LX U5.0-30, the Battery system supports a maximum working current of 720A, a working Power of 36kW, and can connect up to 6 Inverter units and 8 Battery units. • BCB-33-WW-0:	

Equipm ent Type	model	Instructions	
		 Compatible with LX U5.0-30, Battery system supports a maximum working current of 720A, working Power of 36kW, and can connect up to 6 Inverter and 15 Battery. When the number of Battery exceeds 8, two 600A fuses must be connected in parallel. Others: Please configure according to the system Power and current on your own. 	
Smart Meter	 Built-in meter (shipped with Inverter) GM330 (purchased from GoodWe) 	 Built-in energy meter: Please use the CTs shipped with the cabinet to connect to Inverter. CT ratio is 120A:40mA. When the built-in meter of Inverter does not meet the requirements, you can contact the dealer to purchase the GM330 Smart Meter. GM330: CT can be sourced from GoodWe or purchased separately, with a CT ratio requirement of nA/5A. nA: CT primary side input current, n range is 200-5000 5A: CT secondary side output current 	
Smart dongle	WiFi/LAN Kit-20	 Configure device parameters and view operational information via Bluetooth signals for local access, and upload system operational data to the monitoring platform via WiFi or LAN. InverterTo use one-click upgrade or operation log export functions, ensure the WiFi/LAN Kit-20 software version is V2.3 or above. 	

Equipm ent Type	model	Instructions	
	4G Kit-CN-G20 (China Only)	 Only applicable to single-unit networking scenarios for Inverter. Configure device parameters and view operational information via Bluetooth signals for local access, while uploading system operational data to the monitoring platform through 4G. To use functions such as one-click upgrade and operation log export, ensure that the 4G Kit-CN-G20 version is 05 or above. 	
grid- tied PV inverter	-	 It is recommended to use GoodWe brand gridtied PV inverter, and third-party grid-tied PV inverter is supported. In the microgrid system, ensure that grid-tied PV inverterNominal output power ≤ hybrid InverterNominal output power. When the microgrid system is in the on-grid state, if Power limitation is required, please ensure: Hybrid Inverter must pass through SolarGo APPExport power limitSet in the interface; grid-tied PV inverter Please configure according to the actual tool used. To ensure the grid-tied PV inverter can operate continuously for power generation, it must pass the SolarGo APP.Microgrid modeThe interface adjusts the output Power of the hybrid Inverter. Note: The output Power control accuracy varies for different grid-tied PV inverter. Please set the Export power limit parameter value according to the actual situation. 	

Coupling scenario

When grid-tied PV inverter is connected to a hybrid Inverter ON-GRID port, it



Equipm ent Type	model	Instructions		
Hybrid Inverter	GW5K-ET-L-G10 GW6K-ET-L-G10 GW10K-ET-L-G10 GW12K-ET-L-G10 GW15K-ET-L-G10 GW20K-ET-L-G10 GW12K-ET-L-G10	 Inverter supports the connection of generators or large loads. GW5K-ET-L-G10, GW6K-ET-L-G10, GW8K-ET-L-G10, GW10K-ET-L-G10, GW12K-ET-L-G10, GW12K-ET-L-G10, only support single-string Battery input. GW15K-ET-L-G10 and GW20K-ET-L-G10 support dual-channel Battery input. The system supports a maximum of 6 Inverter units to form a parallel system, allowing hybrid parallel operation of Inverter in different Power segments for both grid-tied and off-grid applications. In a parallel system, if different Power models are mixed and used, set the high Power model as the Master inverter. If grid connection is required, please use the GM330Smart Meter. In a parallel system, each Inverter requires a Installation WiFi/LAN Kit-20, with the software version requirement being V2.5 or higher. The following version requirements must be met for parallel unit networking: Inverter ARM software version is 02.108 and above. Inverter DSP software version is 03.3015 and above. SolarGo software version in 6.9.0 and above. 		
	LX A5.0-30	Up to 30 Battery can be clustered in parallel within the same system.		

Equipm ent Type	model	Instructions	
Battery	GW14.3-BAT-LV-G10	 The single Battery The nominal charging and discharging current is 140A; the maximum Charge current is 224A, and the maximum Discharge current is 260A. Supports up to 30 clusters in parallel within the same system. Products with SN code 25C and later versions support 30 units in parallel by default. For products manufactured before 25C, if you need to meet the requirement of 30 units in parallel, please contact GoodWe After-Sales Service Center to upgrade the firmware version. View product SN code SN code meaning. 	
	LX U5.0-30	Up to 30 Battery can be clustered in parallel within the same system.	
	lead-acid battery	 Supports connection to AGM, GEL, and Flooded types of lead-acid Battery Calculate the number of Battery based on the lead-acid Battery voltage. The total voltage of the series-connected Battery must not exceed 60V. 	
Busbar	BCB-22-WW-0 BCB-32-WW-0 BCB-33-WW-0 (Purchased from GoodWe)	Please select the busbar based on the Inverter charging Discharge capacity, load size, and Battery charging Discharge capacity in the system. • BCB-22-WW-0: • When paired with the LX A5.0-30, the Battery system supports a maximum working current of 720A, a working Power of 36kW, and up to 6 Battery.	

Equipm ent Type	model	Instructions
		 When paired with the LX U5.0-30, the Battery system supports a maximum working current of 720A, a working Power of 36kW, and can connect up to 6 Inverter units and 6 Battery units. BCB-32-WW-0: When paired with the LX A5.0-30, the Battery system supports a maximum working current of 720A, a working Power of 36kW, and up to 15 Battery. When used with GW14.3-BAT-LV-G10, Battery system supports a maximum working current of 720A, a working Power of 36kW, and up to 15 Battery. When paired with the LX U5.0-30, the Battery system supports a maximum working current of 720A, a working Power of 36kW, and can connect up to 6 Inverter units and 8 Battery units. BCB-33-WW-0: Compatible with LX U5.0-30, Battery system supports a maximum working current of 720A, working Power of 36kW, with a maximum connection of 6 Inverter and 15 Battery. When the number of Battery exceeds 8, two 600A fuses must be connected in parallel. Others: Please configure according to the system Power and current on your own.

Equipm ent Type	model	Instructions	
Smart Meter	 Built-in energy meter (shipped with Inverter) GM330 (purchased from GoodWe) 	 Built-in energy meter: Please connect the CT provided with the shipment to Inverter. CT ratio is 120A:40mA. When the built-in meter of Inverter does not meet the requirements, you can contact the dealer to purchase the GM330 Smart Meter. GM330: CT can be sourced from GoodWe or purchased independently, with a CT ratio requirement of nA/5A. nA: CT primary side input current, n range is 200-5000 5A: CT secondary side output current 	
Smart	WiFi/LAN Kit-20	 Applicable to Inverter single-unit grid connection and parallel-unit grid connection scenarios. Configure device parameters and view operational information via Bluetooth signals for local access, while uploading system operational data to the monitoring platform through WiFi or LAN. InverterTo use one-click upgrade, operation log export, and other functions, ensure that the WiFi/LAN Kit-20 software version is V2.3 or above. 	

Equipm ent Type	model	Instructions	
	4G Kit-CN-G20 (China Only)	 Only applicable to single-unit networking scenarios of Inverter. Configure device parameters and view operational information via Bluetooth signals for local access, while uploading system operational data to the monitoring platform through 4G. InverterTo use one-click upgrade or operation log export functions, ensure the 4G Kit-CN-G20 firmware version is 05 or above. 	
grid- tied PV inverter	-	 It is recommended to use GoodWe brand gridtied PV inverter, which supports the use of thirdparty grid-tied PV inverter. In the coupling scenario, ensure that grid-tied PV inverterNominal output power ≤ hybrid InverterNominal output power. When the coupling system is in the on-grid state, if Power limitation is required, please ensure: Hybrid Inverter needs to pass through SolarGo APPExport power limitSet in the interface; grid-tied PV inverter Please configure according to the actual tools used. Note: The output Power control accuracy varies with different grid-tied PV inverter. Please set the Export power limit parameter value according to actual conditions. 	

Equipm ent Type	model	Instructions
heavy load	-	Only in standalone mode does it support SG Ready heat pump connection, controlling the heat pump via dry contact signals. 1. Total large load Power < GEN port maximum output Power
		2. Large Load Power + BACK-UP Power < AC Max.Input Power (Utility grid)
Generat or	-	The generator Power must be greater than the total Power of all loads in the BACKUP port.

3.2 Product Overview

3.2.1 Inverter


Inverter controls and optimizes power through an integrated energy management system in photovoltaic systems. The electricity generated by the photovoltaic system can be supplied to loads, stored in Battery, or exported to Utility grid.

NOTICE

The appearance of Inverter may vary in different Power sections. Please refer to the actual product.

No.	model	Nominal output power	Nominal output voltage
1	GW5K-ET-L-G10	5kW	400/380, 3L/N/PE
2	GW6K-ET-L-G10	6kW	400/380, 3L/N/PE
3	GW8K-ET-L-G10	8kW	400/380, 3L/N/PE

No.	model	Nominal output power	Nominal output voltage
4	GW10K-ET-L-G10	10kW	400/380, 3L/N/PE
5	GW12K-ET-L-G10	12kW	400/380, 3L/N/PE
6	GW15K-ET-L-G10	15kW	400/380, 3L/N/PE
7	GW20K-ET-L-G10	20kW	400/380, 3L/N/PE
8	GW12K-ET-LL-G10	12kW	220, 3L/N/PE





Component Introduction


No.	Component/Sc reen printing	Description	
1	indicator	Indicates the working status of Inverter.	
2	display screen	View data related to Inverter.	
3	button	Cooperate with the display screen to perform setting operations on the Inverter.	
4	Lower cover of the enclosure	-	
5	Inverter lifting rod Installation hole	 (Optional) Used for Installation lifting rod. GW5K-ET-L-G10, GW6K-ET-L-G10, GW8K-ET-L-G10, GW10K-ET-L-G10, GW12K-ET-L-G10 x 3 GW15K-ET-L-G10, GW20K-ET-L-G10 x 4 	
6	Anti-theft lock hole	(Optional) Anti-theft lock for use between Installation mounting brackets and Inverter.	
7	Mounting Slot for Hanging	Used for Installing the Inverter to be hung.	
8	Grounding terminal	Connecting the PE cable	
9	DC switch	Control the connection or disconnection of DC input.	
10	Pressure relief valve	-	
11, 22	BACK-UP端口	Connect the AC line and connect the critical load to Inverter.	
12, 17	Communicatio n Port	Can be connected to load control,CT、RS485remote shutdownRapid Shutdown、 DRED(Australia)/RCR(Europe) etc.	

No.	Component/Sc reen printing	Description	
13, 18	Battery input port	 Can connect Battery DC input line. GW5K-ET-L-G10, GW6K-ET-L-G10, GW8K-ET-L-G10, GW10K-ET-L-G10, GW12K-ET-L-G10 x 1 GW15K-ET-L-G10, GW20K-ET-L-G10 x 2 	
14, 19	Generator	Used to connect generators, large loads, or grid-tied PV inverter.	
15 , 23	Grid-connected	Connect the AC line, connect Inverter to Utility grid.	
16	PVterminal	 ConnectablePVDC input cable of PV modules. GW5K-ET-L-G10, GW6K-ET-L-G10, GW8K-ET-L-G10 x 2 GW10K-ET-L-G10, GW12K-ET-L-G10, GW12K-ET-LL-G10 x 3 GW15K-ET-L-G10, GW20K-ET-L-G10 x 4 	
20	smart dongleport	 Connectable communication module, such asWiFi/LANsmart dongle. Support connectionUThe panel supports local upgrade of the Inverter software version. Brazilian market can be connectedUSB-RS485Adapter cable. 	
21	Cooling fan	Used for Inverter heat dissipation	

Size Introduction









3.2.2 Battery

The battery system stores and releases electricity based on the requirements of a PV energy storage system. The input and output ports of the energy storage system are both high-voltage direct current. The ET LV inverter supports connecting lead-acid batteries, and the product material of the battery can be obtained from the battery manufacturer.


3.2.2.1 LX A5.0-30



3.2.2.2 GW14.3-BAT-LV-G10




3.2.2.3 LX U5.0-30



3.2.3 Smart Meter


Smart Meter can measure and monitor electrical data in photovoltaic energy storage system, such as: voltage, current, Frequency, Output Power Factor, Power, etc.



No.	model	Application scenarios	
		CT can be supplied by GoodWe or purchased separately. CT ratio requirement: nA: 5A	
1	GM330	 nA: Primary side input of CT current, with n ranging from 200-5000 5A: CT secondary side output current 	


3.2.4 smart dongle

smart dongle is primarily used for real-time transmission of various Inverter power generation data to remote monitoring platforms, and for local device Commissioning via SolarGo APP connection to smart dongle.



No.	model	Signal type	Application scenario
1	WiFi/LAN Kit-20	WiFi, LAN, Bluetooth	InverterSingle unit,Multi-machine scenario
2	4G Kit-CN-G20 (China Only)	4G, Bluetooth	Inverter Standalone Scenario


3.3 Supported Grid Types



3.4 System Working Mode


Self-consumption mode


- Basic operating mode of the system.
- PV generation prioritizes supplying power to the load, with excess electricity directed to Battery charge. Any remaining power is sold to Utility grid. When PV generation cannot meet the Load consumption demand, Battery supplies power to the load. If the Battery power is also insufficient to meet the Load consumption demand, Utility grid provides power to the load.



Back-up Mode


- Recommended for use in Utility grid unstable areas.
- When Grid disconnected, the Inverter switches to off-grid operation mode, and the Battery discharge supplies power to the load to ensure that the BACK-UP Loads does not POWER OFF. When Utility grid is restored, the Inverter operation mode switches to on-grid operation.
- To ensure the Battery SOC is sufficient to maintain normal system operation when off-grid, during on-grid operation, Battery will utilize PV or Utility grid to purchase electricity Charge to Back-up SOC. If purchasing electricity for Battery charge via Utility grid is required, please confirm compliance with local Utility grid laws and regulations.






TOU mode


In compliance with local laws and regulations, set different time periods for buying and selling electricity based on the peak and valley Utility grid tariff differences. For example: during the off-peak electricity price period, set the Battery to Charge mode, and buy power from the grid Charge; during the peak electricity price period, set the Battery to Discharge mode, and supply power to the load through Battery.







Time Delay Charge Mode

- Suitable for areas with on-grid Power output restrictions.
- Setting the peak Power limit allows excess photovoltaic generation beyond the ongrid limit to be used for charging the Battery charge; or configuring PV Charge periods enables the utilization of photovoltaic power to charge the Battery charge during the Charge period.









Peakshaving mode

- Mainly suitable for industrial and commercial scenarios.
- When the total Load consumption Power exceeds the electricity quota in a short period, the Battery discharge can be utilized to reduce the portion of electricity consumption that exceeds the quota.
- When Inverter two BatterySOCAll are below the reserved value.SOCFor
 Peakshaving, the system determines buy power from the grid based on time
 periods, Load consumption quantity, and peak electricity purchase limits; when
 Inverter has only one Battery path.SOCAll below the reserved valueSOCFor
 Peakshaving, the system determines the buy power from the grid based on the
 Load consumption quantity and the peak electricity purchase limit.





Off-grid mode


NOTICE

Do not operate in pure off-grid mode when Inverter is not connected to Battery system.

When Grid disconnected, Inverter switches to off-grid operation mode.

- During the day, PV generation prioritizes supplying power to the load, with excess electricity directed to the Battery charge.
- At night, the Battery discharge supplies power to the load to ensure that the BACK-UP Loads does not POWER OFF.
- Off-grid SOC recovery: After the system operates off-grid, Battery gradually

restores to the minimum SOC level through photovoltaic power generation or other power generation methods.



SLG00NET0012

3.5 Features

NOTICE

For specific Features, please refer to the actual product configuration.

AFCI

Integrated AFCI circuit device, used to detect arc faults and quickly disconnect the circuit upon detection, thereby preventing electrical fires.

Causes of arc generation:

- Connectors in the photovoltaic system are damaged.
- Cable connection error or damage.
- · Connector and cable aging.

Troubleshooting method:

- 1. When an arc is detected, the fault type can be viewed on the Inverter display or via the App.
- 2. If the fault is triggered fewer than 5 times within 24 hours, the machine will automatically restore the on-grid Protection after a 5-minute wait. After the 5th arc fault, the fault must be cleared for the Inverter to resume normal operation. For detailed instructions, please refer to the "SolarGo APP User Manual."

model	label	Instructions
GW5K-ET-L-G10 GW6K-ET-L-G10 GW8K-ET-L-G10	AFCI: F-I-AFPE-1-2-1	F (Full coverage): Full coverage Inverter PV input port I(Integrated): Integrated within the Inverter AFPE (Arc Fault Protection Equipment): Combines the detection functions of both AFD and AFI. 1: A pair of PV inputs port (PV+, PV-) is connected to a string of PV input arrays. 2A arc detection sensor detects the number of PV input port. 1: Number of detection sensors for arc

model	label	Instructions
GW10K-ET-L-G10 GW12K-ET-L-G10 GW12K-ET-LL- G10	AFCI: F-I-AFPE-1-2/1-2	F (Full coverage): Full coverage Inverter PV input port I(Integrated): Integrated within the Inverter AFPE (Arc Fault Protection Equipment): Combines the detection functions of both AFD and AFI. 1: A pair of PV inputs port (PV+, PV-) is connected to a string of PV input arrays. 2/1A arc detection sensor detects the number of PV input port. 2: Number of arc detection sensors
GW15K-ET-L-G10 GW20K-ET-L-G10	AFCI: F-I-AFPE-1-2-2	F (Full coverage): Full coverage Inverter PV input port I(Integrated): Integrated within the Inverter AFPE (Arc Fault Protection Equipment): Combines the detection functions of both AFD and AFI. 1: A pair of PV inputs port (PV+, PV-) is connected to a string of PV input arrays. 2A arc detection sensor detects the number of PV input port. 2: Number of sensors for arc detection

Three-phase unbalanced output

Inverter on-grid terminal and BACK-UPBoth ends support three-phase unbalanced output, and each phase can be connected to different Power loads. The maximum output Power for each phase under different model conditions is shown in the following table:

No.	model	Single-phase maximum output power
1	GW5K-ET-L-G10	4kW
2	GW6K-ET-L-G10	4kW
3	GW8K-ET-L-G10	4kW
4	GW10K-ET-L-G10	6kW
5	GW12K-ET-L-G10	6kW
6	GW15K-ET-L-G10	10kW
7	GW20K-ET-L-G10	10kW
8	GW12K-ET-LL-G10	6kW

load control

Inverter Dry contact control port, supports connection of additional contactors for controlling load switching on/off. Compatible with household loads, heat pumps, etc. The method is as follows:

- Time Control: Set the time for turning the load on or off. The load will automatically turn on or off within the set time period.
- Switch control: When the control mode is set to ON, the load will be turned on; when the control mode is set to OFF, the load will be turned off.
- BACK-UP Loads Control: Inverter Built-in relay dry contact control port allows the relay to control whether the load is turned off. In off-grid mode, if an overload is detected at the BACK-UP terminal Battery and the SOC value is below the Battery off-grid Protection setpoint, the load connected to the relay port can be turned off.

Rapid Shutdown(RSD)快速关断

In a Rapid Shutdown system, the Rapid Shutdown transmitter works in conjunction with the receiver to enable system Rapid Shutdown. The receiver maintains module output by receiving signals from the transmitter. The transmitter can be externally mounted or integrated into the Inverter. In emergency situations, the transmitter can be deactivated by enabling an external trigger device, thereby shutting down the module.

External transmitter

- Transmitter model: GTP-F2L-20, GTP-F2M-20
 https://www.goodwe.com/Ftp/Installation-instructions/RSD2.0-transmitter.pdf
- Receiver model: GR-B1F-20, GR-B2F-20
 https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW-RSD-20_Quick-Installation-Guide-POLY.pdf
- Built-in transmitter
 - External trigger device: external switch
 - Receiver model: GR-B1F-20, GR-B2F-20
 https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW_RSD-20_Quick-Installation-Guide-POLY.pdf

4 Check and Storage

4.1 Check Before Receiving

Check the following items before accept.

- 1. Check the outer packing box for damage, such as holes, cracks, deformation, and other signs of equipment damage. Do not unpack the package and contact the supplier as soon as possible if any damage is found.
- 2. When removing the GW14.3-BAT-LV-G10 battery, make sure that the packaging carton is intact. If the packaging is damaged and you need to return or exchange the product due to quality issues, please contact GoodWe after-sales service or your dealer to obtain a special packaging box.
- 3. Check the product model. If the product model is not what you requested, do not unpack the product and contact the supplier.

4.2 Deliverables

WARNING

Check the deliverables for correct model, complete contents, and intact appearance. Contact the supplier as soon as possible if any damage is found.

4.2.1 Inverter Deliverables

Component	Instructions	Component	Instructions
	Inverter x1	o o	mounting plate x1
	Expansion screw x4		Grounding terminal x4

Component	Instructions	Component	Instructions
	• GW5K-ET-L-G10、GW6K-ET-L-G10、GW8K-ET-L-G10、GW10K-ET-L-G10、GW12K-ET-L-G10、GW12K-ET-LL-G10、GW20K-ET-L-G10、GW20K-ET-L-G10、CW20K-ET-L-G10×2		Lead-acid battery temperature sensor wire x N N: China region x 0; Other regions x 1.
	Lead-acid Battery temperature sensor cable fixing adhesive tape x N N: China region x 0; Other regions x 2.		Battery power cable PIN terminal • GW5K-ET-L-G10、GW6K-ET-L-G10、GW8K-ET-L-G10、GW10K-ET-L-G10、GW12K-ET-L-G10、GW12K-ET-L-G10×2 • GW15K-ET-L-G10×4
	6Pin communication terminal x 4		Signal line PIN terminal x 28

Component	Instructions	Component	Instructions
	GEN 750 x 4		BACKUP and ON-GRID
	CT x 3		• GW5K-ET-L-G10、GW6K-ET-L-G10、GW8K-ET-L-G10 x 2 • GW10K-ET-L-G10、GW12K-ET-L-G10 x 3 • GW12K-ET-LL-G10 x 3 • GW15K-ET-L-G10 x 4
	 (Optional) Anti-theft lock fixing sheet metal x 1 M5 screw x 1 Note: If an Installation anti-theft lock is required, please contact GoodWe to purchase the anti-theft lock fixing sheet metal. 		M6 Allen Wrench x 1

Component	Instructions	Component	Instructions
	Lifting rod x 1		PV unlocking tool x N N: China region x 0; Other regions x 1.
or	smart dongle x1		Product Documentation x 1

4.2.2 Batteries Deliverables

4.2.2.1 LX A5.0-30

Componen t	Description	Component	Description
	Battery module x1		Terminal resistor x 1 When connecting to a third-party busbar, this terminal resistor needs to be installed.

Componen	Description	Component	Description
	 M5 OT terminal x 2: Recommended for connecting 10mm² cable M8 OT terminal x 4: Recommended for connecting 50mm² cable M10 OT terminal x 2: Recommended for connecting 70mm² cable 		M5*12 grounding screw x 2
	Bracket x 2 For wall-mounted installation		M6* 70 Expansion bolts x 4 For wall-mounted installation
	M5*12 grounding screw x 2 For wall-mounted installation	: :	Line drawing template x 1 For wall-mounted installation
	Battery bracket x 2 (optional) For floor-mounted installation		M4*8 screw x 8 For floor-mounted installation
	Documents x 1		Negative power line (optional) x 1
	Positive power line (optional) x 1		Grounding cable (optional) x 1

Componen t	Description	Component	Description
	Communication cable (optional) x 1	(<u>17.</u> 77	Decorative cover (optional) x 1

4.2.2.2 Battery Deliverables (GW14.3- BAT-LV-G10)

Component	Description	Component	Description
	Battery module x1		Wire cover x 1
	Terminal resistor x 1		Documents x 1
	Expansion bolt x		Wall locking anti-tip bracket x 2
	Grounding OT terminal x 1		DC OT connector x 6
	M5*16 internal cross external hexagon screw x 7		Communication cable x
	Wall mount bracket (optional) x 1		Hooks (optional) x 4
	M5*16 internal cross external hexagon (optional) x 12		M10 Expansion bolts (optional) x 4

4.2.2.3 Batteries Deliverables(LX U5.0-30)

Component	Description	Component	Description
	Battery x 1		Plastic cover x 1
	Wall-mounted x 1		Expansion screwx 2
0 0	locking bracket x 2		 35-8 OT terminal x 4: Recommended connection with 25mm² or 35mm² cables 50-8 OT terminal x 4: Recommended to connect 50mm² cable 70-10 OT terminal x 2: Recommended to connect 70mm² cable
	14-5Grounding terminal x 2		M5 x 7
	M10 x 6		Wire harness fixing plate x 1

Component	Description	Component	Description
	Terminal resistor x 1		Product Documentation x 1

4.2.3 Busbar Deliverables

4.2.3.1 BCB-22-WW-0 (Optional)

Component	Description	Component	Description
	360A Manifold box x 1		M6 Expansion bolts x 4
	(258) OT terminal x 36 (7010) OT terminal x 6	-	-

4.2.3.2 BCB-32-WW-0, BCB-33-WW-0 (optional)

Component	Description	Component	Instructions
	720A Combiner Box x 1		M6 x 4
	(50-8) OT terminal x 30 (70-10) OT terminal x 6	-	-

4.2.4 GM330

Component	Description	Component	Description
	Smart meter x1		2 PIN terminal x1
	PIN terminal x 6		7 PIN terminal x1
	Screw driver x 1	7	Documents x 1

4.3 Storage

NOTICE

[1] The storage time is calculated from the SN date on the Battery outer packaging. After exceeding the storage period, Discharge maintenance charging is required. (Battery Maintenance time = SN date + Discharge maintenance charging cycle). For the method to check the SN date, please refer to:13.4.SN code meaning(Page 458). [2] After the charging maintenance is qualified, if there is a Maintaining Label on the outer box, please update the maintenance information on the Maintaining Label. If there is no Maintaining Label, please record the maintenance time and SOC (State of Charge) yourself and keep the data properly to facilitate the preservation of maintenance records.

If the equipment is not put into use immediately, please store it according to the following requirements. After long-term storage, the equipment must be inspected and confirmed by professionals before it can be used again.

- 1. If the storage time of Inverter exceeds two years or the non-operational time after Installation exceeds six months, it is recommended to undergo inspection and testing by professionals before being put back into service.
- 2. To ensure the good electrical performance of the internal electronic components of the Inverter, it is recommended to power it on every 6 months during storage. If it has not been powered on for more than 6 months, a professional inspection and testing are recommended before putting it into operation.

3. To ensure the performance and service life of the Battery, it is recommended to avoid long-term idle storage. Prolonged storage may lead to deep Discharge of the Battery, causing irreversible chemical degradation, capacity decay, or even complete failure. It is advisable to use it promptly. If the Battery requires long-term storage, please follow the maintenance requirements below:

Battery model	Initial SOC range for storage	Recom mende d Storag e Tempe rature	Charging Discharge Maintenance Cycle ^[1]	Battery maintenanc e method ^[2]	
LX A5.0-30	30%~40%	0~35°C	-20~45°C, ≤6 months	For	
GW14.3-BAT-LV-G10	30%~40%	0~35°C	-20~35°C, ≤12 months 35~45°C, ≤6 months	maintenance methods, please consult the dealer or after-sales service center.	
LX U5.0-30	30%~40%	0~35°C	-20~0°C, ≤1 month 0~35°C, ≤6 months 35~40°C, ≤1 month		

Packaging requirements:

Ensure the outer packaging box is not dismantle, and the desiccant inside the box is not missing.

Environmental requirements:

- 1. Ensure that Storage is placed in a shaded area and avoid direct sunlight.
- 2. Ensure the storage environment is clean, with an appropriate temperature range and no condensation. If condensation is observed on the equipment, do not operate the device.
- 3. Ensure that Storage is kept away from flammable, explosive, and corrosive materials.

stack requirements:


- 1. Ensure the Inverter stack is positioned at the correct height and orientation as indicated on the packaging label.
- 2. Ensure there is no risk of tipping after Inverter stack.

5 Installation

ADANGER

Install and connect the equipment with the deliverables included in the package. Otherwise, the manufacturer shall not be liable for the damage.

5.1 System Installation and Commissioning Procedure



5.2 Installation Requirements


5.2.1 Installation Environment Requirements

- 1. The equipment must not be operated in flammable, explosive, or corrosive environments.
- 2. The ambient temperature of the equipment Installation must be within the appropriate range.

- 3. Installation Location should be kept out of reach of children and avoid Installation in easily accessible locations.
- 4. Inverter The enclosure temperature may exceed 60°C during operation. Do not touch the enclosure before it cools down to prevent burns.
- 5. The equipment should be protected from exposure to sunlight, rain, snow, and other Installation conditions. It is recommended to Installation in a shaded Installation Location, and if necessary, a sunshade can be constructed.
- 6. Direct sunlight, high temperatures, and other adverse environmental conditions may lead to Inverteroutput derating.
- 7. The Installation space must meet the ventilation and heat dissipation requirements of the equipment as well as the operational space requirements.
- 8. The environment must meet the equipment's Ingress Protection Rating, Inverter, Battery, and smart dongle requirements for both indoor and outdoor Installation; the electric meter must comply with indoor Installation.
- 9. The height of the equipment Installation should facilitate operation and maintenance, ensuring that the equipment indicator and all labels are easily visible, and the wiring terminal is easy to operate.
- 10. Equipment Installation Altitude is below Max. Operating Altitude.
- 11. Before installing salt affected area outdoor Installation equipment, consult the manufacturer. salt affected area mainly refers to areas within 500m of the coast. The affected zone is related to factors such as sea breeze, precipitation, and terrain.
- 12. The DC line between Battery and Inverter, as well as the Communication cable line length, must be less than 3m. Please ensure that the Installation distance between Inverter and Battery meets the cable length requirement.
- 13. Keep away from strong magnetic fields to avoid electromagnetic interference. If there are radio stations or wireless communication devices operating below 30MHz near the Installation Location, please Installation the equipment according to the following requirements:
 - Inverter: Add ferrite cores with multiple turns on the Inverter DC input or AC output lines, or incorporate low-pass EMI Filter; or maintain a distance of over 30m between the Inverter and radio frequency interference equipment.
 - Other equipment: The distance between the equipment and the wireless electromagnetic interference device exceeds 30m.

NOTICE

- If the Installation is in an environment below 0°C, the Battery will be unable to continue Charge energy recovery after being emptied, resulting in Battery Under Voltage.
- LX A5.0-30, GW14.3-BAT-LV-G10, LX U5.0-30: Charge Temperature range: 0 < T ≤ 55°C; Discharge Temperature range: -20 < T ≤ 55°C




5.2.2 Installation Space Requirements

When working on equipment in the Installation system, sufficient space should be reserved around the equipment to ensure adequate Installation and heat dissipation

space.

- When using CAT 7E Communication cable between Inverter, the cable distance should not exceed 10 meters; when using CAT 5E or CAT 6E Communication cable, the cable distance should not exceed 5 meters. Communication cable must not exceed 10m, otherwise communication abnormalities may occur.
- Installation CTs shall use CAT 5E or higher shielded network cable, with cable length not exceeding 30 meters.
- The RS485 twisted-pair shielded cable for communication between Inverter and the electric meter, with a cable distance not exceeding 100 meters.



5.2.3 Tool Requirements

NOTICE

When Installation, it is recommended to use the following Installation tools. If necessary, other auxiliary tools can be used on-site.

Installation tool

Tool type	Description	Tool type	Instructions
	diagonal plier	O Participation of the Control of th	RJ45
To me	wire stripper		Level bar
	open-end wrench		PVterminalcrimp tool A-2546B
	hammer drill (Drill bit Φ13mm)		torque wrench M4、M5、M6、M8
	rubber hammer		socket wrench
	Marker pen		multimeter Range ≤1000V
	Heat shrink tubing		Hot air gun

Tool type	Description	Tool type	Instructions
	cable tie		Vacuum cleaner
9	single-axis		Cable gland unlocking tool Note: Please contact your distributor or GoodWe for purchase if needed.
	Inverter Battery cable crimp tool HS-95WF		Hex key wrench M16、M8
	(China Only) PV Unlocking Tool	-	-

personal protective equipment


Tool Type	Description	Tool type	Description
	Insulating gloves, protective gloves		Dust mask
	goggle		safety shoes

5.3 Equipment Handling

! \CAUTION		
C/1011014		

- 1. Operations such as transportation, turnover, installation and so on must meet the requirements of the laws and regulations of the country or region where inverters are installed.
- 2. Move the equipment to the site before installation. Follow the instructions below to avoid personal injury or equipment damage.
- 3. Please equip the corresponding personnel according to its weight, so that the equipment does not exceed the maximum weight that the personnel can carry to avoid personnel injuries.
- 4. Wear safety gloves to avoid personal injury.
- 5. Keep balance to avoid falling down when moving the equipment.
- 6. The battery system can be removed from the packaging box using a crane or hoist and transported to the installation site.
 - Crane requirements (GW14.3-BAT-LV-G10): Load capacity ≥ 180 kg
- 7. When moving equipment using a hoisting method, please use flexible slings or straps. The lifting rings and ropes for GW14.3-BAT-LV-G10 must meet the following requirements:
 - Suspension Ring: 4 M10 suspension rings, load capacity ≥ 260 kg
 - Suspension Rope: 1 suspension rope, rope length ≥ 2.5 m, suspension rope load capacity ≥ 600 kg


GW14.3-BAT-LV-G10:



5.4 Installing the Inverter

ACAUTION

- Avoid the water pipes and cables buried in the wall when drilling holes.
- Wear goggles and a dust mask to prevent the dust from being inhaled or contacting eyes when drilling holes.
- Make sure the inverter is firmly installed in case of falling down.
- 1. Put the mounting plate on the wall horizontally and mark positions for drilling holes.
- 2. Drill holes with hammer drill.
- 3. Use expansion bolts to fix the mounting plate on the wall.
- 4. (Optional) Install the lifting handle on the inverter.
- 5. Install the inverter on the mounting plate. Tighten the nuts to secure the mounting plate and the inverter.
- 6. (Optional) Install a security lock.



5.5 Installing the Battery System


5.5.1 LX A5.0-30

LX A5.0-30: Stacking installation

NOTICE


Up to 6 batteries can be stacked.

- 1. Place the battery vertically, and remove the battery handles.
- 2. Install brackets on the battery, and secure them with screws.
- 3. Place the battery flat and stack multiple batteries. Ensure that the locating pin is inserted into the locating hole.




LX A5.0-30: Cabinet Installation

- It is recommended to install it in a 19-inch standard cabinet with a length * width of 600*800mm and above, and the height should be determined based on the thickness of the battery (133mm) and above.
- For cabinet installation, electrical labels and warning labels need to be attached to any position of the front panel of the battery (these labels are shipped as additional accessories).
- 1. Place the battery on the guide rail of the rack and secure the battery to the rack with screws from the handle.



LX A5.0-30: Wall-mounted Installation

- 1. Determine the drilling position with installation positioning cardboard and marker pen.
- 2. Use an impact drill to drill holes.
- 3. Install the battery brackets.
- 4. Install the battery on the brackets and use screws to secure the battery.




5.5.2 GW14.3-BAT-LV-G10


NOTICE

• Wall mounting requires two people.

GW14.3-BAT-LV-G10: Floor-mounted installation




GW14.3-BAT-LV-G10: Wall-mounted Installation




5.5.3 LX U5.0-30

LX U5.0-30: Floor-mounted Installation




LX U5.0-30: Wall-mounted Installation



5.6 Installing the Smart Meter

AWARNING

In areas with lightning DANGER, if the meter cable length exceeds 10m and the cable is not routed with grounding Steel conduit, it is recommended to install external lightning protection devices.



GMK10INT0003

6 System Wirings

DANGER

- The installation, routing, and connection of cables must comply with local laws, regulations, and standard requirements.
- All operations during the electrical connection process, as well as the specifications of the cables and components used, must comply with local laws and regulations.
- Before performing electrical connections, please disconnect the DC switch and AC output switch of the equipment to ensure it is POWER OFF. Live operation is strictly prohibited, as it may lead to electric shock or other DANGER.
- Cables of the same type should be bundled together and arranged separately from different types of cables. Intertwining or cross-arrangement is strictly prohibited.
- If the cable is subjected to excessive tension, it may result in poor connections. When wiring, ensure to leave a certain length of slack in the cable before connecting it to the Inverter terminal port.
- When wiring the crimp, ensure that the conductor part of the cable makes full
 contact with the terminal. Do not crimp the cable insulation together with the
 terminal, as this may cause the equipment to fail to operate or result in
 unreliable connections leading to overheating, which could damage the Inverter
 terminal busbar.

- When performing electrical connections, wear safety shoes, protective gloves, insulated gloves, etc. as required.
- Only qualified personnel are permitted to perform electrical connection operations.
- The cable colors in the diagrams of this document are for reference only. The actual cable specifications must comply with local regulatory requirements.
- For parallel systems, please NOTICE comply with the user manuals corresponding to the relevant products in the system Safety Precautions.


6.1 System Wiring Electrical Block Diagram

NOTICE

- N and PE wiring of ON-GRID and BACK-UP ports of the inverter are different according to the regulation requirements of different regions. Refer to the specific requirements of local regulations.
- The inverter has a built-in electric meter that can be directly connected to a CT for use. The CT cable supplied with the box is 10 meters long. If a longer cable is required, a shielded cable that complies with local regulations can be used to extend the cable to 30 meters.
- When the length of the connection between the CT and the inverter exceeds 30 m, accuracy will decrease. If high accuracy is required, an external smart meter can be connected.
- The ON-GRID and GEN AC ports of the inverter have built-in relays. When the
 inverter is in off-grid mode, the built-in ON_GRID state relay is disconnected;
 when the inverter is in on-grid operation mode, the built-in ON-GRID relay is
 connected.
- When the inverter is powered on, the BACK-UP AC port is energized. Power off the inverter first if maintenance is required on the BACK-UP loads. Otherwise, it may cause electric shock.


N and PE cables are connected together in the Main Panel

- To maintain neutral integrity, the neutral lines on the grid-connected side and the off-grid side must be connected together, otherwise the off-grid function will not work properly.
- The figure below shows a schematic diagram of the power grid systems in Australia, New Zealand, and other regions:



N and PE cables are separately wired in the Main Panel

- Ensure that the grounding of BACK-UP is correctly tightened. Otherwise, the BACK-UP function may be abnormal in case of grid failure.
- The following diagram is applicable to areas except Australia or New Zealand:



6.2 Detailed System Wiring Diagram

When all the loads in the photovoltaic system cannot consume the electricity generated by the system, the surplus power will be fed back into the Utility grid. In this case, it can be paired with a Smart Meter or CT monitoring system to measure the power generation and control the amount of electricity fed into the Utility grid.

- Connecting Smart Meter enables output Power limitation and load monitoring functions.
- After connecting the Smart Meter, please enable the "Export power limit" function via the SolarGo App.

Detailed System Wiring Diagram only shows wiring connections for some model equipment. Please refer to the corresponding wiring guidance chapter for the actual

equipment used during installation.


NOTICE

- Optional GM330 meter. Please contact the distributor or GoodWe for purchase if needed.
- The microgrid scenario does not support hybrid inverter parallel operation.
- grid-tied PV inverter If output Power limitation is required, please connect a separate meter or CT (Current Transformer) device.
- When the built-in meter of Inverter is not used, do not connect the CT port of Inverter.


6.2.1 Detailed System Wiring Diagram for Single Inverter

General scenario

Built-in meter matching scenario




Matching GM330 scenario




Microgrid scenario

In microgrid scenarios, if output grid-tied PV inverter needs to be limited, please connect a separate meter or CT (Current Transformer) device.

Built-in meter matching scenario









Coupling scenario

When coupling scenarios, if output Power limitation is required, please connect a separate meter or CT device.

Built-in meter matching scenario



Matching with GM330 meter scenario



6.2.2 Detailed System Wiring Diagram for Parallel System


NOTICE

- If it is necessary to connect DRED devices, RCR devices, remote shutdown devices, NS Protection, SG Ready heat pumps, generators, etc. in the system, please connect them to Master inverter.
- remote shutdown/NS Protection Function: Please connect the Communication cable to the Master inverter. Rapid Shutdown (RSD: Rapid Shutdown) Function: Please connect the Communication cable to each Inverter individually. If you need to use both the Rapid Shutdown and remote shutdown/NS Protection functions simultaneously, please contact the after-sales service center.
- In a parallel system, if it is necessary to disconnect any port breaker of a Inverter, please simultaneously disconnect the other port breaker of this Inverter; otherwise, it may cause abnormal system operation.
- When using the Battery non-busbar access mode in a parallel system:
 - Inverter "BAT access mode" only supports "stand-alone access".
 - Each Battery interface of every Inverter must be connected to Battery system.
 - Compatible with different model of GoodWe, the relevant wiring methods can be referred to in the "6.8.Connecting the Battery Cable(Page 123)Chapter.
- If the parallel system contains GoodWe inverters of different model, it is necessary to configure the corresponding Battery parameters individually for each Inverter through the SolarGo APP. For detailed setup steps, please refer to "9.3.9.Enable Battery function(Page 265)Chapter.
- The following diagram highlights the wiring related to parallel operation. For other port wiring requirements, please refer to the single-unit system.

In parallel system, the Inverter connected to the meter is Master inverter, while the others are Slave inverter.


Master inverter must be configured as the master unit through the "Parallel System Settings" in the SolarGo App..For specific settings, please refer to <u>9.3.5.Configure</u> <u>RS485 parallel system(Page 221)</u>.

General scenario



In the general parallel operation scenario, the Battery busbar wiring method should refer to the Battery busbar wiring method in the coupling scenario.

Coupling scenario



In the parallel coupling scenario, the Battery hand-in-hand wiring method can be referenced to the general scenario Battery hand-in-hand wiring method.

6.3 Preparing Materials



- It is prohibited to connect any load between the Inverter and the AC Switch directly connected to the Inverter.
- Each Inverter must be equipped with an AC output breaker. Multiple Inverter units cannot be connected to the same AC breaker simultaneously.
- To ensure the safe disconnection of Inverter from Utility grid in case of abnormal conditions, please connect AC breaker to the AC side of Inverter. Select the appropriate AC breaker according to local regulations.
- When the Inverter power on is activated, the BACK-UP AC port becomes live. If maintenance is required on the BACK-UP Loads, please Inverter the power off to avoid the risk of electric shock.
- For cables used in the same system, it is recommended that the conductor material, cross-sectional area, length, etc., be consistent.
 - The BACK-UP AC line of each Inverter
 - The AC line of each Inverter ON-GRID
 - Inverter to Battery power cable cable
 - power cable cable between Battery and Battery
 - Inverter to busbar power cable cable
 - power cable cable between Battery and busbar

6.3.1 Preparing Breakers

No.	Circuit breaker	Recommended specifications	Acquisit ion method	Comment
1	 ON-GRID Circuit Breaker BACK-UP Load Breaker 	Some recommended backup power scenarios are as follows: Rated voltage≥230Vac. The rated current requirements are as follows: GW5K-ET-L-G10, GW6K-ET-L-G10: nominal current ≥20A GW8K-ET-L-G10, GW10K-ET-L-G10: nominal current ≥32A GW12K-ET-L-G10, GW15K-ET-L-G10, GW20K-ET-L-G10: nominal current ≥63A Rated voltage≥127Vac. The rated current requirements are as follows: GW12K-ET-L-G10: Nominal Current≥63A	Prepare d by custome rs	When selecting a circuit breaker, you can also choose one that meets local installation regulations based on the actual working current.
2	 ON-GRID Circuit Breaker BACK-UP Load Breaker 	The following are recommended scenarios for whole-house backup power supply: • Rated voltage≥230Vac. The rated current requirements are as follows: • GW5K-ET-L-G10, GW6K-ET-L-G10, GW8K-ET-L-G10, GW12K-ET-L-G10, GW20K-ET-L-G10: nominal current ≥100A • Rated voltage≥127Vac. The rated current requirements are as follows: • GW12K-ET-L-G10: Nominal Current≥100A	Prepare d by custome rs.	

No.	Circuit breaker	Recommended specifications	Acquisit ion method	Comment
3	GEN Breaker	Nominal Voltage≥230Vac The rated current requirements are as follows: 63A for all power segments.	Prepare d by custome rs.	
4	Battery Breaker	Optional in compliance with local laws and regulations • Rated voltage≥60Vdc. The rated current requirements are as follows: • GW5K-ET-L-G10: Nominal Current≥200A • GW6K-ET-L-G10: Nominal Current≥200A • GW8K-ET-L-G10: Nominal Current≥200A • GW10K-ET-L-G10: Nominal Current≥250A • GW12K-ET-L-G10: Nominal Current≥300A • GW15K-ET-L-G10: Nominal Current≥200A× 2 • GW20K-ET-L-G10: Nominal Current≥300A× 2 • Rated voltage≥60Vdc. The rated current requirements are as follows: • GW12K-ET-LL-G10: Nominal Current≥300A	Prepare d by custom ers.	
5	RCD	Optional in compliance with local laws and regulations • Type A • ON-GRID RCD: 300mA • BACK-UP RCD: 30mA	Prepare d by custome rs.	-

6.3.2 Preparing Cables

No.	cable	Recommended Specifications	Acquisition method	Remarks
1	InverterPE cable	 single core Outdoor copper cable conductorcross-sectional area: S=16mm² Cable outer diameter: 7.5mm-9.0mm 	self-owned	-
2	Battery PE cable	 single core Outdoor copper cable conductor cross-sectional area: LX A5.0-30: 10mm² GW14.3-BAT-LV-G10: 10mm² LX U5.0-30: 10mm² 	 self-supply LX A5.0-30: Accessory Acquisition (Optional) GW14.3- BAT-LV-G10: For some machines, the grounding cable is shipped with the Battery accessory. 	-
3	PV DC line	 Industry-standard outdoor photovoltaic cables conductorcross-sectional area: 4-6mm² Cable outer diameter: 5.9mm-8.8mm 	self-owned	-

No.	cable	Recommended Specifications	Acquisition method	Remarks
4	Battery DC line	 single core Outdoor copper cable InverterBatteryport Wiring Requirements: conductorcross-sectional area: 70mm² The cable requirements between Battery and the busbar: LX A5.0-30, conductorcross-sectional area: 50mm² GW14.3-BAT-LV-G10, conductor cross-sectional area: 70mm² LX U5.0-30, conductor cross-sectional area: 25mm² Cable requirements between Battery and Battery: LX A5.0-30, conductorcross-sectional area: 50mm² GW14.3-BAT-LV-G10, conductor cross-sectional area: 70mm² LX U5.0-30, conductor cross-sectional area: 70mm² LX U5.0-30, conductor cross-sectional area: 70mm² LX U5.0-30, conductor cross-sectional area: 25mm² 	 self-supply LX U5.0-30: Available for purchase from GoodWe LX A5.0-30: Accessory Acquisition (Optional) GW14.3- BAT-LV-G10: Some machines, Battery DC cable, are shipped with Battery accessories. 	-

No.	cable	Recommended Specifications	Acquisition method	Remarks
5	AC line	 AC input/output cable (BACK-UP/ON-GRID) conductorcross-sectional area: 16mm² multi-core Outdoor copper cable outer diameter: 25-32mm Generator power cable (GEN): conductorcross-sectional area:10mm² multi-core Outdoor copper cable outer diameter: 18mm-22mm 	Self-supply	When selecting the wire diameter, you can also choose a wire diameter that complies with local electrical regulations based on the actual working current.
6	Power cable	 Outdoor copper cable conductorcross-sectional area: 1mm² 	self-supply	-
7	BatteryBMSCo mmunication cable	Customized Communication cable, default length is3m	Shipped with Inverter	Self- recommend ation if needed:CAT 5Eand above specification s standard network cable andRJ45RJ45 connector


No.	cable	Recommended Specifications	Acquisition method	Remarks
8	Battery Communicatio n cable	Communication between the combiner box and Battery, as well as between Battery, requires the use of CAT 5E or higher specification standard shielded network cable and RJ45 shielded RJ45 connector.	 self-supply LX A5.0-10, LX A5.0-30: Accessory Acquisition (Optional) GW14.3- BAT-LV- G10: Inverter and Battery between Communi cation cable: partial standard- equipped Battery Communi cation cable: Self- provided, cable length 	
9	WiFi/LAN Kit- 20Communica tion cable	CAT 5E and above standard shielded network cables and RJ45 shielded RJ45 connector	self-owned	-

No.	cable	Recommended Specifications	Acquisition method	Remarks
10	CTCommunica tion cable	 Shielded wire compliant with local standards conductor cross-sectional area:0.2mm²-0.4mm² Cable outer diameter:5mm-8mm 	self-supply	-
11	EMS RS485	Shielded Twisted Pair		
12	Electric meter RS485Commu nication cable	(STP) • conductor cross-sectional area:0.2mm²-0.4mm²	self-supply	-
13	load control and generator control Communicatio n cable			-
14	remote shutdownCom munication cable Rapid ShutdownCom munication cable NS Protection	 Shielded wire compliant with local standards conductor cross-sectional area:0.2mm²-0.4mm² Cable outer diameter:5mm-8mm 	self-owned	-
15	RCR/DREDSign al line			-
16	Lead-acid Battery temperature sensor wire		self-owned	China only

No.	cable	Recommended Specifications	Acquisition method	Remarks
16	Parallel operation of inverters	 RJ45 RJ45 connector CAT 5E or higher specification straight-through Ethernet cable The recommended length for CAT 5E or CAT 6E should not exceed 5 meters. The recommended length for CAT 7E should not exceed 10 meters. 	self-owned	-


6.4 dismantleInverter Bottom Cover

dismantleInverter Bottom Cover of the Enclosure:



ETL10INT0003

(Optional) Use of gland unlocking tool:



ETL10INT0008

6.5 Connecting the PE cable

MARNING


- The Protection grounding of the chassis enclosure cannot replace the PE cable of the AC output port. When wiring, ensure that the PE cable at both locations is reliably connected.
- To improve the corrosion resistance of terminal, it is recommended to apply silica gel or paint on the exterior of Grounding terminal for protection after completing the connection of Installation to PE cable.
- When Installation equipment, the PE cable must be Installation first; when dismantle equipment, the PE cable must be dismantle last.

NOTICE


GW14.3-BAT-LV-G10:

- If the Battery grounding cable is already provided inside the packaging box, please use this cable directly without performing the crimp operation.
- If the Battery grounding cable is not provided in the packaging box, please follow the steps below to make the cable.

Inverter




Battery(GW14.3-BAT-LV-G10)




LXA10ELC0014

Battery(LX A5.0-30)




Battery(LX U5.0-30)



6.6 Connecting the AC Cable

MARNING

- The residual current monitoring unit (RCMU) is integrated into the inverter to avoid that the residual current exceeds the limit. The inverter will disconnect with the utility grid quickly once it found the residual current exceeds the limit.
- When connecting the wires, make sure that the AC wires are connected to the AC terminals labeled "BACK-UP," "ON-GRID," "GEN," and the ground port. Incorrect cable connections will damage the equipment.
- Ensure that the whole cable cores are inserted into the terminal holes, and no part of the cable core can be exposed.
- Ensure that the insulation board is inserted into the AC terminal tightly.
- Ensure that the cables are connected securely. Otherwise it will cause damage to the inverter due to overheat during its operation.



6.7 Connecting the PV Cable

ADANGER


- Do not connect the same PV string to multiple Inverter, as this may cause damage to the Inverter.
- Before connecting the PV string to the Inverter, please confirm the following information. Otherwise, it may cause permanent damage to the Inverter, and in severe cases, it may lead to a fire, resulting in personal injury and property loss.
 - 1. Please ensure that both Max. Short Circuit Current per MPPT and Max.Input Voltage are within the permissible range of Inverter.
 - 2. Please ensure that the positive terminal of the PV string is connected to the PV+ of Inverter, and the negative terminal of the PV string is connected to the PV- of Inverter.

!WARNING

- The PV string output does not support grounding. Before connecting the PV string to Inverter, ensure that the the minimum insulation resistance of the PV string meets the minimum insulation resistance requirement (R=Max.Input Voltage/30mA).
- After the connection is completed, ensure that the cables are securely fastened and free from looseness.
- Use a multimeter to measure the positive and negative terminals of the DC cable, ensuring correct polarity without reverse connection; and verify that the voltage is within the allowable range.


NOTICE

The two sets of PV String in each MPPT channel must adopt the same model, the same number of Battery panels, the same tilt angle, and the same azimuth to ensure the maximization of Efficiency.



ETL10ELC0002

If dismantlePV connector is required, please follow the steps below for dismantle.



ESA20ELC0014

6.8 Connecting the Battery Cable



- In a single inverter system, do not connect the same battery pack to multiple inverters, which may cause inverter damage.
- It is forbidden to connect loads between the inverter and the battery.
- When connecting battery cables, use insulated tools to prevent accidental electric shock or short circuit to the batteries.
- Ensure that the open circuit voltage of the battery is within the permissible range of the inverter.
- Install a DC breaker between the inverter and the battery in compliance with local laws and regulations.
- The battery supports connection to GoodWe busbars and third-party busbars. If you need to use a third-party busbar, please replace the terminal resistor with the black terminal resistor provided in the box.

NOTICE

The inverter supports a maximum of 15 batteries connected in parallel on a single circuit. If you require more batteries to be connected in parallel, please contact the GoodWe After-Sales Service Center.

Instructions for BMS communication connection between inverter and battery

Inverter port	Connected to the battery port	Port definition	Description
BMS1/BMS2	COM1	4: CAN_H 5: CAN_L	 The inverter communicates with the battery through CAN. Connect the BMS port of the inverter to the COM1 port of the battery.


LX A5.0-30 Communication Port Definition


PIN	COM1	COM2	Description
1	-	-	Dosoniod
2	-	-	Reserved
3	Parallel OUT+	Parallel OUT+	Parallel operation communication port
4	CAN_1H	CAN_1H	Connect the inverter communication port
5	CAN_1L	CAN_1L	or battery parallel communication port
6	Parallel OUT2+	Parallel OUT2+	Parallel interlock communication port
7	-	-	Reserved
8	Parallel OUT-	Parallel OUT-	Parallel operation communication port


GW14.3-BAT-LV-G10 Communication Port Definition


PIN	COM1	COM2	Description
1	RS485A	RS485A	Reserved
2	RS485B-	RS485B-	Reserved
3	Parallel OUT+	Parallel OUT+	Parallel operation communication port
4	CAN_H	CAN_H	Connect the inverter communication
5	CAN_L	CAN_L	port or battery parallel communication port
6	Parallel OUT2+	Parallel OUT2+	Parallel operation communication port
7	-	-	Reserved
8	Parallel OUT-	Parallel OUT-	Parallel operation communication port


Battery system wiring diagram




















ETL10NET0010







LX A5.0-30: When connecting the battery to a single 1-way output inverter. Type I:




Type II:




LX A5.0-30: When connecting the battery to a single 2-way output inverter.




LXA5.0-30: When connecting two output inverters using the BCB-22-WW-0 busbar connection method.




LX A5.0-30: When connecting two output inverters using the BCB-32-WW-0 busbar connection method.




LXA5.0-30: When connecting two output inverters using a third-party bus connection method.




GW14.3-BAT-LV-G10: When connecting the battery to a single 1-way output inverter. Type I:




Type II:




GW14.3-BAT-LV-G10: When connecting the battery to a single 2-way output inverter. Type I:




Type II:




GW14.3-BAT-LV-G10: When connecting two batteries to a single 2-way output inverter.




GW14.3-BAT-LV-G10: When connecting two output inverters using a busbar (BCB-32-WW-0).



GW14.3-BAT-LV-G10: When connecting two output inverters using a third-party busbar.



GW14.3-BAT-LV-G10, LXA5.0-30: Battery connected to a single 2-way output inverter.



ETL10ELC0025

6.8.1 Connecting the Power Cable between the Inverter and Battery

!WARNING


- Use a multimeter to measure the positive and negative terminals of the DC cable, ensuring correct polarity without reverse connection; and verify that the voltage is within the allowable range.
- During wiring, ensure that the Battery wire fully matches the "BAT+", "BAT-", and grounding port terminals of the Battery terminal. Incorrect cable connections may result in equipment damage.
- Ensure the conductor is fully inserted into the terminal terminal hole without any exposure.
- Please ensure the cable connections are securely fastened, otherwise loose connections may cause overheating during equipment operation, leading to device damage.
- Do not connect the same Battery group to multiple Inverters, as this may cause damage to the Inverter.

NOTICE


GW14.3-BAT-LV-G10:

- If the Batterypower cable cable is already provided inside the packaging box, please use this cable directly without performing the crimp operation.
- If the Batterypower cable cable is not provided in the packaging box, please follow the steps below to make the cable.

Overview of Inverter and Battery power cable




Inverter end cable fabrication




ETL10ELC0004

Battery and Combiner Box End Cable Fabrication Method (LX A5.0-30)




Battery and Combiner Box End Cable Fabrication Method (GW14.3-BAT-LV-G10)



LXA10ELC0015


Battery and Combiner Box End Cable Fabrication Method (LX U5.0-30)




6.8.2 Connecting the Communication Cable between the Inverter and Battery

It is recommended to use the included BMS communication cable in the package of the inverter. If the included communication cables do not meet the requirement, prepare shielded network cables and RJ connectors by yourself to make the cable. Only crimp PIN4 and PIN5 of the connector when making the cable, otherwise the communication may fail.

Connection diagram for inverter BMS1 communication:




Inverters BMS1 and BMS2 are both connected for communication, as shown in the diagram:



- When connecting the lead-acid battery temperature sensor cable, it is recommended to connect the temperature sensor cable at a location with poor heat dissipation. For example, when lead-acid batteries are placed side by side, the sensor should be fixed on the lead-acid battery located in the middle.
- To better protect the battery cell, a temperature sampling cable must be installed, and it is recommended to place the battery in a well-ventilated environment.


Lead-acid battery communication diagram:




6.9 Connecting the Meter Cable

- Ensure that the CT is connected in the correct direction and phase sequences, otherwise the monitoring data will be incorrect.
- Ensure all cables are connected correctly, tightly, and securely. Inappropriate wiring may cause poor contacts and damage the equipment.
- In areas at risk of lightning, if the meter cable exceeds 10m and the cables are not wired with grounded metal conduits, you are recommended to use an external lightning protection device.
- Outer diameter of the AC cable should be smaller than the holes diameter of the CT, so that the AC cable can be threaded through the CT.
- To ensure accurate current detection, the CT cable is recommended to be shorter than 30m.
- Do not use network cable as the CT cable, otherwise the smart meter may be damaged due to high current.
- The CTs vary slightly in dimensions and appearance among different models, but they are installed and connected in the same way.


Wiring of GMK110



Connection steps




Installing the CT (Type I)



GMK10ELC0006

Installing the CT (Type II)




6.10 Connecting the Inverter Communication Cable

NOTICE

- To ensure the proper functioning of the meter and CT, please ensure the following:
 - Please ensure the CTs are correctly matched and connected to the phase lines:
 CT1 to L1, CT2 to L2, and CT3 to L3.
 - Please connect the CT according to the meter's direction. If reversed, it may cause CT reverse fault.
 - When replacing or maintaining the CT later, use the "Meter/CT-Auxiliary Detection Function" on the SolarGo App to allow the Inverter to readapt to the CT sampling current direction.
- When using the built-in energy meter, please use the CT shipped with the box.
- Inverter if not connectedDREDDo not operate when working on equipment or remote shutdown equipment.SolarGo AppEnable this function, otherwise Inverter cannot on-grid operate.
- In a parallel system, to implement the DRED and RCR functions, simply connect the DRED and RCR Communication cable to Master inverter.
- To ensure the waterproof rating of the Inverter, do not dismantle the unused waterproof plugs on the Inverter.
- InverterDOSignal Communication Port, connectable dry contact signal specifications:Max<24Vdc,1A.
- Inverter Communication function is optional, please select according to actual usage scenarios.
- Inverter supports connecting to mobile phones or WEB interfaces via 4G,

Bluetooth, WiFi, and LAN communication methods to set device-related parameters, view device operation information and error messages, and promptly understand system status.

- In a single-unit system, it supports InstallationWiFi/LAN Kit-20 or 4G Kit-CN-G20Smart dongle.
- In a parallel system, the main Slave inverter must be equipped with the Installation WiFi/LAN Kit-20 Smart dongle for networking.
- When using the 4G Kit-CN-G20:
 - For grid connection, please contact GoodWe to purchase the WiFi/LAN Kit-20.
 - China Region standard-equipped Micro-SIM card, carrier is Mobile Communications. Please confirm that the device Installation is within the carrier's signal coverage area. If local mobile signal is not covered, please contact the carrier to optimize the signal.
 - Supports connection to third-party monitoring platforms via the MQTT communication protocol.
- The 4G Kit-CN-G20 is an LTE single-module device, suitable for application scenarios with lower requirements for data transmission rates.




Communication Function Description B

port(Screen Printing)		Function	Description	
A	PAR1	Parallel connection Communicati on Port1	Parallel operation Communication Port Please use CAT 5E or higher standard network cable and RJ45 RJ45 connector	

_	t(Screen nting)	Function	Description
В	PAR2	Parallel Connection Communicati on Port 2	
С	BMS 1	BMS	When connecting to lithium-ion Battery, it is used
D	BMS 2	communicati on	to interface with the Battery system BMS Communication cable, supporting communication via CAN signals.
Е	СТ	CT connection	When only using the built-in meter of the Inverter, it is necessary to connect the CT Communication cable cable.
F	DI	remote shutdown/NS protection/Ra pid Shutdown	 External remote shutdown or local NS protection device, disabled by default. In a Rapid Shutdown system, the Rapid Shutdown transmitter works in conjunction with the receiver to achieve system Rapid Shutdown. The receiver maintains module output by receiving signals from the transmitter. The transmitter can be externally mounted or integrated into the Inverter. In emergency situations, the transmitter can be deactivated by enabling an external trigger device, thereby shutting down the module.
	LOAD	load control	 Supports dry contact signal connection to enable functions such as load control. The DO contact rating is 12V DC@1A, with NO/COM normally open contacts. Supports SG Ready heat pump connection, controls the heat pump via dry contact signals for heat pump management.


	t(Screen nting)	Function	Description	
	GEN Generator for st Control port Conr		Supports connection to generator control signals for starting and stopping the generator. Connection to generators is not supported in microgrid scenarios.	
	EMS	EMS	Connect third-party EMS devices for energy control.	
G	METER	Meter connection port	Connect external Smart Meter using RS485 communication.	
	BAT-T	Lead-acid temperature sampling	Temperature sensing wire for connecting lead- acid temperature measurement.	
Н	DRED	RCR or DRED function connection port	 RCR (Ripple Control Receiver): Provides RCR signal control for port, meeting the dispatching requirements of Utility grid in European regions. DRED (Demand Response Enabling Device): Provides DRED signal control functionality, meeting the DERD requirements in regions such as Australia. 	
J	SW1		In a multi-unit parallel scenario, the parallel DIP	
K	SW2	Parallel coding switch	switches of the first and last Inverter units should be set to the ON position, while the switches of other Inverter units should be set to the OFF position.	

Connection Communication cable method



ETL10ELC0005


6.11 Installing Inverter Box Bottom Cover




ETL10INT0004

6.12 Installing the Battery Cover


6.12.1 LX A5.0-30



6.12.2 GW14.3-BAT-LV-G10



6.12.3 LX U5.0-30



7 System Commissioning

7.1 Check Before Power ON


No.	Inspection items
1	The equipment is firmly installed, easy to operate and maintain, with sufficient space for ventilation and heat dissipation, and the environment is clean and tidy.
2	DC line, AC line, Communication cable, and Terminal resistor are correctly and securely connected.
3	The cable ties meet the wiring requirements, are reasonably distributed, and show no signs of damage.
4	Unused through-holes and port should be reliably connected using the provided terminal accessories and properly sealed.
5	Ensure that all used cable pass-through holes are properly sealed.
6	The Inverter and Frequency of the on-grid access point comply with the on-grid requirements.

7.2 Power ON

≜WARNING

- Battery Black Start Function: When there is no PV power generation in the photovoltaic system and the Utility grid is abnormal, if the Inverter cannot operate normally, the Battery black start function can be used to forcibly start the Inverter via the Battery discharge. The Inverter can then enter off-grid operation mode, with the Battery supplying power to the load.
- After startup, ensure normal communication between Inverter and Battery system within 15 minutes. If Inverter and Battery system fail to communicate properly, the Battery system switch will automatically trip, and Battery system will undergo POWER OFF.
- When multiple Battery are connected in parallel in the system, starting any one Battery will activate all Battery.
 - GW14.3-BAT-LV-G10: After Battery and power off, perform power on again. It is necessary to restart each Battery individually or wait for 15 minutes before starting any one Battery, after which all Battery can be activated.

power on



- 1. (Optional) Close the Slave inverterON-GRIDbreaker.
- 2. Close the Master inverterON-GRIDbreaker.
- 3. Close the BACK-UPbreaker.
- 4. (Optional) Close GENbreaker.

- 5. (Select according to local regulations) Close the switch between Inverter and Battery.
- 6. Start Battery system.
 - GW14.3-BAT-LV-G10, LX U5.0-30: Integrate the Battery system into the breaker, close it, and briefly press the multifunction button for less than 1 second.
 - LX A5.0-30: Press the Battery system switch for ≤2s.
- 7. Close the DC switch of Inverter.

7.3 Indicators

7.3.1 Inverter Indicators

Indicat or	Status	Description
	шшшш	The inverter is starting up and in the self-check mode.
		The inverter is powered on and in the standby mode.
(1)	шшшш	BACK-UP output overload.
\odot		System failure.
		LCD ON: The inverter is powered on and in the standby mode. LCD OFF: The inverter is powered off.
port of the inverter is normal.		The grid is abnormal, and the power supply to the BACK-UP port of the inverter is normal.
		The grid is normal, and the power supply to the BACK-UP port of the inverter is normal.
		The BACK-UP port has no power supply.
((•))	<u></u>	The monitoring module of the inverter is resetting.
The inverter fails to termination.		The inverter fails to connect with the communication termination.
		Communication fault between the communication termination and server.

Indicat or	Status	Description	
		The monitoring of the inverter operates well.	
		The monitoring module of the inverter has not been started yet.	

7.3.2 Battery Indicators

7.3.2.1 LX A5.0-30

In	dicator	System Status
0000	No SOC indicator shows green.	SOC=0%
•000	The first SOC indicator shows green.	0% < SOC ≤ 25%
••00	The first two SOC indicators are green.	0% < SOC ≤ 25%
•••0	The first three SOC indicators are green.	0% < SOC ≤ 25%
••••	All SOC indicators are green.	0% < SOC ≤ 25%
	Green light is on.	The battery system is working normally.
	Green light flashes 1 time/s.	The battery system is in the standby mode.
	Green light flashes 3 time/s.	The PCS communication is lost.
RUN light	Green flashes slowly.	The battery system gives an alarm, and conducts a self-check. After the self-checking is over, it will change to normal working status or fault status.
ALM Light	Red light is on.	Check the SOC indicator status to identify the fault type and handle the problem as recommended in the Troubleshooting section.

7.3.2.2 LX A5.0-30、LX U5.0-30

in	dicator	System Status
0000	SOCindicator no green display	SOC=0%
•000	The first SOCindicator is displayed in green.	0% < SOC ≤ 25%
••00	The second SOCindicator is displayed in green.	25% < SOC ≤ 50%
•••0	The third SOCindicator is displayed in green.	50% < SOC ≤ 75%
••••	The fourth SOCindicator displays green.	75% < SOC ≤ 100%
	Green steady on	Battery system is operating normally
	Green flashing once per second	Battery system is in the Standby state
	Green flashing 3 times/s	PCS communication loss
RUN light	slow blinking	After an Battery system alarm occurs, a self-check will be performed. Wait for the self-check to complete, then transition to normal operation or fault status.
ALM light	Red steady on	Determine the type of fault that occurred based on the SOCindicator display format, and handle it according to the recommended methods in the Troubleshooting section.

7.3.2.3 GW14.3-BAT-LV-G10



Normal status

Indicat or Name	Indicator Status		Corresponding to Other Light Statuses	System Status
		SOC indicator shows green.		SOC=0% 0% < SOC ≤ 25% 0% < SOC ≤ 25% 0% < SOC ≤ 25% 0% < SOC ≤ 25%
SOC Indicat or		SOC indicator shows green.	/	The battery system is in discharging status.
Operatio n Indicato r Light + Touch Button		White light is on.	Blue-purple breathing light	The system is working normally.

Indicat or Name	Indicator Status		Corresponding to Other Light Statuses	System Status
		White light flashes.	Blue-purple marquee	The system is preparing.
Commu nication Light	((p))	White light is on.	/	PCS communication normal

Abnormal status

Indicat or name	Indicator	status	Corresponding to other light statuses	System Status
SOC Indicat or		SOC indicator shows green.	Red light flashes. Power Off Red light is on.	Check the SOC indicator status to identify the fault type and handle the problem as recommended in the Troubleshooting section.
Commu nication Light	((p))	Power Off	/	The PCS communication is lost.

Indicat or name	Indicator status		Corresponding to other light statuses	System Status
System Alarm Light	<u>(1)</u>	White light is on.	/	System alarms. Undervoltage faults 2, 3, and 4

7.3.3 Smart Meter Indicator

GM330

Туре	Status	Description
D 1: 1 /	On	Power on, no RS485 communication.
Power light	Blinks.	Power on, RS485 communication works properly.
	Off	The smart meter has been powered off.
Communication	Off	Reserved
indicator	Blinks.	Press the Reset button for more than 5 seconds, power light, buying or selling electricity indicator light flash: Reset the meter.
Importing or	On	Importing from the grid.
exporting	Blinks.	Exporting to the grid.
indicator	Off	Do not import from and export to the grid.
₩	Reserved	

7.3.4 Smart Dongle Indicator

• WiFi/LAN Kit-20

- Double-click the Reload button to enable Bluetooth, and the communication indicator will switch to a single-flash state. Please connect to the SolarGo app within 5 minutes, otherwise Bluetooth will automatically turn off.
- Communication indicator The single flash status only occurs after double-clicking the Reload button to enable Bluetooth.

indicator	Status	Instructions
Power		Always On: Smart dongle is power on.
LED		Extinguish: Smart dongle Not power on
		Always On: WiFi mode or LAN mode
		communication is normal.
		Single flash: Smart dongle Bluetooth signal is on,
		waiting to connect to SolarGo app.
communic	ш_ш_	Double flash: Smart dongle not connected to
communic		Router.
ation light		Four flashes: Smart dongle communicates
(G)))	1111	normally with Router, but fails to connect to
		Server.
		Six flashes: Smart dongle is identifying
		connected devices.
		Extinguished: Smart dongle Software reset in
		progress or not power on.

indicator	color	Status	Instructions
LAN communica		Always On	100Mbps wired network connection is normal.
tion indicator	green	Extinguish	 Network cable not connected. 100Mbps wired network connection anomaly. 10Mbps wired network connection is normal.

indicator	color	Status	Instructions
	Yellow	Constant On	10/100Mbps wired network connection is normal, with no communication data transmission or reception.
		flicker	Communication data transceiving.
		Extinguish	Network cable not connected.

Button	Description
Reload	Hold for 0.5~3 seconds, Smart dongle will be reset.
	Hold for 6~20 seconds, Smart dongle will restore factory settings.
	Double-click quickly to enable Bluetooth signal (only lasts for 5 minutes).

• 4G Kit-CN-G20

indicator	Status	Description
(I)		Constant On: Smart dongle has been power on.
		Off: Smart dongle not power on.
		Constant On: Smart dongle is connected to Server, communication is normal.
	• • • • • • • • • • • • • • • • • • • •	Double flash: Smart dongle not connected to the communication base station.
((G)))		Four flashes: Smart dongle is connected to the communication base station but not connected to Server.
		Six flashes: Communication between Smart dongle and Inverter is disconnected.
		Extinguished: Smart dongle Software reset in progress or not power on.

button	Description	
DELCIVID	Hold for 0.5~3 seconds, Smart dongle will restart.	
	Hold for 6~20 seconds, Smart dongle will restore factory settings.	

8 Rapid System Configuration

8.1 Downloading the App

8.1.1 Downloading SolarGo App

Make sure that the mobile phone meets the following requirements:

- Mobile phone operating system: Android 5.0 or later, iOS 13.0 or later.
- The mobile phone can access the Internet.
- The mobile phone supports WLAN or Bluetooth.


NOTICE

Once the SolarGo App has been installed, you will receive automatic notifications when updates are available.

Method 1: Search SolarGo in Google Play (Android) or App Store (iOS) to download and install the app.



Method 2: Scan the QR code below to download and install the App.



8.1.2 Downloading SEMS+ APP

Make sure that the mobile phone meets the following requirements:

- Mobile phone operating system: Android 6.0 or later, iOS 13.0 or later.
- The mobile phone can access the Internet.
- The mobile phone supports WLAN or Bluetooth.

Download Method:

Method 1:

Search SEMS+ in Google Play (Android) or App Store (iOS) to download and install the App.



Method 2:

Scan the QR code below to download and install the App.



8.2 Connecting the Hybrid Inverter (Bluetooth)

Step 1 Ensure that the inverter is power on, both the inverter and the communication module are working properly.


Step 2 Select **Bluetooth** tab on the SolarGo app hompage.

Step 3 Pull down or tap **Search Device** to refresh the device list. Find the device by the the inverter serial number. Tap the device name to log into the **Home** page. Select the device by checking the serial number of the master inverter when multi inverters are parallel connected.

Step 4 For first connection with the equipment via Bluetooth, there will be a Bluetooth pairing prompt, tap **Pair** to continue the connection.

Step 5 Log in as an Owner or an Installer. Initial password: 1234. Default password: 1234.

Step 6 (Optional): If connecting via WLA-*** or WFA-***, enable Bluetooth Stays On following the prompts as entering the device details page. Otherwise, the bluetooth signal of the device will be off after disconnection.



8.3 Setting Communication Parameters

The communication configuration interface may be different if the inverter uses different communication modes or connects different communication modules. Please refer to the actual interface.


8.3.1 Setting Privacy and Security Parameters

Type I

Step 1: Tap **Home > Settings > Communication Setting > Privacy & Security** to set the parameters.

Step 2: Set the new password for the WiFi hotspot of the communication module, and tap **Save**.


Step 3 Open the WiFi settings of your phone and connect to the inverter's WiFi signal (Solar WiFi***) with the new password.



Type II

Step 1: Tap **Home > Settings > Communication Setting > Privacy & Security** to set the parameters.

Step 2 Enable Bluetooth Stays On or WLAN Control based on actual needs.




No.	Parameters	Description
1	Bluetooth Stays On	Disabled by default. Enable the function, the bluetooth of the device will be contentious on to keep connected to SolarGo. Otherwise, the bluetooth will be off in 5 minutes, and the device will be disconnected from SolarGo.
2	WLAN Control	Disabled by default. Enable the function, the device and the SolarGo can be connected through the WLAN when they are on the same LAN. Otherwise, they cannot be connected even if they are on the same LAN.
3	Modbus-TCP	Enable the function, the third party monitoring platform can access inverter through Modbus-TCP communication protocol.
4	SSH control Ezlink	After enabling this function, third-party platforms can connect to and control EzLink's Linux system.

Type III

Step 1: Tap Home > Settings > Communication Setting > Privacy & Security to set

the parameters.

Step 2: Enable Bluetooth Stays On or Login Password based on actual needs.




No.	Parameters	Description
1	Bluetooth Stays On	Disabled by default. Enable the function, the bluetooth of the device will be contentious on to keep connected to SolarGo. Otherwise, the bluetooth will be off in 5 minutes, and the device will be disconnected from SolarGo.
2	Password	Disabled by default. Enable the function, you will be prompted to enter the login password when connecting the device to SolarGo. Use the initial password and change it at the first login prompt.

8.3.2 Setting WLAN/LAN Parameters

When the inverter is connected to different communication modules, the communication configuration interface may be different. Please refer to the actual interface.

Step 1: Tap **Home > Settings > Communication Setting > WLAN/LAN** to set the parameters.

Step 2: Configure the WLAN or LAN parameters based on actual needs.



No.	Parameters	Description
1	Network Name	Only for WLAN. Select WiFi based on the actual connecting.
2	Password	Only for WLAN. WiFi password for the actual connected network.
3	DHCP	Enable DHCP when the router is in dynamic IP mode. Disable DHCP when a switch is used or the router is in static IP mode.

No.	Parameters	Description
4	IP Address	Do not configure the parameters when DHCP is
5	Subnet Mask	enabled.
6	Gateway Address	Configure the parameters according to the router o switch information when DHCP is disabled.
7	DNS Server	


8.3.3 Configuring RS485 Parameters

NOTICE

Set the communication address of the inverter. For a single inverter, the address is set based on actual needs. For multi connected inverters, the address of each inverter should be different while cannot be 247.

Step 1: Tap **Home > Settings > Communication Settings > RS485** to set the parameters.

Step 2: Set the Modbus Address And Baud Rate base on actual situation.



8.4 Quick Setting the Basic Information

- The setting page varies depending on inverter model.
- The parameters will be configured automatically after selecting the safety country/region, including overvoltage protection, undervoltage protection, overfrequency protection, underfrequency protection, voltage/frequency connection protection, cosφ curve, Q(U) curve, P(U) curve, FP curve, HVRT, LVRT, etc. Tap Home > Settings > Advanced Settings > Safety Parameters to check the parameters after selecting the safety country.
- The power generation efficiency is different in different working modes. Set the working mode according to the local requirements and situation.
 - Self-use mode: The basic working mode of the system. PV power generation is used to supply power to the load first, the excess power is used to charge the battery, and the remaining power is sold to the grid. When PV power generation cannot meet the load's power demand, the battery will supply power to the load; when the battery power also cannot meet the load's power demand, the grid will supply power to the load.
 - Back-up mode: The back-up mode is mainly applied to the scenario where the grid is unstable. When the grid is disconnected, the inverter turns to off-grid mode and the battery will supply power to the load; when the grid is restored, the inverter switches to grid-tied mode.
 - Economic mode: It is recommended to use economic mode in scenarios when the peak-valley electricity price varies a lot. Select Economic mode only when it meets the local laws and regulations. Set the battery to charge mode during Vally period to charge battery with grid power. And set the battery to discharge mode during Peak period to power the load with the battery.
 - Off-grid mode: suitable for areas without power grid. PV and batteries form a
 pure off-grid system. PV generates electricity to power the load and excess
 electricity charges the battery. When PV power generation cannot meet the
 power demand of the load, the battery will supply power to the load.
 - Smart charging: In some countries/regions, the PV power feed into the utility grid is limited. Select Smart Charging to charge the battery using the surplus power to minimize PV power waste.
 - Peak shaving mode: Peak shaving mode is mainly applicable to peak power limited scenarios. When the total power consumption of the load exceeds the power consumption quota in a short period of time, battery discharge can be used to reduce the power exceeding the quota.

8.4.1 System Quick Settings (Type II)


Step 1Through**Home > Settings > Quick Configuration**Enter the parameter settings page.

Step 2Enter login password.

Step 3Some models support one-click configuration, select**Configuration Guide Mode**Rapid configuration system.


Step 4Select the safety standard country based on the country or region where Inverter is located. Additionally, for certain models, it is necessary to choose Grid type according to the actual connected Utility grid configuration. After completing the settings, please click**Next step**Set the Battery access mode or the number of Inverter parallel units. The Utility grid standard code is only configurable by Installation vendors.

Step 5Only parallel system. Set the number of Inverter parallel units. After completing the setup, please click Next to configure the Battery access mode.



Step 6Based on the actual situation of Battery connection, select the Battery connection mode. If there is no Battery connection, the basic parameter settings end here. If there is Battery connection, please click after completing the settings.**Next step**Set Batterymodel.

Step 7Based on the actual connection status of Battery, select Batterymodel. After completing the settings, please click**Next step**Set working mode.




For certain models, when paralleling Inverter via RS485, please set the Battery access mode to either busbar mode or non-busbar mode based on actual conditions, and select the Battery model. Once the master unit is configured, the slave units will automatically synchronize the Battery settings. If the Battery connected to the slave unit does not match the master unit, please access the Quick Settings interface via the slave SN on the homepage and configure the Battery model separately.



Step 8Set the working mode according to actual needs. After setting, please click. **Next step**, Work mode configuration completed. For certain models, after the work mode configuration is completed, the system automatically enters the CT/meter self-test state. During this process, Inverter will temporarily disconnect from the grid and then automatically reconnect.

Step 9Select the Battery based on actual conditions. **First Installation, routine operation**or **Changeover machine**.



No. Parameter Name

Back-up Mode


Utility grid Purchase of Electricity Charge

Description


No.	Parameter Name	Description	
2	Charge Power	The percentage of Power to Inverter Nominal power when purchasing electricity.	
TOU mo	de		
3	Start Time	Within the Start Time and End Time, the Battery	
4	End Time	performs Charge or Discharge based on the set charging Discharge mode and Nominal power.	
5	Charge Discharge mode	Set to Charge or Discharge based on actual requirements.	
6	InverterNomina I power	The percentage of Power to InverterNominal power during Charge or Discharge.	
7	Cut-off SOC	When the Battery power reaches the set SOC, stop Charge.	
peak sha	peak shaving		
8	Reserved SOC for Peakshaving	In Peakshaving mode, the Battery SOC is lower than the reserved SOC for Peakshaving. When the Battery SOC is higher than the reserved SOC for Peakshaving, the Peakshaving function is disabled.	
9	Peak power purchase limit	Set the maximum Power limit allowed for buy power from the grid. When the load consumption Power exceeds the sum of the electricity generated by the PV system and this limit, the excess Power is supplemented by Battery discharge.	
10	Time period for purchasing electricity Charge	During the period of purchasing electricity Charge, when Load consumption does not exceed the purchase quota, it can be supplied to Battery charge via Utility grid. Outside this time range, only photovoltaic power generation Power can be utilized to supply Battery charge.	
Time De	Time Delay Charge Mode		

No.	Parameter Name	Description	
11	Peak power selling limit	Set the peak Power limit according to the Utility grid standard requirements of certain countries or regions. The peak Power limit value must be lower than the local specified output Power limit value.	
12	PV prioritizes supplying power to Battery charge	Within the Charge timeframe, photovoltaic power generation is prioritized for supplying Battery charge.	
13	Startup time		

Step 10For devices that support one-click configuration, a template can be generated based on the completed configuration.




Step 11If there is a one-click configuration template available, you can use the existing template to directly import the mode and quickly complete the configuration.



SLG00CON0120

8.5 Creating a Station

- **Step 1**: Tap on overview or station page, or tap **Create Station** on service page.
- **Step 2**: Enter station information on the **Creat Station** page.
- **Step 3**: Tap **Save&Exit** to complete creating a station, without devices added. Or tap **Save&Continue** to add devices. Support adding multiple devices.



9 System Commissioning

9.1 Commissioning Method Overview

The inverter without LCD screen only supports setting the inverter through the SolarGo APP.

The inverter with LCD screen supports setting the inverter through LCD screen and the SolarGo APP.

9.2 Configuration via LCD

9.2.1 LCD Overview

Through the LCD screen, users can:

- 1. View the device's operational data, software version, alarm information, etc.
- 2. Set parameters, safety regulation regions, power limit, etc.


NOTICE

The model of the equipment varies, and the LCD display interface will differ depending on the safety regulation country set. Please refer to the actual interface display.

Introduction to LCD Interface

The LCD supports both touch and button operation.


General Status



Name/Icon	Instructions
	upward

Name/Icon	Instructions	
	Downward	
	Confirm	
ESC	 Short press: Exit page Press and hold for 5 seconds simultaneously: Restart the device 	
	Used to view PV current, voltage, and power generation information.	
	 Used to view information such as Battery model and status. GW5K-ET-L-G10, GW6K-ET-L-G10, GW8K-ET-L-G10, GW10K-ET-L-G10, GW12K-ET-L-G10 display a single Battery GW15K-ET-L-G10, GW20K-ET-L-G10 display dual Battery 	
	Used to view the Inverter fault code	
•	Used to enter the settings interface of Inverter	
***************************************	Used to view the status information of Utility grid.	
	Used to view the status of the generator	
**	Used to view the load information of Inverter.	
•	Return to the main interface	
Cancel	Return to the previous menu	
Next	Proceed to the next setup page	
Back	Return to the previous settings page	

Microgrid status








Name/Icon	Description	
	Upward	
\bigcirc	Downward	
	Confirm	
ESC	 Short press: Exit page ESC and Press and hold for 5 seconds simultaneously: Restart the device 	
	Used to view PV current, voltage, and power generation information.	
	 Used to view information such as Battery model and status. GW5K-ET-L-G10, GW6K-ET-L-G10, GW8K-ET-L-G10, GW10K-ET-L-G10, GW12K-ET-L-G10 display a single Battery GW15K-ET-L-G10, GW20K-ET-L-G10 display two channels of Battery 	
<u> </u>	Used to view the Inverter fault code	
•	Used to enter the setup interface of Inverter	
R	Used to view the status information of Utility grid.	

Name/Icon	Description	
PV	Used to display the status of grid-tied PV inverter	
(A)	To view the load information of Inverter	
	Return to the main interface	
Cancel	Return to the previous menu	
Next	Proceed to the next setup page	
Back Return to the previous settings page		

LCD setting interface structure




9.2.2 Parallel system configuration

- 1. Through the main interface, click > Parallel System Settings, enter the parameter configuration interface.
- 2. Based on the actual wiring of Inverter, set it as master, slave, or standalone.
- 3. After completing the settings, click "Confirm". The interface will display "Confirm OK" indicating the parameters have been successfully set.

NOTICE

Please ensure to click "Confirm" on each page to validate the parameters; otherwise, the system will operate with default settings.


Set Master inverter parameters





ESL10CON0006


Set Slave inverter parameters





ESL10CON0007

Set single unit




ESL10CON0008

9.2.3 Quick Settings

Set safety regulations

- 1. Through the main interface, click Quick Settings > Safe Code, enter the parameter configuration interface.
- 2. Please select the corresponding safety code based on the country or region where the equipment is located.
- 3. After completing the settings, click "Confirm". The interface will display "Confirm OK" indicating the parameters have been successfully set.




ETL10CON0002

Set Battery parameters

- 1. Through the main interface, click Quick Settings > BAT Setting, enter the parameter setting interface.
- 2. Please set the parameters according to the actual situation.
- 3. After completing the settings, click "Confirm". The interface will display "Confirm OK" indicating the parameters have been successfully configured.

NOTICE

Please ensure to click Confirm on each page to make the parameters take effect; otherwise, the system will operate with default settings.



Basic parameter settings

BAT Connection Mode	Туре	Instructions
Battery	GOODW E	If the system is connected to a GoodWe brand lithium Battery, select GOODWE and choose the correct model.
	Default	If the third-party lithium Batterymodel connected in the system is not listed, please select based on the actual situation: Lithium 50Ah Lithium 100Ah

	Others	If the third-party lithium Batterymodel connected in the system is listed here, please select the correct model based on the actual situation.
	Lead acid	If the system is connected to a lead-acid Battery, select Lead acid and choose the correct lead-acid type. Currently, GEL, AGM, and Flooded are supported.
NO Battery	No Battery is connected to the system	
BAT Setting	Set according to the actual connected Battery in the system.	

Lithium Battery parameter settings

Parameter Name	Description	
SOC Protection	Enable or disable the SOCProtection function.	
Depth Of Discharge	Inverteron-grid During operation, the maximum depth of	
(On-Grid)	discharge Protection point of Battery.	
Depth Of Discharge	During off-grid operation, the maximum depth of	
(Off-Grid)	discharge Protection point of Battery.	
	To ensure the Battery SOC is sufficient to maintain normal	
Backup SOC Holding	system operation when off-grid, during on-grid operation,	
backup 30C Holding	the Battery will charge via Utility grid or PV Charge until	
	reaching the preset SOC Protection value.	

Lead-acid Battery parameter settings

Parameter Name		Description
Maximum	Charging	Battery charge defaults to constant charging mode;
Current		The maximum Charge voltage and the maximum
Constant Charging Voltage		Charge current in this mode need to be set; please configure according to Battery Technical Data.
Float Voltage		
The Time Float Charging		


Maximum Current For Switch To Float Charge	When Battery chargecurrent is less than Maximum Current For Switch To Float Charge and the duration reaches The Time Float Charging, the Battery charge status changes from constant charge mode to float charge mode. Float Voltage is the maximum Battery Charge voltage in float charging mode. Please set it according to Battery Technical Data.
Battery Capacity	Set the Battery capacity according to the actual connected Battery parameters.
Internal Resistance	The internal resistance present in Battery should be configured according to Battery Technical Data.
Temperature Compensation	When the default temperature exceeds 25°C, the upper limit of Charge voltage decreases by 3mV for every 1°C increase. Please adjust the settings based on the actual Battery Technical Data.
Lower Limit Of Discharge Voltage	Please configure according to Battery Technical Data.
Maximum Discharging Current	Please configure according to Battery Technical Data. The larger the Dischargecurrent, the shorter the Battery operating time.

Set working mode


- 1. Through the main interface, click Quick Settings > Working Mode, enter the parameter setting interface.
- 2. Please set the parameters according to the actual situation.
- 3. After completing the settings, click "Confirm". The interface will display "Confirm OK" indicating the parameters have been successfully set.

NOTICE

Please ensure to click Confirm on each page to make the parameters effective, otherwise the system will operate with default parameters.








ETL10CON0008

Parameter Name		Description
Self-use Mode		When the working mode is set to Self-use Mode, the Back-up Mode, TOU Mode, and Off-Grid Mode can be enabled simultaneously. Please select according to actual conditions. The operational priority of working modes is: Off-Grid Mode > Back-up Mode > TOU Mode > Self-use Mode.
Back-up Mode	Charging From Grid	Enable this function to allow the system to buy power from the grid.
	Rated Power	The percentage of Power to Inverter Nominal power when purchasing electricity.
TOU Mode	Time	Within the Start Time and End Time, the Battery performs Charge or Discharge based on the configured charging Discharge mode and Nominal power.
	Charge/Dischar ge	Set to Charge or Discharge based on actual requirements.
	Power (%)	The percentage of Power to InverterNominal power during Charge or Discharge.

	Bat (%)	When the Battery power reaches the set SOC, the Charge is stopped. To set the stop SOC for Battery discharge, please refer to 9.3.9.9.2.2.2 Set Battery parameters (Page 265) Chapter, set Depth of Discharge (On-Grid) and Depth of Discharge (Off-Grid) via the LCD screen.
Off-Grid Mode		In off-grid mode, Inverter disconnects from Utility grid, supplying power only to BACK-UP Loads, with excess energy directed to Battery charge.

Set PV connection mode

- 1. Through the main interface, click Quick Settings > PV Connect Mode, enter the parameter configuration interface.
- 2. Please set the parameters according to the actual situation.
- 3. After completing the settings, click "Confirm". The interface will display "Confirm OK" indicating the parameters have been successfully set.



Parameter Name

Stand-alone Connect

The PV String is connected in a one-to-one correspondence with the MPPT port on the Inverter side.

When a string of PV String is connected to the Inverter side multi-channel MPPT port, other PV modules are simultaneously connected to other MPPT port on the Inverter side.

	When the external PV String is connected to the Inverter
Parallel Connect	side photovoltaic input port, one PV String is connected
	to multiple photovoltaic inputs port.

Set Export power limit

- 1. Through the main interface, click Quick Settings > Power Limit, enter the parameter setting interface.
- 2. Please set the parameters according to the actual situation.
- 3. After completing the settings, click "Confirm". The interface will display "Confirm OK" to indicate successful parameter configuration.




ESU10CON0016

Parameter Name	Instructions
Power Limit	According to the Utility grid standard requirements of certain countries or regions, this function should be enabled when it is necessary to limit the output Power.
Export Power	Set according to the maximum Power that can actually be input to Utility grid.
External CT Ratio	 Set as the ratio of the primary side to the secondary side current of the external CT. Built-in meter: No need to set CT ratio. Default CT ratio is 120A/40mA. GM330: CT can be sourced from GoodWe or purchased separately, with a CT ratio requirement of nA/5A. A: CT primary side input current, range of n is 200-5000. 5A: CT secondary output current.


Electric Meter/CT Auxiliary Testing

- 1. Through the main interface, click Quick Settings > Meter/CT Assisted Test, enter the parameter configuration interface.
- 2. Click Start Test to begin the detection. After the test is completed, determine the result based on the interface prompts.



9.2.4 Setting Advanced Parameters

- 1. Tap Home > Advanced Settings to set the parameters. Enter the initial password: 1111.
- 2. Set the parameters based on actual needs.
- 3. After the setting is completed, please click Confirm. After the interface prompts Confirm OK, the parameters are set successfully.




Parameter	Description	
One-click restart	By using this function, the inverter can be quickly restarted.	
	After being turned on, the battery can be awakened when it shuts down due to undervoltage protection.	
Battery Wake-up	Only applicable to lithium batteries without circuit breakers. After being turned on, the output voltage of the battery port is about 60V.	

Off-grid Switch	In off-grid mode, the switch controls the on/off of the inverter's off-grid function. In on-grid mode, this function does not take effect. The switch is initially in the ON state, and the off-grid function is enabled. After the inverter is powered on, the off-grid output function of the inverter is enabled. In the off-grid state, turning off and then turning on the off-grid switch, the off-grid overload time can be known and the off-grid output can be restarted.
Shadow Scan	Enable Shadow Scan when the PV panels are severely shadowed to optimize the power generation efficiency.

9.2.5 Setting Immediate Charging

- 1. Tap Home 😊 Immediate Charging to set the parameters.
- 2. Set the parameters based on actual needs.
- 3. After the setting is completed, please click Confirm. After the interface prompts Confirm OK, the parameters are set successfully.



Parameter	Description
Immediate Charging	Enable to charge the battery by the grid immediately. This takes effect once. Enable or Disable based on actual needs.
SOC For Stopping Charging	Stop charging the battery once the battery SOC reaches SOC For Stopping Charging.

	Indicates the percentage of the charging power to the
	inverter rated power when enabling Immediate
Immediate Charging	Charging.
Power	For example, setting the Immediate Charging Power of
	a 10kW inverter to 60, which means the charging power
	of the inverter is 10kW*60%=6kW.

9.2.6 Setting the Basic Information

- 1. Tap Home 🐤 Basic Settings to set the parameters.
- 2. Set the parameters based on actual needs.
- 3. After the setting is completed, please click Confirm. After the interface prompts Confirm OK, the parameters are set successfully.



9.2.7 Setting Port Connection

NOTICE


In microgrid mode, if you need to set the relevant parameters of grid-tied PV inverter, please connect SolarGo APP for configuration.

Setting Port Connection generator

- 1. Through the main interface, click Port Connection, enter the parameter setting interface.
- 2. Please set the parameters according to the actual situation.
- 3. After completing the settings, click "Confirm". The interface will display "Confirm OK" to indicate successful parameter configuration.

NOTICE

Please ensure to click "Confirm" on each page to validate the parameters; otherwise, the system will operate with default settings.



No.	Parameter Name	Instructions
1	Generator ON/OFF	Control the start and stop of the generator. Only applicable to generators supporting dry contacts.
2	Rated Power	Generator's Nominal power.
3	Run Time	The continuous operation time of the generator. After exceeding the set operation time, the generator will automatically shut down. This function is only effective for generators that support dry contact connections.
4	Max Charging Power	Set as Max charge power with generator as Battery charge.
5	SOC for Starting Charging	Set the generator to start at the Battery charge SOC. When the SOC of Battery falls below the set value, the generator will charge the Battery charge.


6	SOC for Stopping Charging	Set the generator to stop charging Battery charge at the specified SOC. When the SOC of Battery reaches the set value, the generator will cease charging Battery charge.
7	Maximum Operation Voltage	Set the operational voltage upper limit for the generator.
8	Minimum Operation Voltage	Set the operating voltage lower limit of the generator.
9	Upper Limit Of Operating Frequency	Set the operational Frequency upper limit for the generator.
10	Lower Limit Of Operating Frequency	Set the operating Frequency lower limit of the generator.
11	Delay Before Load	No-load preheating time of the generator before loading.
12	Prohibited Working Hours	Please set the prohibited operating time for the generator according to actual conditions.

Setting Port Connection load control Dry contact mode

- 1. Through the main interface, click Port Connection, enter the parameter setting interface.
- 2. Please set the parameters according to the actual situation.
- 3. After completing the settings, click "Confirm". The interface will display "Confirm OK" indicating the parameters have been successfully configured.

NOTICE

Please ensure to click Confirm on each page to ensure the parameters take effect; otherwise, the system will operate with default parameters.



1	Load Control ON/OFF	Enable/Disable load control function
2	Dry Contact Mode	ON: When the switch status is set to ON, power supply to the load is initiated. OFF: When the switch status is set to OFF, power supply to the load is terminated.
3	Time Mode	Within the set time period, the load will automatically supply power to the load or POWER OFF. Standard mode or intelligent mode can be selected.
4	Load Control 1	Set the 1st group load control time, up to 4 groups can be set.
5	Mode: Standard/Intelligent	Standard mode: Supplies power to the load within the set time period. Smart Mode: Within the set time period, when the remaining energy generated by photovoltaics exceeds the preset load Nominal power, power supply to the load begins.
6	Load Consumption Time	Minimum operating time after load is turned on to avoid frequent switching due to energy fluctuations. Only applicable in smart mode.
7	Load Rated Power	When the surplus energy generated by photovoltaics exceeds this load Nominal power, it begins to supply power to the load. This applies only to intelligent mode.
8	SOC Mode	Inverter has built-in relay dry contact control port, which can control whether to supply power to the load through the relay.
9	Off-Grid Battery Protection Value	In off-grid mode, if an overload is detected at the BACK-UP terminal or the BatterySOC value falls below the off-grid BatteryProtection setting, the power supply to loads connected to the relay port can be stopped. Please set the off-grid BatteryProtection value according to actual requirements.

9.2.8 Viewing Device Information

1. Tap Home 🐤 Device Information to search the parameters.

NOTICE

Inverter serial number, DSP, BMS, LCD and ARM can be queried.



9.3 SolarGo APP

9.3.1 Product Introduction

NOTICE

- All the user interface (UI) screenshots or words in this document are based on SolarGo app V6.6.0. The UI may be different due to the version upgrade. The screenshots, words or data are for reference only.
- The method to set parameters is the same for all inverters. But the parameters displayed varies based on the equipment model and safety code. Refer to the actual interface display for specific parameters.
- Before setting any parameters, read through user manual of the App and the inverter or charger to learn the product functions and features. When the inverter parameters are set improperly, the inverter may fail to connect to the utility grid or fail to connect to the utility grid in compliance with related requirements and damage the battery, which will affect the inverter's power generation.

SolarGo App is a mobile application that communicates with the inverter via Bluetooth, WIFi, 4G, or GPRS. Commonly used functions are as follows:

- Check the operating data, software version, alarms of the inverter, etc.
- Set grid parameters and communication parameters of the inverter.

- · Set charging mode of the charger.
- Maintain the equipment.

9.3.1.1 Downloading and Installing the App


Make sure that the mobile phone meets the following requirements:

- Mobile phone operating system: Android 5.0 or later, iOS 13.0 or later.
- The mobile phone can access the Internet.
- The mobile phone supports WLAN or Bluetooth.


NOTICE

After installing the app, it can automatically prompt users to update the app version.

Method 1: Search SolarGo in Google Play (Android) or App Store (iOS) to download and install the app.



Method 2: Scan the QR code below to download and install the app.




9.3.1.2 App Connection


Connect as the following shows after powering on the equipment.

NOTICE

The connection distance varies depending on smart dongles. Refer to the actual used smart dongles.



9.3.1.3 GUI Introductions to Login Page



No.	Name/Icon	Description	
1	SEMS	Tap the icon to open the page downloading the SEMS Portal app.	
2	?	Tap to read the connection guide.	
	Not found		
3	···	 Check information such as app version, local contacts, etc. Other settings, such as update date, switch language, set temperature unit, etc. 	
4	Bluetooth/Wi Fi/4G	Select based on actual communication method. If you have any problems, tap or NOT Found to read the connection guides.	

No.	Name/Icon	Description
5	Device List	 The list of all devices. The last digits of the device name are normally the serial number of the device. Select the device by checking the serial number of the master inverter when multi inverters are parallel connected. The device name varies depending on the inverter model or smart dongle model: Wi-Fi/LAN Kit, Wi-Fi Kit, Wi-Fi Box: Solar-WiFi*** External or integrated bluetooth mudule:Solar-BLE*** WiFi/LAN Kit-20: WLA-*** WiFi Kit-20: WFA-*** Ezlink3000: CCM-BLE***; CCM-***; *** 4G Kit-CN-G20/4G Kit-CN-G21: GSA-***; GSB-*** 4G Kit-G20: GSC-*** Micro inverter: WNN*** AC Charger: ***
6	Search Device	Tap Search Device if the device is not found.

9.3.2 Connecting the Hybrid Inverter (Bluetooth)

Step 1 Ensure that the inverter is power on, both the inverter and the communication module are working properly.


Step 2 Select **Bluetooth** tab on the SolarGo app hompage.

Step 3 Pull down or tap **Search Device** to refresh the device list. Find the device by the the inverter serial number. Tap the device name to log into the **Home** page. Select the device by checking the serial number of the master inverter when multi inverters are parallel connected.

Step 4 For first connection with the equipment via Bluetooth, there will be a Bluetooth pairing prompt, tap **Pair** to continue the connection.

Step 5 Log in as an Owner or an Installer. Initial password: 1234. Default password: 1234.

Step 6 (Optional): If connecting via WLA-*** or WFA-***, enable Bluetooth Stays On following the prompts as entering the device details page. Otherwise, the bluetooth signal of the device will be off after disconnection.



9.3.3 GUI Introductions to Hybrid Inverters



No.	Name/Icon	Description
1	Serial Number	Serial number of the connected inverter.
2	Device Status	Indicates the status of the inverter, such as Working,Fault, etc.
3	Energy Flow Chart	Indicates the energy flow chart of the PV system. The actual page prevails.
4	System Status	Indicates the system status, such as Safety Code, Working Mode, Battery Model, Battery Status, Power Limit, Three- Phase Unbalanced Output, etc
5	A	Home. Tap Home to checkSerial Number, Device Status, Energy Flow Chart, System Status, etc.
6	=	Parameters. Tap Parameters to check the inverter Data.

No.	Name/Icon	Description
7	···	 Settings Tap to perform quick settings, basic settings, advanced settings, etc. on the inverter. Login required to access Quick Setup and Advanced Setting. Contact the supplier or after sales service for password. Password for professional technicians only.

9.3.4 Setting Communication Parameters


NOTICE

The communication configuration interface may be different if the inverter uses different communication modes or connects different communication modules. Please refer to the actual interface.

9.3.4.1 Setting Privacy and Security Parameters

Type I


- **Step 1**: Tap **Home > Settings > Communication Setting > Privacy & Security** to set the parameters.
- **Step 2**: Set the new password for the WiFi hotspot of the communication module, and tap **Save**.
- **Step 3** Open the WiFi settings of your phone and connect to the inverter's WiFi signal (Solar WiFi***) with the new password.



Type II

Step 1: Tap **Home > Settings > Communication Setting > Privacy & Security** to set the parameters.

Step 2 Enable Bluetooth Stays On or WLAN Control based on actual needs.




No.	Parameters	Description
1	Bluetooth Stays On	Disabled by default. Enable the function, the bluetooth of the device will be contentious on to keep connected to SolarGo. Otherwise, the bluetooth will be off in 5 minutes, and the device will be disconnected from SolarGo.
2	WLAN Control	Disabled by default. Enable the function, the device and the SolarGo can be connected through the WLAN when they are on the same LAN. Otherwise, they cannot be connected even if they are on the same LAN.
3	Modbus-TCP	Enable the function, the third party monitoring platform can access inverter through Modbus-TCP communication protocol.
4	SSH control Ezlink	After enabling this function, third-party platforms can connect to and control EzLink's Linux system.

Type III

Step 1: Tap Home > Settings > Communication Setting > Privacy & Security to set

the parameters.

Step 2: Enable Bluetooth Stays On or Login Password based on actual needs.



No.	Parameters	Description
1	Bluetooth Stays On	Disabled by default. Enable the function, the bluetooth of the device will be contentious on to keep connected to SolarGo. Otherwise, the bluetooth will be off in 5 minutes, and the device will be disconnected from SolarGo.
2	Password	Disabled by default. Enable the function, you will be prompted to enter the login password when connecting the device to SolarGo. Use the initial password and change it at the first login prompt.


9.3.4.2 Setting WLAN/LAN Parameters

NOTICE

When the inverter is connected to different communication modules, the communication configuration interface may be different. Please refer to the actual interface.

Step 1: Tap **Home > Settings > Communication Setting > WLAN/LAN** to set the parameters.

Step 2: Configure the WLAN or LAN parameters based on actual needs.



No.	Parameters	Description
1	Network Name	Only for WLAN. Select WiFi based on the actual connecting.
2	Password	Only for WLAN. WiFi password for the actual connected network.
3	DHCP	Enable DHCP when the router is in dynamic IP mode. Disable DHCP when a switch is used or the router is in static IP mode.

No.	Parameters	Description
4	IP Address	Do not configure the parameters when DHCP is
5	Subnet Mask	enabled.
6	Gateway Address	Configure the parameters according to the router or
7	DNS Server	switch information when DHCP is disabled.


9.3.4.3 Configuring RS485 Parameters

NOTICE

Set the communication address of the inverter. For a single inverter, the address is set based on actual needs. For multi connected inverters, the address of each inverter should be different while cannot be 247.

Step 1: Tap **Home > Settings > Communication Settings > RS485** to set the parameters.


Step 2: Set the Modbus Address And Baud Rate base on actual situation.



9.3.4.4 WLAN Detection

Step 1: Tap **Home > Settings > Communication Settings > WLAN Detection.**.

Step 2: Tap **Diagnosis** to check the network connection status.




9.3.5 Setting Up the RS485 Parallel System

NOTICE

- When paralleling hybrid inverters via RS485, you must set each inverter as the master or slave inverter individually using the SolarGo App.
- When an inverter in a parallel system needs to be used as a single unit, it must be set to standalone inverter via the SolarGo App.
- Please set the inverter connected to the meter as the master.
- Please first set the slave inverter address, then set the parallel network through the master.
- Step 1: Go to the settings interface via Settings > Parallel System Settings.
- **Step 2**: Set the inverter to Master, Slave, or Stand-alone based on its actual wiring.

- If the inverter is the master, set it to Master and then exit the connection. After setting the slave inverter address, return to this interface, click **Parallel Networking**, set the number of inverters in the parallel system, and then click **Network**.
- If the inverter is the slave, set the **Inverter Address** and click \lor .



9.3.6 Quick Setting the Basic Information

NOTICE

- The setting page varies depending on inverter model.
- The parameters will be configured automatically after selecting the safety country/region, including overvoltage protection, undervoltage protection, overfrequency protection, underfrequency protection, voltage/frequency connection protection, cosφ curve, Q(U) curve, P(U) curve, FP curve, HVRT, LVRT, etc. Tap Home > Settings > Advanced Settings > Safety Parameters to check the parameters after selecting the safety country.
- The power generation efficiency is different in different working modes. Set the working mode according to the local requirements and situation.
 - Self-use mode: The basic working mode of the system. PV power generation is used to supply power to the load first, the excess power is used to charge the battery, and the remaining power is sold to the grid. When PV power generation cannot meet the load's power demand, the battery will supply power to the load; when the battery power also cannot meet the load's power demand, the grid will supply power to the load.
 - Back-up mode: The back-up mode is mainly applied to the scenario where the grid is unstable. When the grid is disconnected, the inverter turns to off-grid mode and the battery will supply power to the load; when the grid is restored, the inverter switches to grid-tied mode.
 - Economic mode: It is recommended to use economic mode in scenarios when the peak-valley electricity price varies a lot. Select Economic mode only when it meets the local laws and regulations. Set the battery to charge mode during Vally period to charge battery with grid power. And set the battery to discharge mode during Peak period to power the load with the battery.
 - Off-grid mode: suitable for areas without power grid. PV and batteries form a
 pure off-grid system. PV generates electricity to power the load and excess
 electricity charges the battery. When PV power generation cannot meet the
 power demand of the load, the battery will supply power to the load.
 - Smart charging: In some countries/regions, the PV power feed into the utility grid is limited. Select Smart Charging to charge the battery using the surplus power to minimize PV power waste.
 - Peak shaving mode: Peak shaving mode is mainly applicable to peak power limited scenarios. When the total power consumption of the load exceeds the power consumption quota in a short period of time, battery discharge can be used to reduce the power exceeding the quota.

9.3.6.1 System Quick Settings (Type II)


Step 1Through**Home > Settings > Quick Configuration**Enter the parameter settings page.

Step 2Enter login password.

Step 3Some models support one-click configuration, select**Configuration Guide Mode**Rapid configuration system.

Step 4Select the safety standard country based on the country or region where Inverter is located. Additionally, for certain models, it is necessary to choose Grid type according to the actual connected Utility grid configuration. After completing the settings, please click**Next step**Set the Battery access mode or the number of Inverter parallel units. The Utility grid standard code is only configurable by Installation vendors.

Step 5Only parallel system. Set the number of Inverter parallel units. After completing the setup, please click Next to configure the Battery access mode.




Step 6Based on the actual situation of Battery connection, select the Battery connection mode. If there is no Battery connection, the basic parameter settings end here. If there is Battery connection, please click after completing the settings.**Next step**Set Batterymodel.

Step 7Based on the actual connection status of Battery, select Batterymodel. After completing the settings, please click**Next step**Set working mode.




For certain models, when paralleling Inverter via RS485, please set the Battery access mode to either busbar mode or non-busbar mode based on actual conditions, and select the Battery model. Once the master unit is configured, the slave units will automatically synchronize the Battery settings. If the Battery connected to the slave unit does not match the master unit, please access the Quick Settings interface via the slave SN on the homepage and configure the Battery model separately.



Step 8Set the working mode according to actual needs. After setting, please click. **Next step**, Work mode configuration completed. For certain models, after the work mode configuration is completed, the system automatically enters the CT/meter self-test state. During this process, Inverter will temporarily disconnect from the grid and then automatically reconnect.

Step 9Select the Battery based on actual conditions. **First Installation, routine operation**or **Changeover machine**.



No. Parameter Name

Back-up Mode


Utility grid Purchase of Electricity Charge

Description


No.	Parameter Name	Description	
2	Charge Power	The percentage of Power to Inverter Nominal power when purchasing electricity.	
TOU mo	de		
3	Start Time	Within the Start Time and End Time, the Battery	
4	End Time	performs Charge or Discharge based on the set charging Discharge mode and Nominal power.	
5	Charge Discharge mode	Set to Charge or Discharge based on actual requirements.	
6	InverterNomina I power	The percentage of Power to InverterNominal power during Charge or Discharge.	
7	Cut-off SOC	When the Battery power reaches the set SOC, stop Charge.	
peak sha	aving		
8	Reserved SOC for Peakshaving	In Peakshaving mode, the Battery SOC is lower than the reserved SOC for Peakshaving. When the Battery SOC is higher than the reserved SOC for Peakshaving, the Peakshaving function is disabled.	
9	Peak power purchase limit	Set the maximum Power limit allowed for buy power from the grid. When the load consumption Power exceeds the sum of the electricity generated by the PV system and this limit, the excess Power is supplemented by Battery discharge.	
10	Time period for purchasing electricity Charge	During the period of purchasing electricity Charge, when Load consumption does not exceed the purchase quota, it can be supplied to Battery charge via Utility grid. Outside this time range, only photovoltaic power generation Power can be utilized to supply Battery charge.	
Time De	Time Delay Charge Mode		

No.	Parameter Name	Description
11	Peak power selling limit	Set the peak Power limit according to the Utility grid standard requirements of certain countries or regions. The peak Power limit value must be lower than the local specified output Power limit value.
12	PV prioritizes supplying power to Battery charge	Within the Charge timeframe, photovoltaic power generation is prioritized for supplying Battery charge.
13	Startup time	

Step 10For devices that support one-click configuration, a template can be generated based on the completed configuration.



Step 11If there is a one-click configuration template available, you can use the existing template to directly import the mode and quickly complete the configuration.




9.3.7 Setting the Basic Information

9.3.7.1 Setting the SPD

After enabling SPD, when the SPD module is abnormal, there will be SPD module abnormal alarm prompt.

Step 1: Tap **Home > Settings > Basic Settings > SPD**, to set the parameters.

Step 2: enable or disable the function based on actual needs.




9.3.7.2 Setting the Back-up Power Parameters

After enabling Backup, the battery will power the load connected to the backup port of the inverter to ensure Uninterrupted Power Supply when the power grid fails.

Step 1: Tap **Home > Settings > Basic Settings > Backup**, to set the parameters.

Step 2: Set the backup supply function based on actual needs.



No.	Parameters	Description
1	UPS Mode- Full Wave Detection	Check whether the utility grid voltage is too high or too low.
2	UPS Mode- Half Wave Detection	Check whether the utility grid voltage is too low.
3	EPSmode-with LVRT support.	Stop detecting utility grid voltage.
4	First Cold Start (Off-grid)	It will only take effect once. In off-grid mode, enable First Cold Start (Off-grid) to output backup supply with battery or PV.


No.	Parameters	Description
5	Cold Start Holding (Off-grid)	Take effect multiple times. In off-grid mode, enable First Cold Start (Off-grid) to output backup supply with battery or PV.
6	Clear Overload History	Once the power of loads connected to the inverter BACK-UP ports exceeds the rated load power, the inverter will restart and detect the power again. The inverter will perform restart and detection several times until the overloading problem is solved. Tap Clear Overload History to reset the restart time interval after the power of the loads connected to the BACK-UP ports meets the requirements. The inverter will restart immediately.

9.3.7.3 Setting the Shadow Scan

Enable Shadow Scan when the PV panels are severely shadowed to optimize the power generation efficiency.


Step 1: Tap **Home > Settings > Basic Settings> Shadow Scan**, to set the parameters.


Step 2: Enable or disable the function based on actual needs. Set the Shadow Scan interval and MPPT shadow scan if the inverter supports.



9.3.7.4 Setting Power Adjustment Parameters

- **Step 1**: Go to the settings interface via **Home > Settings > Basic Settings > Power Scheduling**.
- **Step 2**: Set the active power dispatch or reactive power dispatch parameters according to the actual situation.





SLG00CON0124

No.	Parameter	Description
Active Sch	Active Scheduling	

No.	Parameter	Description
1	Active Scheduling Mode	According to the requirements of the power grid company in the country/region where the inverter is located, control the active power according to the selected dispatch mode. Supports: • Disabled: Disables active scheduling. • Fixed value reduction: Dispatch according to a fixed value. • Percentage reduction: Dispatch based on a percentage of the rated power.
2	Active Power	 When the active power dispatch mode is set to fixed value derating, the active power is set to a fixed value. When the active power dispatch mode is set to percentage derating, the active power is set as a percentage of the rated power. 比。
Reactive S	Scheduling	
3	Reactive Scheduling Mode	According to the requirements of the power grid company in the country/region where the inverter is located, control the reactive power according to the selected dispatch mode. Supports: • Disabled: Disables reactive scheduling. • Fixed value compensation: Dispatch according to a fixed value. • Percentage compensation: Dispatch based on a percentage of the rated power. • PF compensation.
4	Status	Set the power factor as lagging or leading based on actual needs and local grid standards and requirements.

No.	Parameter	Description
5	Reactive Power	 When the reactive power dispatch mode is set to fixed value derating, the reactive power is set to a fixed value. When the reactive power dispatch mode is set to percentage derating, the reactive power is set as a percentage of the rated power.
6	Power Factor	When the reactive power dispatch mode is set to PF compensation, set the power factor.

9.3.8 Setting Advanced Parameters

NOTICE


Contact the supplier or after sales service for Advanced Setting password. Password for professional technicians only.

9.3.8.1 Setting Three-phase Unbalanced Output

Enable the Three-phase unbalanced output when connecting unbalanced loads, which means L1, L2, L3 of the inverter respectively connected to loads with different power. Only for three phase inverters.

Step 1: Tap **Home > Settings > Advanced Settings > Three-phase Unbalanced Output** to set the parameters.

Step 2: Enable or disable the function based on actual needs.




9.3.8.2 Setting the Backup N and PE Relay Switch

To comply with local laws and regulations, ensure that the relay inside the back-up port remains closed and the N and PE wires are connected when the inverter is working off-grid.

Step 1: Tap **Home > Settings > Advanced Settings > Backup N and PE Relay Switch** to set the parameters.


Step 2: Enable or disable the function based on actual needs.



9.3.8.3 Setting DRED/Remote Shutdown/RCR/EnWG 14a

Enable DRED/Remote Shutdown/RCR before connecting the third party DRED, remote shutdown, or RCR device to comply with local laws and regulations.

- **Step 1**: Tap **Home > Settings > Advanced Settings > DRED/Remote Shutdown/RCR** to set the parameters.
- **Step 2**: Enable or disable the function based on actual needs.
- **Step 3**: For areas where the EnWG 14a regulation applies, when enabling the RCR function, you need to select the RCR mode according to the actual device type and set the DI port power.




9.3.8.4 Setting the Power Limit Parameters

Step 1: Tap Home > Settings > Advanced Settings > Power Limit to set the

parameters.

- **Step 2**: Turn on or off the power limit function according to actual needs.
- **Step 3**: After turning on the function, enter the parameter value according to actual needs and tap "\" to successfully set the parameter.


9.3.8.4.1 Set the grid-connected power limit parameters (general)



No.	Parameters	Description
1	Power Limit	Turn on this function when output power needs to be limited according to the grid standards of some countries or regions.
2	Export Power	Set according to the maximum power that can be input to the grid.
3		Set the ratio of the primary current to the secondary current of the external CT.

9.3.8.5 Setting the AFCI Detection

Step 1: Tap **Home > Settings > Advanced Settings > AFCI Test** to set the parameters.



Step 2: Enable AFCI Test, Clear AFCI Alarm and Self-Check based on actual needs.

No.	Parameters	Description
1	AFCI Test	Enable or disable AFCI accordingly.
2	AFCI Test Status	The detection status like Not Self-checking.
3	Clear AFCI Alarm	Clear ARC Faulty alarm records.
4	Self-check	Tap to check whether the AFCI function works normally.


9.3.8.6 Setting Power Adjustment Response Parameters

Step 1: Go to the parameter settings page via **Home > Settings > Advanced Settings** > **Power Adjustment Response Parameters**.

Step 2: Based on actual requirements, select **Disable, Slope Adjustment**, or **First-Order Low-Pass Filter** Mode from the Active Power Adjustment drop-down menu. If you select slope adjustment, enter the power change gradient value; if you select first-order low-pass filter mode, enter the first-order low-pass filter time parameter value.

Step 3: Based on actual requirements, select **Disable, Slope Adjustment**, or **First-Order Low-Pass Filter** Mode from the Reactive Power Adjustment drop-down menu. If you select slope adjustment, enter the power change gradient value; if you select first-order low-pass filter mode, enter the first-order low-pass filter time parameter value.

Step 4: Click \lor to save the settings.



SLG00CON0125


No.	Parameter	Description	
Active	Active Adjustment Response Mode		
1	First-order Low- pass Filter	Within the response time constant, active adjustment is implemented according to a first-order low-pass curve.	
2	First-order Low- pass Filter Time Parameter	Set the time constant within which the active power changes based on the first order LPF curve.	
3	Slope Adjustment	Implement active power dispatch based on the power change slope.	
4	Power Change Gradient	Set the slope of active power adjustment changes.	
Reacti	Reactive Adjustment Response Mode		


No.	Parameter Description	
5	First-order Low- pass Filter	Within the response time constant, reactive adjustment is implemented according to a first-order low-pass curve.
6	First-order Low- pass Filter Time Parameter	Set the time constant within which the reactive power changes based on the first order LPF curve.
7	Slope Adjustment	Implement reactive power dispatch based on the power change slope.
8	Power Change Gradient	Set the slope of reactive power adjustment changes.


9.3.8.7 Setting Safety Parameters

NOTICE

Set the custom safety parameters in compliance with local requirements. Do not change the parameters without the prior consent of the grid company.








SLG00CON0076


9.3.8.7.1 Setting the Reactive Power Mode

Step 1 : Tap Home > Settings > Advanced Settings > Safety Parameter Setting > Reactive Power Mode Settings to set the parameters.

Step 2: Set the parameters based on actual needs.



Cosφ Curve




No.	Parameters	Description	
Fix PF			
1	Fix PF	Enable Fix PF when it is required by local grid standards and requirements. After the parameters are set successfully, the power factor remains unchanged during the operation of the inverter.	
2	Under-excited	Set the power factor as lagging or leading based on actual needs and local grid standards and requirements.	
3	Over-excited		
4	Power Factor	Set the power factor based on actual needs. Range: 0-~-0.8, or +0.8~+1.	
Fix Q			
1	Fix Q	Enable Fix Q when it is required by local grid standards and requirements.	
2	Over- excited/Under- excited	Set the reactive power as inductive or capacitive reactive power based on actual needs and local grid standards and requirements.	
3	Reactive Power	Set the ratio of reactive power to apparent power.	
Q(U) (Q(U) Curve		
1	Q(U) Curve	Enable Q(U) Curve when it is required by local grid standards and requirements.	

No.	Parameters	Description	
2	Mode Selection	Set Q(U) curve mode, supporting basic mode and slope mode.	
3	Vn Voltage	The percentage of actual voltage to the rated voltage at Vn point, n=1, 2, 3, 4. When set to 90, it means: V/Vrated% = 90%.	
4	Vn Reactive Power	The percentage of the reactive output power to the apparent power at Vn point, n=1, 2, 3, 4. For example, setting Vn Reactive Power to 48.5 means Q/Srated%=48.5%。	
5	Voltage Deadband Width	When Q(U) curve mode is set to slope mode, this parameter defines the voltage deadband range where no reactive power output is required.	
6	Over-excitation Slope	(In Q(U) slope mode) Sets the positive or negative slope	
7	Under- excitation Slope	for reactive power variation during over-voltage conditions.	
8	Vn Reactive Power	The percentage of the reactive output power to the apparent power at Vn point, n=1, 2, 3, 4. For example, setting Vn Reactive Power to 48.5 means Q/Srated%=48.5%。	
9	Q(U) Curve Response Time Constant	The reactive power must reach 95% of the target value within 3 time constants, following a first-order low-pass filter curve.	
10	Extended Function	Enable the extended function and configure the corresponding parameters.	
11	Lock-In Power	When the inverter output reactive power to the rated power ratio is between the Lock-in power and Lock-out power, the ratio meets Q(U) curve requirements.	
12	Lock-out Power		
Cosφ(Cosφ(P) Curve		

No.	Parameters	Description
1	Cosφ(P) Curve	Enable Cosφ Curve when it is required by local grid standards and requirements.
2	Mode Selection	Set cosφ(P) Curve Mode and support basic mode and slope mode configurations.
3	N-point Power	The percentage of inverter output active power relative to rated power at the N-point. N=A, B, C, D, $\rm E_{\circ}$
4	N-point cosφ Value	N-point Power Factor N=A, B, C, D, E。
5	Over-excitation Slope	When cosφ(P) curve mode is set to slope mode,
6	Under- excitation Slope	configures the power variation slope as either positive or negative.
7	N-point Power	The percentage of inverter output active power relative to rated power at the N-point. N=A, B, C。
8	N-point cosφ Value	N-point Power Factor N=A, B, C。
9	cosφ(P) Curve Response Time Constant	The reactive power must reach 95% of the target value within 3 time constants, following a first-order low-pass filter curve.
10	Extended Function	Enable the extended function and configure the corresponding parameters.
11	Lock-in Voltage	When the grid voltage is between Lock-in Voltage and
12	Lock-out Voltage	Lock-out Voltage, the voltage meets Cosφ curve requirements.
Q(P) Curve		
1	Q(P) Curve Function	Enable Q(P) Curve when it is required by local grid standards and requirements.
2	Mode Selection	Set Q(P) curve mode, supporting basic mode and slope mode.

No.	Parameters	Description
3	Pn-point Power	The percentage of the output reactive power to the rated power at Pn point, n=1, 2, 3, 4, 5, 6. For example, setting to 90 means Q/Prated%=90%.
4	Pn-point Reactive Power	The percentage of the output active power to the rated power at Pn point, n=1, 2, 3, 4, 5, 6. For example, When set to 90, it means: P/Prated% = 90%.
5	Over-excitation Slope	When the Q(P) curve mode is set to slope mode, configure the power variation slope as either a positive or negative value.
6	Under- excitation Slope	
7	Pn-point Power	Ratio of reactive power to rated power at Pn points (n=1, 2, 3). For example, setting to 90 means Q/Prated%=90%.
8	Pn-point Reactive Power	Ratio of active power to rated power at Pn points (n=1, 2, 3). For example, When set to 90, it means: P/Prated% = 90%.
9	Time Constant	The reactive power must reach 95% of the target value within 3 time constants, following a first-order low-pass filter curve.

9.3.8.7.2 Setting the Active Power Mode





SLG00CON0149

Step 1: Tap Home > Settings > Advanced Settings > Safety Parameter Settings > Active Power Mode Settings to set the parameters.


Step 2: Set the parameters based on actual needs.







P(U) Curve



No.	Parameter s	Explanation
1	Generation Power Limit	Set the change slope when the active output power increases or decreases.
2	Power Gradient	Set the active power change slope.
Overf	requency Unl	oading
1	P(F) Curve	Enable P(F) Curve when it is required by local grid standards and requirements.
2	Over- Frequency Load Shedding Mode	 Set the overfrequency unloading mode based on actual needs. Slope mode: adjusts power based on the over frequency point and load reduction slope. Stop mode: adjusts the power based on the over-frequency start point and over-frequency end point.
3	Overfreque ncy Threshold	The inverter output active power will decrease when the utility grid frequency is too high. The inverter output power will decrease when the utility grid frequency is higher than Overfrequency Threshold .
4	Import/Exp ort Electricity Conversion Frequency	When the set frequency value is reached, the system switches from selling electricity to buying electricity.
5	Overfreque ncy Endpoint	The inverter output active power will decrease when the utility grid frequency is too high. The inverter output power will stop decreasing when the utility grid frequency is higher than Overfrequency Endpoint .

No.	Parameter s	Explanation
6	Over- Frequency Power Slope Reference Power	Adjust the inverter output power based on Apparent Active Power, Rated Active Power, Momentary Active Power, Or Max. Active Power.
7	Power response to overfreque ncy gradient	The inverter output active power will increase when the utility grid frequency is too high. Indicates the slope when the inverter output power decreases.
8	Tentional Delay Ta	Indicates the delayed response time when the inverter output power is higher than the Overfrequency Threshold .
9	Hysteretic Function	Enable the hysteretic function.
10	Frequency Hysteresis Point	During over-frequency load reduction, if the frequency decreases, the power output is based on the lowest point of the load reduction power until the frequency is less than the hysteresis point and the power is restored.
11	Hysteresis Waiting Time	For over-frequency load reduction and frequency decrease, when the frequency is less than the hysteresis point, the power recovery waiting time, that is, it takes a certain amount of time to recover the power.
12	Hysteresis Power Recovery Slope Reference Power	For over-frequency load reduction and frequency decrease, when the frequency is less than the hysteresis point, the power recovery benchmark, that is, the power recovery is based on the recovery slope * the rate of change of the reference power. Support: Pn rated power, Ps apparent power, Pm current power, Pmax maximum power, power difference (\triangle P).

No.	Parameter s	Explanation
13	Hysteretic Power Recovery Slope	For over-frequency load reduction and frequency reduction, when the frequency is less than the hysteresis point, the power change slope when the power is restored.
Unde	rfrequency Lo	ading
1	P(F) Curve	Enable P(F) Curve when it is required by local grid standards and requirements.
2	Underfrequ ency Load Mode	 Set the underfrequency unloading mode based on actual needs. Slope mode: adjusts power based on the underfrequency point and load increase slope. Stop mode: adjusts the power based on the underfrequency start point and underfrequency end point.
3	Underfrequ ency Threshold	The inverter output active power will increase when the utility grid frequency is too low. The inverter output power will increase when the utility grid frequency is lower than Underfrequency Threshold .
4	Import/Exp ort Electricity Conversion Frequency	When the set frequency value is reached, the system switches from selling electricity to buying electricity.
5	Underfrequ ency Endpoint	The inverter output active power will increase when the utility grid frequency is too low. The inverter output power will stop increasing when the utility grid frequency is lower than Underfrequency Endpoint .

No.	Parameter s	Explanation
6	Over- Frequency Power Slope Reference Power	Adjust the inverter output power based on Apparent Active Power, Rated Active Power, Momentary Active Power, Or Max. Active Power.
7	Under- Frequency Power Slope	The inverter output active power will increase when the utility grid frequency is too low. The slope of the inverter output power when it rises.
8	Tentional Delay Ta	Indicates the delayed response time when the inverter output power is lower than the Underfrequency Threshold .
9	Hysteretic Function	Enable the hysteretic function.
10	Frequency Hysteresis Point	During underfrequency loading, if the frequency increases, the power is output according to the lowest point of the loaded power until the frequency is higher than the hysteresis point and the power is restored.
11	Hysteresis Waiting Time	For underfrequency loading, the frequency increases, when the frequency is higher than the hysteresis point, the waiting time for power recovery, that is, it takes a certain amount of time to recover the power.
12	Hysteresis Power Recovery Slope Reference Power	For underfrequency loading, the frequency increases, when the frequency is higher than the hysteresis point, the benchmark for power recovery, that is, the power recovery is carried out according to the recovery slope * the rate of change of the benchmark power. Support: Pn rated power, Ps apparent power, Pm current power, Pmax maximum power, power difference (\triangle P).

No.	Parameter s	Explanation
13	Hysteretic Power Recovery Slope	For under-frequency loading, frequency increase, when the frequency is higher than the hysteresis point, the power change slope when power is restored.
14	P(U) Curve	Enable P(U) Curve when it is required by local grid standards and requirements.
15	Vn Voltage	The percentage of actual voltage to the rated voltage at Vn point, n= 1, 2, 3, 4. For example, setting Vn Voltage to 90 means V/Vrated%=90%.
16	Vn Active Power	The percentage of the output active power to the apparent power at Vn point, (n= 1, 2, 3, 4). For example, setting Vn Reactive Power to 48.5 means P/Prated%=48.5%.
17	Output Response Mode	Set the active power output response mode. Supports: • PT-1 Behavior, realize active scheduling based on the first- order LPF curve within the response time constant. • Gradient Control, realize active scheduling based on the power change slope.
18	Power Gradient	When the output response mode is set to Gradient Control, active power scheduling is achieved according to the power change gradient.
19	First-order Low-pass Filter Time Parameter	Set the time constant within which the active power changes based on the first order LPF curve when the Output Response Mode is set to be First-order Low-pass Filter Time Parameter.
20	Overload Function Switch	When enabled, the maximum active power output is 1.1 times the rated power; otherwise, the maximum active power output is consistent with the rated power value.

9.3.8.7.3 Setting Protection Parameters

Step 1 : Tap Home > Settings > Advanced Settings > Safety Parameter Settings >

Protection Parameters to set the parameters.


Step 2: Set the parameters based on actual needs.

No.	Parameters	Description
1	OV Stage n Trip Value	Set the grid overvoltage protection threshold value, n=1,2,3,4.
2	OV Stage n Trip Time	Set the grid overvoltage protection tripping time, n=1,2,3,4.
3	UV Stage n Trip Value	Set the grid undervoltage protection threshold value, n=1,2,3,4.
4	UV Stage n Trip Time	Set the grid undervoltage protection tripping time.
5	10min Overvoltage Trip Threshold	Set the 10min overvoltage protection threshold value.
6	10min Overvoltage Trip Time	Set the 10min overvoltage protection tripping time.
7	OF Stage n Trip Value	Set the grid overfrequency triggering n-th order protection point, n=1,2,3,4.
8	OF Stage n Trip Time	Set the grid overfrequency trigger n-th order trip time, n=1,2,3,4.
9	UF Stage n Trip Value	Set the grid underfrequency triggering n-th order protection point, n=1,2,3,4.
10	UF Stage n Trip Time	Set the grid underfrequency trigger n-th order trip time, n=1,2,3,4.

9.3.8.7.4 Setting Connection Parameters

Step 1 : Tap Home > Settings > Advanced Settings > Safety Parameter Settings > Protection Parameters to set the parameters.

Step 2: Set the parameters based on actual needs.



No.	Parameters	Description	
Ramp	Ramp Up		
1	Upper Voltage	The inverter cannot connect to the grid if it is powered on for the first connection and the grid voltage is higher than the Upper Voltage .	
2	Lower Voltage	The inverter cannot connect to the grid if it is powered on for the first connection and the grid voltage is lower than the Lower Voltage .	
3	Upper Frequency	The inverter cannot connect to the grid if it is powered on for the first connection and the grid frequency is higher than the Upper Frequency .	
4	Lower Frequency	The inverter cannot connect to the grid if it is powered on for the first connection and the grid frequency is lower than the Lower Frequency .	
5	Observation Time	The waiting time for connecting the inverter to the grid when meeting the following requirements. 1. The inverter is powered on for the first connection. 2. The utility grid voltage and frequency meet certain requirements.	
6	Soft Ramp Up Gradient	Enable the start up power slope.	
7	Soft Ramp Up Gradient	Indicates the percentage of incremental output power per minute based on the local requirements when the inverter is powered on for the first time.	
Recon	Reconnection		

No.	Parameters	Description
8	Upper Voltage	The inverter cannot connect to the grid if it is reconnecting due to a fault and the grid voltage is higher than the Upper Voltage .
9	Lower Voltage	The inverter cannot connect to the grid if it is reconnecting due to a fault and the grid voltage is lower than the Lower Voltage .
10	Upper Frequency	The inverter cannot connect to the grid if it is reconnecting due to a fault and the grid frequency is higher than the Upper Frequency .
11	Lower Frequency	The inverter cannot connect to the grid if it is reconnecting due to a fault and the grid frequency is lower than the Lower Frequency .
12	Observation Time	The waiting time for connecting the inverter to the grid when meeting the following requirements. 1. The inverter is reconnecting to the grid due to a fault. 2. The utility grid voltage and frequency meet certain requirements.
13	Reconnection Gradient	Enable the start up power slope.
14	Reconnection Gradient	Indicates the percentage of incremental output power per minute based on the local requirements when the inverter is powered on for the first time. For example, setting Reconnection Gradient to 10 means the reconnect slope is 10%P/Srated/min.

9.3.8.7.5 Setting Voltage Ride Through Parameters

Step 1 : Tap Home > Settings > Advanced Settings > Safety Parameter Settings > Voltage Ride Through to set the parameters.

Step 2: Set the parameters based on actual needs.

No.	Parameters	Description	
LVRT			
1	UVn Voltage	The ratio of the ride through voltage to the rated voltage at UVn point during LVRT. n=1,2,3,4,5,6,7。	
2	UVn Time	The ride through time at UVn point during LVRT. n=1,2,3,4,5,6,7	
3	Enter Into LVRT Threshold	The inverter will not be disconnected from the utility grid immediately when the grid voltage is between Enter Into	
4	Exit LVRT Endpoint	LVRT Threshold and Exit LVRT Endpoint.	
5	Slope K2	K-factor for reactive power during LVRT.	
6	Zero Current Mode	The system outputs zero current during LVRT.	
7	Entry Threshold	Set the entry threshold of zero current mode.	
HVRT	HVRT		
1	OVn Voltage	The ratio of the ride through voltage to the rated voltage at OVn point during HVRT. n=1,2,3,4,5,6,7。	
2	OVn Time	The ride through time at OVn point during HVRT. n=1,2,3,4,5,6,7。	
3	Enter High Crossing Threshold	The inverter will not be disconnected from the utility grid	
4	Exit High Crossing Threshold	immediately when the grid voltage is between Enter High Crossing Threshold and Exit High Crossing Threshold.	
5	Slope K2	K-factor for reactive power during HVRT.	

No.	Parameters	Description
6	Zero Current Mode	The system outputs zero current during HVRT.
7	Entry Threshold	Set the entry threshold of zero current mode.

9.3.8.7.6 Setting Frequency Ride Through Parameters

Step 1 : Tap Home > Settings > Advanced Settings > Safety Parameter Settings > Frequency Ride Through to set the parameters.

Step 2: Set the parameters based on actual needs.


No.	Parameters	Description
1	UFn Frequency	The frequency at the UFn point during frequency ride through.
2	UFn Frequency	The frequency at the UFn point during frequency ride through. n=1,2,3。
3	UFn Time	The ride through duration at the UFn point during frequency ride through. n=1,2,3。
4	OFn Frequency	The frequency at the OFn point during frequency ride through. n=1,2,3。
5	OFn Time	The ride through duration at the OFn point during frequency ride through. n=1,2,3。

9.3.8.8 Setting PV Connect Mode

Select the PV connect mode based on the actual connections between the PV strings and MPPT ports of the inverter.

Step 1: Tap **Home > Settings > Advanced Settings > PV Connect Mode** to set the parameters.

Step 2: Set the connect mode to Independent Access, Partial Parallel Connect or Parallel Connection based on actual connections.




No.	Parameters	Description
1	Stand-alone Connect	The external PV string is connected to multi MPPT terminals of the inverter.
2	Partial Parallel Connect	The PV strings are connected to the inverter in both stand-alone and parallel connection. For example, one PV string connect to MPPT1 ad MPPT2, another PV string connect to MPPT3.
3	Parallel Connect	When an external PV string is connected to the PV input port on the inverter side, one PV string is connected to multiple PV input ports.

9.3.8.9 Setting the Unbalanced Voltage Output

- **Step 1**: Tap **Home > Settings > Advanced Settings > Unbalanced Voltage Output** to se the parameters.
- **Step 2**: Enable or disable the function based on actual needs.

Step 3: After enabling the Unbalance Voltage Function, set parameters based on actual needs. And tap 'V'. The parameters are set successfully.



9.3.8.10 Restore Factory Settings

To restore the device to its factory default settings, perform the following steps.

Step 1: Go to the settings page by selecting **Home > Settings > Advanced Settings > Restore Factory Settings**.

Step 2: Tap **Restore Factory Settings** to restore the interface prompt section to factory settings.



SLG00CON0122


9.3.8.11 Exporting Parameters

9.3.8.11.1 Exporting Safety Parameters

After selecting the safety code, some models support exporting safety parameter files.


Step 1: Tap **Home > Settings > Advanced Settings > Export** to export the parameters.

Step 2: Select Safety Parameters, and tap **Export** to start downloading the current safety parameter file. When the export is complete, tap **Share** and choose how you want to open the exported file.



9.3.8.11.2 Exporting Log Parameters

- **Step 1**: Tap **Home > Settings > Advanced Settings > Export**.
- **Step 2**: Select the device type to export logs, such as inverter logs, communication module logs, etc.
- **Step 3**: Select the log type to export, download and export the log file. After the export is complete, tap **Share** and choose how to open the exported file according to actual needs.



9.3.9 Enable Battery function


NOTICE

When the photovoltaic storage system is a parallel system:

- If connected via RS485 parallel operation, it supports selecting whether to synchronize the master/slave Battery settings in the "Battery Function" interface.
- If parallel operation is performed through other methods, the master-slave Battery settings will be automatically synchronized. To modify the slave Battery settings, please enter the configuration interface separately via the slave SN on the homepage.

9.3.9.1 Set Parameters for Lithium Battery

- **Step 1**: Tap **Home > Settings> Advanced Settings > Battery Function Settings** to set the parameters.
- **Step 2**: Set the parameters based on actual needs.



No.	Parameter	Description			
Parame	Parameter Settings				
1	Max. Charging Current	Only applicable to certain models. Set the maximum charging current based on actual needs.			
2	Max. Discharging Current	Only applicable to certain models. Set the maximum discharging current based on actual needs.			

No.	Parameter	Description
No.	Parameter Battery Heating	Optional. This option is displayed on the interface when a battery that supports heating is connected. After the battery heating function is turned on, when the temperature is below the value that starts up the battery, PV power or electricity from the grid will be used to heat the battery. Heating Mode: GW5.1-BAT-D-G20/GW8.3-BAT-D-G20 Low Power Mode: Maintains minimum battery power input capacity, turns on when the temperature is below -9°C, and turns off when the temperature is above or equal to -7°C. Medium Power Mode: to maintain the moderate power input capacity of the battery. It will be turned on when the temperature is less than 6°C, and turned off when it is greater than or equal to 8°C. High Power Mode: to maintain the higher power input capacity of the battery. It will be turned on when the temperature is less than 11°C, and turned off when it is greater than or equal to 13°C. GW14.3-BAT-LV-G10 Low Power Mode: Maintains minimum battery
		power input capacity, turns on when the temperature is below 5°C, and turns off when the temperature is above or equal to 7°C. Medium Power Mode: to maintain the moderate power input capacity of the battery. It will be turned on when the temperature is less than 10°C, and turned off when it is greater than or equal to 12°C. High Power Mode: to maintain the higher power input capacity of the battery. It will be turned on when the temperature is less than 20°C, and turned off when it is greater than or equal to 22°C.


No.	Parameter	Description
4	Battery Wake-up	 After being turned on, the battery can be awakened when it shuts down due to undervoltage protection. Only applicable to lithium batteries without circuit breakers. After being turned on, the output voltage of the battery port is about 60V.
Limit P	rotection	
5	SOC Protection	Start battery protection when the battery capacity is lower than the Depth of Discharge.
6	SOC Limit	The upper limit value for battery charging. Charging stops when the battery SOC reaches the SOC upper limit.
7	Discharge Depth (On-grid)	The maximum discharge value allowed for the battery when the inverter is in the on-grid scenario.
8	Backup Power SOC Maintenance	To ensure that the battery SOC is sufficient to maintain normal operation when the system is off-grid, the battery will purchase electricity from the grid and charge to the set SOC protection value when the system is connected to the grid.
9	Discharge Depth (Off-grid)	The maximum discharge value allowed for the battery when the inverter is in the off-grid scenario.
10	Off-grid SOC Recovery	When the inverter is operating off-grid, if the battery SOC drops below the lower limit, the inverter stops outputting power and only charges the battery until the battery SOC returns to the off-grid recovery SOC value. If the SOC lower limit value is higher than the off-grid recovery SOC value, charge to SOC lower limit +10%.
Immed	iate Charging	
11	Immediate Charging	Enable to charge the battery by the grid immediately. This takes effect once. Enable or Disable based on actual needs.

No.	Parameter	Description
12	SOC for Stopping Charging	Stop charging the battery once the battery SOC reaches SOC For Stopping Charging.
13	Immediate Charging Power	Indicates the percentage of the charging power to the inverter rated power when enabling Immediate Charging. For example, for an inverter with a rated power of 10kW, when set to 60, the charging power is 6kW.
14	Start	Start charging immediately.
15	Stop	Immediately stop the current charging task.

9.3.9.2 Setting Lead-acid Battery Parameter

Step 1: Tap **Home > Settings> Advanced Settings > Battery Function Settings** to set the parameters.

Step 2: Set the parameters based on actual needs.




Equalization Cycle

Number of days interval starting uniform charging


Range[0,365]DAY

90 90









No.	Parameter	Description
1	Nominal Capacity	Set the battery capacity according to the actual parameters.
2	Battery Internal Resistance	Set the battery internal resistance according to the actual parameters.
3	Temperature Compensation	When the battery temperature changes, the battery charging voltage will be affected. Based on 25°C, the charging voltage upper limit is adjusted according to the set value for every degree change in battery temperature. For example, if the charging temperature influence coefficient is set to 10, when the battery temperature rises to 26 degrees, the charging voltage upper limit decreases by 10 mV.
4	Lower Discharge Voltage	Set the minimum voltage during battery discharge according to actual requirements.
5	Max. Discharging Current	Set the maximum discharging current based on actual needs.
6	Max. Charging Current	Set the maximum charging current based on actual needs.
7	Constant Charging Voltage	Set the voltage value for constant charging of the battery according to actual requirements.
8	Floating Voltage	Set the voltage value for battery float charging according to actual requirements.
9	Maximum Current When Switching to Floating Charge	The maximum charging current after switching the battery charging mode from constant charging/equal charging to float charging.

No.	Parameter	Description	
10	Time to Switch to Float Charging Mode	The time required to switch the battery charging mode from constant charging/equal charging to float charging.	
11	Equalization Charging Cycle	Set the interval days for battery equalization charging.	
Restri	ction protection.		
12	SOC Protection	Start battery protection when the battery capacity is lower than the Depth of Discharge.	
13	SOC Lower Limit (Grid Connection)	The minimum battery charge that must be maintained when the inverter is connected to the grid.	
14	Backup Power SOC Maintenance	To ensure that the battery SOC is sufficient to maintain normal operation when the system is off-grid, the battery will purchase electricity from the grid and charge to the set SOC protection value when the system is connected to the grid.	
15	SOC Lower Limit (Off-Grid)	The minimum battery charge that must be maintained when the inverter is operating off-grid.	
16	Off-grid SOC Recovery	When the inverter is operating off-grid, if the battery SOC drops below the lower limit, the inverter stops outputting power and only charges the battery until the battery SOC returns to the off-grid recovery SOC value. If the SOC lower limit value is higher than the off-grid recovery SOC value, charge to SOC lower limit +10%.	
Imme	Immediate Charging		
17	SOC for Stopping Charging	Stop charging the battery once the battery SOC reaches SOC For Stopping Charging.	

No.	Parameter	Description
18	Immediate Charging Power	Indicates the percentage of the charging power to the inverter rated power when enabling Immediate Charging. For example, for an inverter with a rated power of 10kW, when set to 60, the charging power is 6kW.
19	Start	Start charging immediately.
20	Stop	Immediately stop the current charging task.


9.3.10 Setting the Meter Parameters

9.3.10.1 Meter/CT-Assisted Test

Meter/CT-Assisted Test is used to auto-check if the Smart Meter and CT are connected in the right way and their working status.

Step 1: Tap **Home > Settings > Meter/CT Assisted Test** to set the function.

Step 2: Tap **Start Test** to start test. Check Test Result after test.



9.3.11 Setting Generator/Load Control

9.3.11.1 Setting Load Control


NOTICE

- Loads and generators can be controlled by SolarGo app when the inverter supports load control function.
- For ET40-50kW series inverters, the load control function is supported only when the inverter is used with STS. The inverter supports load control of the GENERATOR port or the BACKUP LOAD port.


Step 1: Tap **Home > Settings > Port Connection** to set the parameters.

Step 2: Select **Generator Control** or **Load Control** based on actual needs.

• Dry Contact Mode: when the switch is ON, the loads will be powered; when the switch is OFF, the power will be cut off. Turn on or off the switch based on actual needs.



• Time Mode: set the time to enable the load, and the load will be powered automatically within the setting time period. Select standard mode or intelligent mode.



No.	Parameters	Description
1	Standard	The loads will be powered within the setting time period.
2	Intelligent	Once the excess energy of the photovoltaic exceeds the load nominal power within the time period, the loads will be powered.
3	Start Time	The time mode will be on between the Start Time and
4	End Time	End Time.
5	Repeat	The repeat days.
6	Load Consumption Time	The shortest load working time after the loads been powered. The time is set to prevent the loads be turned on and off frequently when the PV power fluctuates greatly. Only for Intelligent mode.
7	Load Rated Power	The loads will be powered when the excess energy of the photovoltaic exceeds the nominal power of load. Only for Intelligent mode.

• SOC Mode: the inverter has integrated dry contact controlling port, which can control whether the load is powered or not by contactor. In off-grid mode, the load connected to the port will not be powered if the BACKUP overload is detected or

the battery SOC value is lower than the Off-grid battery protection value. Set Off-grid Battery Protection Value based on actual needs.




9.3.11.2 Setting the Generator Parameters

NOTICE

- When the inverter supports the generator control function, the generator can be controlled through the SolarGo App.
- For ET40-50kW series inverters, the generator can be connected and controlled only when the inverter is used with STS.
- **Step 1**: Tap **Home > Settings > Port Connection** to set the parameters.
- **Step 2**: Select Generator Connection or Load Connection based on actual needs.
- **Step 3**: When setting the generator control function, select the generator type according to the actual access situation. Currently supported:**Not Installed, Manual Control Of Generator** or **Automatic Control Generator**. And set the parameters according to the selected generator type.
- Not Installed: If no generator is connected in the system, select Not Installed.
- Manual Control Of Generator(Doesn't Support Dry Node Connection): Start or stop the generator manually. The inverter cannot control the generator when Manual Control Of Generator(Doesn't Support Dry Node Connection) is selected.

- Automatic control generator (Supports dry node connection): If the generator has dry contact port and is connected to the inverter, set the generator control mode to Switch Control Mode or Automatic Control Mode based on actual needs.
 - Switch Control Mode: The generator will start working when the Generator Dry Node Switch is on, and stop automatically after reaching Run Time.
 - Automatic Control Mode: The generator will work during Run Time, but stop working during Prohibited Working Hours.



No.	Parameters	Description
1	Startup Mode	Switch Control Mode/Automatic Control Mode
Switch Control Mode		

No.	Parameters	Description
2	Generator Dry Node Switch	Only for Switch Control Mode.
3	Run Time	Set the generator's continuous runtime, after which the generator will be turned off.
Auton	Automatic Control Mode	
4	Prohibited Working Hours	Set the time period during which the generator cannot work.
5	Run Time	Set the generator's continuous runtime, after which the generator will be turned off. If the generator start-up operation time includes prohibited working time, the generator will stop running during this time period; after the prohibited working time, the generator will restart running and timing.

No.	Parameters	Description	
Gener	ator Information Set	ttings	
1	Rated Power	Set the rated power of the generator.	
2	Run Time	Set the continuous running time of the generator. The generator will be shut down after the continuous running time ends.	
3	Upper Voltage	Set the operation voltage range of the generator.	
4	Lower Voltage		
5	Frequency Cap	Cat the operation frequency range of the generator	
6	Lower Frequency	Set the operation frequency range of the generator.	
7	Preheating time	Set the generator no-load preheating time.	
Param	Parameter settings for generator charging batteries		
8	Switch	Select whether to use the generator to generate electricity to charge the battery.	

No.	Parameters	Description
9	Max.charging power (‰)	The charging power when the generator generates electricity to charge the battery.
10	Start charging SOC	When the battery SOC is lower than this value, the generator generates electricity to charge the battery.
11	Stop charging SOC	When the battery SOC is higher than this value, stop charging the battery.

9.3.11.3 Setting Microgrid Parameters

NOTICE

When the inverter supports microgrid function, you can set microgrid parameters through SolarGo App.

Step 1: Tap **Home > Settings > Port Connection** to set the parameters.

Step 2: According to the actual interface prompts, enter the microgrid control interface and set the microgrid parameters according to actual needs.



SLG00CON0078

No.	Parameters	Description
1	Maximum SOC for Charging	Set the upper limit of charging SOC, and stop charging when the upper limit is reached.
2	Manual wake-up	 When the grid fails, if the battery power is low, the energy storage inverter cannot be supported to work off the grid. Click this button to force the energy storage inverter to output voltage to the grid-connected inverter, thereby starting the grid-connected inverter. Single effect.

No.	Parameters	Description
3	Automatic wake- up	 When the grid fails, if the battery power is low, the energy storage inverter cannot be supported to work off the grid. After enabling this function, the system will force the energy storage inverter to output voltage to the grid-connected inverter at a fixed time, thereby starting the grid-connected inverter. Multiple effect.
4	Grid Import Power Limit Offset	Set the adjustable range of the maximum power that the device can actually buy from the grid.

9.3.12 Equipment Maintenance

9.3.12.1 Checking Firmware Information/Upgrading Firmware Version

Upgrade the DSP version, ARM version, BMS version, AFCI version, or STS version of the inverter, or firmware version of the communication module. Some devices do not support upgrading the firmware version through SolarGo app.

NOTICE


If the Firmware Upgrade dialog box pops up once logging into the app, click Firmware Upgrade to directly go to the firmware information page.

9.3.12.1.1 Regular Upgrade

NOTICE

- When there is a red dot on the right side of the firmware information, please click to view the firmware update information.
- During the upgrade process, please ensure that the network is stable and the device is connected to SolarGo, otherwise the upgrade may fail.
- **Step 1**: Tap **Home > Settings > Firmware Information** to check the firmware version. If the firmware upgrade dialog box pops up, tap **Firmware Upgrade** and turn to the upgrade interface.
- **Step 2**: (Optional) Tap **Check For Update** to confirm whether the latest firmware version is available for updating.
- **Step 3**: Tap **Firmware Upgrade** to enter the firmware upgrade interface.
- **Step 4**: (Optional) Tap **Learn More** to view firmware-related information, such as the current version, the latest version, firmware update records, etc.


Step 5: Tap **Upgrade** and complete the upgrade according to the prompts on the interface.



9.3.12.1.2 One-click Upgrade

NOTICE

- When there is a red dot on the right side of the firmware information, please click to view the firmware update information.
- During the upgrade process, please ensure that the network is stable and the device is connected to SolarGo, otherwise the upgrade may fail.
- **Step 1**: Tap **Home > Settings > Firmware Information**. Tap **Firmware Information** as prompted to enter the firmware upgrade page.
- **Step 2**: Tap **Upgrade** and follow the prompts to complete the upgrading. If you only need to upgrade a specific firmware version, tap **Learn More** to check the firmware related information and tap **Firmware Upgrade** below the firmware version you want to upgrade, and follow the on-screen prompts to complete the operation.
- **Step 3**: Tap **Learn More** to view all current firmware version information.
- **Step 4**: (Optional)Tap ,to view the version upgrade record.



9.3.12.1.3 Automatic Upgrade

NOTICE

- When using WiFi/LAN Kit-20 or WiFi Kit-20 module communication and the module firmware version is V2.0.1 or above, the device automatic upgrade function can be enabled.
- After the device automatic upgrade function is enabled, if the module version is updated and the device has been connected to the network, the corresponding firmware version can be automatically upgraded.
- **Step 1**: Tap **Home > Settings > Firmware Information**.
- **Step 2**: Enable or disable the automatic device upgrade function according to actual needs.
- **9.3.12.1.4** Checking Firmware Information
- Step 1: Tap **Parameters > Firmware Version** to check the version information.




SLG00CON0191

9.3.12.2 Change the Login Password

NOTICE

The login password can be changed. Keep the changed password in mind after changing it. Contact the after-sales service if you forget the password.

- **Step 1**: Tap **Home > Settings > Change Login Password** to change the password.
- **Step 2**: Change the password based on actual needs.



SLG00CON0088

10 Station Monitoring

NOTICE

The parameters may vary depending on the account type or power station type. The actual interface takes precedence.

10.1 Product Introduction

SEMS+ App is a monitoring platform to manage power plants and devices, and check the operating data and alarming information of the power plant.

10.1.1 Applicable Product Model

SEMS+ App can be used to monitor and manage GoodWe products, such as inverters, smart meters, smart loggers, chargers, batteries and so on.

10.1.2 Downloading and Installing the App

Make sure that the mobile phone meets the following requirements:

- Operating system: Android 6.0 or later, iOS 13.0 or later.
- · Internet connection via browser.
- · WLAN/Bluetooth capabilities.

Download Methods:

Method I

Search SEMS+ on Google Play (Android) or App Store (iOS) to download and install the App.




SEMS0001

Method II

Scan the QR code below to download and install the App.



10.1.3 App Connection





10.1.4 Setting Language and Server


NOTICE

The server is automatically matched based on login account information. To set it manually, ensure that the selected region matches the region of the account. Otherwise, login may fail.

Select the language and the server based on the actual situation.








10.2 Managing the Account

10.2.1 Registering an Account

- **Step 1:** Tap **Register** to enter the account registration interface.
- **Step 2:** Select the account type based on your actual needs and tap **Next**.
- **Step 3:** Enter your account information based on the actual situation and tap **Register** to complete the registration.



10.2.2 Logging in to the App

NOTICE

- Register an account or obtain an account from your dealer before logging in.
- Check and manage power station after logging in. The actual interface takes precedence.


Step 1: Enter the username and password, read, and agree to the login agreement. Tap **Log In**.



10.2.3 Switching Accounts

Step 1: Go to **My** tab, and tap **Log Out > Log with Another Account**.

Step 2: Select an already added account or add a new account based on actual needs.




10.2.4 Deleting an Account


Step 1: Go to My tab and tap Account&Security.

Step 2: Tap Close Account, input the account password, and Submit.

SEMS0008







10.2.5 Account Permission Descriptions

The SEMS+ App supports various types of accounts with different permissions. Refer to the table below for details.

Primary menu	Submenu	Third-Level Menu	Fourth-Level Menu	Fifth-Level Menu	Permissions
Login & Register	-	-	-	-	Administrator, Technician, Browser, End User, Visitor
	Monitoring Information	-	-	-	Administrator, Technician, Browser, End User, Visitor
Overview	Create Station	-	-	-	Administrator, Technician, End User and Visitor

Station					Administrator,
	Station List	-	-	-	Technician, Browser,
					End User, Visitor
					Administrator,
		Monitoring	-	-	Technician, Browser,
					End User, Visitor
					Administrator,
			Add Device	-	Technician, End User
					Administrator,
				Search	Technician, Browser,
				Device	End User, Visitor
				Replace	Administrator,
			Device List	Device	Technician, End User
					Administrator,
				Edit Device	Technician, End User
		Device		Delete	Administrator,
				Device	Technician, End User
			Device Details	Device	Administrator,
	Station Details			Monitoring	Technician, Browser,
				Info	End User, Visitor
				Device Remote Control Administrator Technician, Er	Advairiatestas
					recriffician, End Oser
				Device	Administrator,
				Remote	Technician
				Upgrade	recrimetari
					Administrator,
		Alarms	-	-	Technician, Browser,
					End User, Visitor
		Station Configuratio	Edit Station	_	Administrator,
			Luit Station	-	Technician, End User
			Delete	_	Administrator,
			Station		Technician, End User

			History		Technician, Browser,
					End User
			User	_	Administrator,
			Information		Technician, End User
			Home		Administrator,
			Configuratio	-	Technician, Browser,
			n		End User, Visitor
					Administrator,
	Create Station	-	-	-	Technician, End User
					and Visitor
A.I					Administrator,
Alarm	-	-	-	-	Technician, Browser
					Administrator,
		Warranty	-	-	Technician, Browser,
					End User, Visitor
		Report	-	-	Administrator,
					Technician, Browser,
		Center			End User
		C = = = 1\A/=	-	-	Administrator,
	Services	GoodWe News			Technician, Browser,
					End User, Visitor
		A		-	Administrator,
6		Announceme	-		Technician, Browser,
Services		nts			End User, Visitor
				-	Administrator,
		Community	-		Technician, Browser,
					End User, Visitor
		Crooks			Administrator,
		Create	-	-	Technician, End User
		Station			and Visitor
	Tools				Administrator,
		Network Link	-	-	Technician, Browser,
					End User, Visitor
		DNSP			Administrator,

					Technician, Browser,
					End User, Visitor
					Administrator,
	Help	-	-	-	Technician, Browser,
					End User, Visitor
					Administrator,
	User Profile	-	-	-	Technician, Browser,
					End User, Visitor
	User				Administrator,
	Information	-	-	-	Technician, Browser,
	Information				End User, Visitor
					Administrator,
	Setting	-	-	-	Technician, Browser,
					End User, Visitor
					Administrator,
		Email	-	-	Technician, Browser,
					End User, Visitor
		Password	-	-	Administrator,
					Technician, Browser,
Му	Account				End User, Visitor
	Security	Secondary			Administrator,
		Account	-	-	Technician, Browser
					Administrator,
		Close	-	_	Technician, Browser,
		Account			End User, Visitor
					Administrator,
		Remote	_	-	Technician, Browser,
	Auth	Control Auth			End User, Visitor
	Management	Monitoring			
		Auth	-	-	End User
					Administrator,
	Apps	_	_	-	Technician, Browser,
					End User, Visitor
	About	-	_	-	Administrator,

					Technician, Browser,
					End User, Visitor
					Administrator,
	Logout Login anther Account	Logout	-	-	Technician, Browser,
					End User, Visitor
		l a sin anthau			Administrator,
		-	-	Technician, Browser,	
		Account			End User, Visitor

10.3 Setting the Network Information

The SEMS+ App allows connecting devices via Bluetooth or WiFi and configuring network parameters to realize remote monitoring or management.

NOTICE

The device name varies depending on the inverter model or smart dongle model.

- Wi-Fi/LAN Kit, Wi-Fi Kit, Wi-Fi Box: Solar-WiFi***
- WiFi/LAN Kit-20: WLA-***
- WiFi Kit-20: WFA-***
- Ezlink3000: CCM-BLE***, CCM-***, ***
- 4G Kit-CN-G20/4G Kit-CN-G21: GSA-***; GSB-***
- AC Charger:***

10.3.1 Connecting via Bluetooth


NOTICE

- Before connecting, ensure: Your phone's Bluetooth is enabled. The device is powered on and communicating properly.
- The App interface and parameters may vary depending the device type or smart dongle model. The actual interface takes precedence.

Step 1: Open the app and select **Network Link** on the homepage or in the **Service** interface.

Step 2: Tap **Bluetooth** and select the device by the serial number.

- **Step 3**: If prompted, log into the App according to your role and enter the password. Default password: 1234. If no login prompt appears, you will directly enter the communication settings interface.
- **Step 4**: (Optional) Enable **Bluetooth Stays ON** if required. Otherwise, the Bluetooth signal will turn off after the connection.
- **Step 5**: Set the **WLAN** or **LAN** parameters based on actual situation. Tap **Save** to complete the settings. Tap **WLAN Detetion** to check the communication status.
- **Step 6**: (Optional) Tap **Login Password Change** to input a new password, and **Save.**




No.	Parameters	Description	
Privac	Privacy&Security		
1	Bluetooth Stays ON	Enable the function, the bluetooth of the device will be contentious on to keep connected to SEMS+. Otherwise, the bluetooth will be off in 5 minutes.	
WLAN	/LAN		
2	WLAN	Enable or disable WLAN.	
3	Name		
4	Encryption Method	Select the name of the router network to be used.	
5	Password		
6	DHCP Automatic Obtain	Enable DHCP when the router is in dynamic IP mode. Disable DHCP when a switch is used or the router is in static IP mode.	
7	IP Address		
8	Subnet Mask	Do not configure the parameters when DHCP is enabled.	
9	Gateway Address	Configure the parameters according to the router or switch information when DHCP is disabled.	
10	DNS Server		

10.3.2 Connecting via WiFi

NOTICE

- Before connecting, ensure: Your phone's Bluetooth is enabled. The device is powered on and communicating properly.
- The App interface and parameters may vary depending the device type or smart dongle model. The actual interface takes precedence.
- **Step 1**: Open the WiFi setting on the phone and connect to the inverter's WiFi signal (Solar-WiFi***). Default password: 12345678
- **Step 2:** Open the app and select **Network Link** on the homepage or in the **Service** interface.
- **Step 3**: Tap **WLAN** and select the device by the serial number.
- **Step 4**: Modify the WiFi hotspot password if needed. If changed, reconnect to the inverter's WiFi signal using the new password.
- **Step 5**: Set the **WLAN** or **LAN** parameters based on actual situation. Tap **Save** to complete the settings. Tap **WLAN Detetion** to check the communication status.



No.	Parameters	Description		
Priva	Privacy&Security			
1	Login Password Change	Modify the WiFi hotspot password if needed. If changed, reconnect to the inverter's WiFi signal using the new password.		
WLAN	WLAN/LAN			
2	Internet Access Port	Set the communication mode as Wi-Fi or LAN based on actual needs.		

No.	Parameters	Description
3	Name	Select the name of the router network to be used.
4	Encryption	
	Method	
5	Password	
	DHCP	Enable DHCP when the router is in dynamic IP mode.
6	Automatic	Disable DHCP when a switch is used or the router is in
	Obtain	static IP mode.
7	IP Address	
8	Subnet Mask	Do not configure the parameters when DHCP is enabled.
9	Gateway	Configure the parameters according to the router or
9	Address	switch information when DHCP is disabled.
10	DNS Server	

10.4 Station Monitoring

NOTICE


The parameters may vary depending on the account type or power station type. The actual interface takes precedence.

10.4.1 Checking Station Information

10.4.1.1 Checking Overview Information of All Stations

After logging in, you can view an overview of all stations linked to your account from the homepage.

Or sort the list of all power stations through different sorting and filtering conditions on the power station page to view the detailed information of the power stations.



No.	Description
1	Displays the overall generation information of all stations, including: Generation Today, Generation This Month, Generation This Year, and Generation Lifetime. Generation This Year will not be displayed if the station amount exceeds 10.
2	Displays the total installed capacity and the working status of the stations. Working status: Running, Waiting, Offline, and Faulted. The stations status is running only when all the devices of the station are working properly.
3	Displays statistical chart of Generation Today, This Year, and Lifetime.Or displays comparison chart comparing current and past generation. Tap to expand the chart.
4	Displays environmental contributions like CO ₂ Reduction, Trees Stationed Equivalent, and Standard Coal Saved.
5	Creating a New Station

No.	Description
6	Searching Stations Enter the device SN, power station name or email address to quickly search for the corresponding power station.
7	Power station operation status. Display the current operation status of power stations and the number of power stations operating in each status. Tap the operation status to filter power stations in the corresponding operation status.
8	 Set KPI indicators displayed in the power station list: Current Power, Rev. Today, Rev. Total, Gen. Today, Gen. Total Set the sorting method of the power station list: By Default, By Capacity Set the display mode of the power station list: Station Card, Station List Set the filtering conditions for the power station list: Scope, Category, Capacity
9	Power station list. Tap the power station name to view the detailed information of the power station. The displayed content varies depending on the station type. The actual interface takes precedence

10.4.1.2 Checking Detailed Information of Single Station

Step 1: Enter the device SN, power station name or email address to quickly search for the corresponding power station.

Step 2: Tap the power station name to enter the power station details page.



10.4.1.2.1 Checking Detailed Information of Power Station (Traditional Mode)



No.	Description
1	The current name of the power station.
2	Favoriting a Station
3	Configuring Station Information. Supported functions: Configure basic information of the power station, modify user information, add power station photos, set PV module layout, etc.
4	Displays current power station operation information in chart form, such as energy flow diagrams, power generation, load power consumption, AC output, and other information.
5	 Device List Displays devices in the current power station, such as inverters, batteries, data collectors, charging piles, etc. Tap the device card to view detailed device information.
6	Alarm information.

10.4.1.3 Checking Alarm Information

10.4.1.3.1 Checking Alarm Information of All Power Stations

Step 1 Tap **Alarms** tab to enter the alarm page.

Step 2 (optional) Use the search bar to locate alarms by station name or device serial number.


Step 3 Select the alarm to view detailed information.



10.4.1.3.2 Checking Detailed Information of Current Power Station (Traditional Mode)

Step 1: If there are multiple power stations, tap the power station name to enter the power station details page.


Step 2: Tap **Alarms** to enter the alarm page to view alarm details. Tap ††† to filter alarm information based on actual needs.



10.4.1.3.3 Checking Alarm Information of Current Devices

Step 1: If there are multiple power stations, tap the power station name to enter the power station details page.

Step 2:Select a device from the device list and enter the device details page. If there are alarms, the device details page allows direct viewing of the 10 latest ongoing alarms.




10.4.1.4 Checking Station Reports

Viewing Reports

Step 1: Tap **Service > Report Center**.


Step 2: Select a time period, search for the desired station, and tap the station name to view the report center. Tap **Export** to download the report if needed.



Viewing Bills

Step 1: Tap Service > Report Center.


Step 2: Search for the desired station. Find the station, swipe left and tap it to view billing details of the month.



10.4.2 Managing Stations

10.4.2.1 Creating a Station

- **Step 1**: Tap on overview or station page, or tap **Create Station** on service page.
- **Step 2**: Enter station information on the **Creat Station** page.
- **Step 3**: Tap **Save&Exit** to complete creating a station, without devices added. Or tap **Save&Continue** to add devices. Support adding multiple devices.




10.4.2.2 Configuring Station Information

NOTICE

The configuration information of the station can be updated as needed. When the information filled in is inconsistent with the actual situation of the power station, the actual situation of the power station shall prevail.


- **Step 1**: (Optional) Select the station to be updated from the station list.
- **Step 2**: Tap ••• > **Basic Information** to check the basic information.
- **Step 3**: Tap ^(a) to modify the information, and tap Confirm **to save the changes.**



10.4.2.3 Managing Station Visitors

SEMS+ App allows users to add visitors to the power station and view basic information. Visitors have limited access and cannot view all information.

- **Step 1**: (Optional) Select the station to be updated from the station list.
- Step 2: Tap ••• > User Information > Add.
- **Step 3**: Input the visitor's information and tap **Confirm**.




To delete a visitor, go to the User Information page, select the visitor, and tap **Delete**.




10.4.2.4 Managing Station Photos

Adding photos to a station helps users find what they need faster.

- **Step 1**: (Optional) Select the station to be updated from the station list.
- **Step 2**: Tap ••• > **Station Photos** > **Add**.
- **Step 3**: Follow the prompts to add photos by **Take a Photo** or **Choose from Album**.




To delete a photo, follow the steps below.



10.4.2.5 Configuring the Page Information

Change what's shown on the station details page, such as showing, hiding, or repositioning the Energy Flow Chart.

- **Step 1**: (Optional) Select the station to be updated from the station list.
- **Step 2**: Tap ••• > **Home Configuration** on the station page.
- **Step 3**: Refer to the on-screen prompts to select the information content to be displayed, or adjust the display order of various information based on actual needs.



10.4.2.6 Set PV Module Layout


Set the PV Layout Design parameters based on the actual conditions of PV modules.

- **Step 1**: (Optional) Select the station to be updated from the station list.
- **Step 2:** Tap ••• > **PV Layout Design** to enter the interface.

Step 3: Tap Row/Column

,and set the arrangement of modules in each row and each column based on the actual installation of PV modules.

Step 4: Tap **Array Name** to enter the **Array Settings** interface, and set the name, angle, and orientation information of the PV array based on the actual situation. SEMS0056




10.4.2.7 Deleting a Station


NOTICE


For station visitors, deleting a station means unbinding it from their account.

Step 1:(Optional) If there are multiple power stations, tap he power station name to enter the power station details page.

- **Step 2:**Tap ••• on the station page.
- **Step 3:** Tap**Delete** and **Confirm** to delete the station.







10.4.2.8 Favoriting a Station

To favorite a station, tap the star icon next to the station name. Tap the icon again to unfavorite it.

Tap $\sqrt{}$ and Select Favorited in the filtering Scope to display all the favorited power stations.





10.4.3 Managing Devices

10.4.3.1 Adding a Device


NOTICE


- Supported device types may vary based on the station type.
- If the environmental monitor is connected to a smart logger, add the environmental monitor to the station and view the its data.
- **Step 1**: Select a station from the station list.
- **Step 2**: Tap **Device** $> \oplus$ to enter the device addition interface.
- **Step 3**:Select the type of device to add.
- **Step 4**: Follow the instructions to scan or manually input device information. To add the scanned devices, choose devices from the scanned device list. To manually add a device, scan the device SN code or input required device information. To add multiple devices, repeat the steps as needed.
- **Step 5**: When manually adding devices, if you need to add multiple devices, return to the power station details page and repeat steps 3 and 4.






Alarms








10.4.3.2 Editing Device Information

The device name can be modified.

Step 1:(Optional) If there are multiple power stations, tap he power station name to enter the power station details page.

Step 2:Tap **Device** to enter the device page. Select the device and swipe left, tap **Step 3:** Input new device name and tap **Submit**.




10.4.3.3 Deleting a Device

Step 1:(Optional) If there are multiple power stations, tap he power station name to enter the power station details page.


Step 2:Tap **Device** to enter the device page. Select the device and swipe left, tap <u>\bigsigs</u>.

Step 3:: Read the prompt and tap **OK** to delete the device.



10.4.3.4 Upgrade the Firmware

- **Step 1**: (Optional) Select the station to be updated from the station list.
- **Step 2:** Tap **Device** to open the device details page and select the device to be upgraded.
- **Step 3:** Tap the device serial number to enter the **Firmware Version** page. If the upgrade is available, tap **Upgrade** and follow the instructions. Tap \bigcirc to find the upgrade history.



10.4.4 Managing Device Remotely

NOTICE

- Set the device parameters via SEMS+ App after creating a plant and adding devices to it.
- Before setting any parameters, read through user manual of the App and the inverter or charger to learn the product functions and features.
 Incorrectly configured parameters, such as grid settings or start/stop commands, may result in devices failing to connect to the grid, potentially affecting power generation.
- λ Only trained professionals familiar with local regulations and electrical systems should perform parameter settings.
- Different account permissions allow for remote setting of different parameters. The interface will be displayed based on the actual account in use, and please refer to the actual interface.
- The setting page varies depending on accounts type and device model.


10.4.4.1 Configuring Hybrid Inverter Parameters


- **Step 1**: (Optional) Select the station to be updated from the station list.
- **Step 2:** Tap **Device** to enter the device page and choose the device to be configured.
- **Step 3**: Tap [™], read the prompts and set parameters as needed.

















No.	Parameters	Description	
1	Safety	Set the safety country in compliance with local grid standards and application scenario of the inverter.	
Battery	Battery		
2	Battery Model	Set the model of the connected battery.	
3	Depth of Discharge (On- Grid)	The maximum depth of discharge of the battery when the system is working on-grid.	

No.	Parameters	Description	
4	Depth of Discharge (Off- Grid)	The maximum depth of discharge of the battery when the system is working off-grid.	
5	Backup SOC Holding	The battery will be charged to preset SOC protection value by utility grid or PV when the system is running on-grid. So that the battery SOC is sufficient to maintain normal working when the system is off-grid.	
6	SOC Protection	Start battery protection when the battery capacity is lower than the Depth of Discharge.	

No.	Parameters	Description	
No. 7	Parameters Battery Heating	When a battery with heating function is connected, this option will be displayed on the interface. After enabling the battery heating function, when the battery temperature does not support battery startup, PV power generation or purchased electricity will be used to heat the battery. Heating modes: • GW5.1-BAT-D-G20/GW8.3-BAT-D-G20 Low-power mode: Maintain the minimum power input capability of the battery. It turns on when the temperature is below -9°C and turns off when the temperature is -7°C or higher. • Medium-power mode: Maintain moderate power input capability of the battery. It turns on when the temperature is below 6°C and turns off when the temperature is 8°C or higher. • High-power mode: Maintain high power input capability of the battery. It turns on when the temperature is below 11°C and turns off when the temperature is 13°C or higher. • GW14.3-BAT-LV-G10 • Low-power mode: Maintain the minimum power input capability of the battery. It turns on when the temperature is below 5°C and turns off when the temperature is below 5°C and turns off when the temperature is below 5°C and turns off when the temperature is 7°C or higher.	
		 Medium-power mode: Maintain moderate power input capability of the battery. It turns on when the temperature is below 10°C and turns off when the temperature is 12°C or higher. High-power mode: Maintain high power input capability of the battery. It turns on when the temperature is below 20°C and turns off when the temperature is 22°C or higher. 	
8	Daily Heating Period	Set the battery heating time period based on actual needs.	

No.	Parameters	Description
9	Battery Wake-up	After being enabled, the battery can be woken up when it shuts down due to undervoltage protection.
10	Battery Breathing Light	 Only applicable to the ESA 3-10kW inverter series. Set the blinking duration of the device's breathing light. Options available: Always on, Always off, 3min. The default mode is to stay on for three minutes after power-on and then turn off automatically.
Mode		
11	Working Mode	 Self-use mode: Back-up mode: The back-up mode is mainly applied to the scenario where the grid is unstable ¡When the grid is disconnected, the inverter turns to off-grid mode and the battery will supply power to the load; when the grid is restored, the inverter switches to on-grid mode. Eco mode: It is recommended to use economic mode in scenarios when the peak-valley electricity price varies a lot. Select Economic mode only when it meets the local laws and regulations. Set the battery to charge mode during Vally period to charge battery with grid power. And set the battery to discharge mode during Peak period to power the load with the battery. Smart charging: In some countries/regions, the PV power feed into the utility grid is limited. Select Smart Charging to charge the battery using the surplus power to minimize PV power waste. Peak shaving mode:Peak shaving mode is mainly applicable to peak power limited scenarios. When the total power consumption quota in a short period of time, battery discharge can be used to reduce the power exceeding the quota.

No.	Parameters	Description
12	On-Grid Power Limitation	Enable On-Grid Power Limitation when power limiting is required by local grid standards and requirements.
13	Maximum On- Grid Output Power	Set the value based on the actual maximum power feed into the utility grid.
14	Power Factor	Set the power factor based on actual needs.
15	Q(U)	Enable Q(U) Curve when it is required by local grid standards and requirements.
16	COS(φ)	Enable Cosφ Curve when it is required by local grid standards and requirements.
17	P(F)	Enable P(F) Curve when it is required by local grid standards and requirements.
Others	5	
18	Backup Supply	After enabling Backup Supply, the battery will power the load connected to the BACK-UP port of the inverter to ensure Uninterrupted Power Supply when the power grid fails.
19	Shadow Scan	Enable Shadow Scan when the PV panels are severely shadowed to optimize the power generation efficiency.

11 Maintenance

11.1 Power OFF the System


DANGER

- When performing operation and maintenance on equipment in the system, please ensure the Power OFF the System is properly handled. Operating live equipment may cause equipment damage or electric shock DANGER.
- After the equipment is POWER OFF, the internal components Discharge require a certain amount of time. Please wait until the equipment is fully Discharge according to the time specified on the label.
- Restarting Battery should be performed using the circuit breaker power on method.
- When closing Battery system, strictly adhere to the Battery system power off requirements to prevent damage to Battery system.
- When there are multiple Battery in the system, power off any one Battery can power off all Battery.

NOTICE

- The breaker between Inverter and Battery, as well as the breaker between Battery system, must be Installation in accordance with local laws and regulations.
- To ensure effective protection of the Battery system, the cover plate of the Battery system switch must remain closed, and the Protective cover should automatically close after being opened. If the Battery system switch is not in use for an extended period, it should be secured with the screw.

current project



- 1. Disconnect the BACK-UP breaker.
- 2. (Optional) Disconnect the GENbreaker.
- 3. Disconnect the Master inverterON-GRIDbreaker.
- 4. (Optional) Disconnect the Slave inverterON-GRIDbreaker circuit.

- 5. (Select according to local regulations) Disconnect the switch between Inverter and Battery.
- 6. Disconnect the Battery system switch.
 - LX A5.0-30: Disconnect the Battery system switch
 - LX U5.0-30, GW14.3-BAT-LV-G10: Close the Battery system integrated breaker or press and hold the Battery system button for ≥5 seconds, the Battery system integrated breaker will automatically disconnect.
- 7. Disconnect the DC switch of Inverter.

11.2 Removing the Equipment

!DANGER

- Make sure that the equipment is powered off.
- Wear proper PPE during operations.
- Please use standard disassembly tools when removing wiring terminals to avoid damaging the terminals or equipment.
- Unless otherwise specified, the dismantling process of the equipment is in reverse order to the installation process, and it will not be further elaborated in this document.
- 1. Power off the System.
- 2. Label the cables connected in the system with tags indicating the cable type.
- 3. Disconnect the connecting cables of the inverter, battery, and smart meter in the system, such as DC cables, AC cables, communication cables, and PE cables.
- 4. Remove equipment such as the smart dongle, inverter, battery, and smart meter.
- 5. Properly store the equipment and ensure that the storage conditions meet the requirements if it needs to be put into use later.

11.3 Disposing of the Equipment

If the equipment cannot work anymore, dispose of it according to the local disposal requirements for electrical equipment waste. The equipment cannot be disposed of together with household waste.

11.4 Routine Maintenance

WARNING

- If any issues that may affect the Battery or hybrid inverter system are detected, please contact after-sales personnel. Unauthorized disassembly is strictly prohibited.
- If exposed copper wires are found inside the conductive line, do not touch them. High voltage DANGER, please contact after-sales personnel. Disassembly by unauthorized personnel is prohibited.
- In the event of any other emergencies, please contact the after-sales personnel immediately. Follow their instructions for operation or wait for on-site assistance from the after-sales team.

Maintenan ce content	Maintenance method	Maintenanc e cycle	Maintenance purpose
System cleaning	Check for any foreign objects or dust on the heat sink, fan, and air inlet/outlet. Check if the Installation space meets the requirements, and inspect whether there is any debris accumulation around the equipment.	Once every six months	Prevent heat dissipation.
System Installation	Check whether the equipment Installation is stable and whether the fastening screw is loose. Check the equipment for any damage or deformation in appearance.	Once every six months to once a year	Verify the stability of the Installation equipment.
Electrical connection	Check for loose electrical connections, damaged cable insulation, or exposed copper conductors.	1 time/half year ~ 1 time/year	Verify the reliability of electrical connections.

Maintenan ce content	Maintenance method	Maintenanc e cycle	Maintenance purpose
Sealing	Check whether the equipment inlet hole Sealing meets the requirements. If the gap is too large or unsealed, reseal it.	Once per year	Verify that the machine's sealing and waterproof performance are intact.
Battery maintenanc e	If the Battery has not been used or fully charged for an extended period, it is recommended to perform regular Charge on the Battery.	Once/15 days	ProtectionBattery service life.

11.5 Fault

11.5.1 Viewing Fault/Alarms Information

All energy storage system and alarm details are displayed on [SolarGo App] and [SEMS+ APP] If your product exhibits abnormalities and is not covered under [SolarGo App] and [SEMS+ APP] If you see any fault information, please contact the after-sales service center.

SolarGo App

Through[Home]>[Parameter]> [Alarm]Check the energy storage system alarm information.

SEMS+ APP

- 1. Open the SEMS+ App and log in with any account.
- 2. Through[power station] >[Alarm]You can view all power stationfault information.
- 3. Click on the specific fault name to view the detailed occurrence time, possible causes, and solutions of the fault.

11.5.2 Fault Information and Troubleshooting

Perform troubleshooting according to the following methods. Contact the after-sales service if these methods do not work.

Collect the information below before contacting the after-sales service, so that the

problems can be solved quickly.

- 1. Product information like serial number, software version, installation date, fault time, fault frequency, etc.
- 2. Installation environment, including weather conditions, whether the PV modules are sheltered or shadowed, etc. It is recommended to provide some photos and videos to assist in analyzing the problem.
- 3. Utility grid situation.

11.5.2.1 System fault

If the system encounters an issue not listed, or if following the instructions fails to resolve the problem or abnormality, immediately cease system operation and contact your distributor without delay.

No.	fault	Solution measures
1	Unable to detect the smart dongle wireless signal	 Please ensure that no other devices are connected to the smart dongle wireless signal. Please ensure that the SolarGo app has been updated to the latest version. Ensure the smart communication stick is powered on normally, with the blue signal light flashing or steadily lit. Ensure the smart device is within the communication range of the smart dongle. Refresh the App device list. Restart Inverter.
2	Unable to connect to smart dongle wireless signal	 Please ensure that no other devices are connected to the smart dongle wireless signal. Restart the Inverter or communication stick, and try to reconnect to the smart dongle wireless signal. Ensure that Bluetooth is successfully encrypted and paired.

No.	fault	Solution measures		
3	Unable to find Router SSID	 Place the Router close to the Smart dongle, or add WiFi repeater devices to enhance the WiFi signal. Reduce the number of devices connected to the Router. 		
4	After all configurations are completed, Smart dongle fails to connect with Router.	 Restart Inverter Check whether the network name, encryption method, and password in the WiFi configuration are the same as those in Router. Restart Router. Place the Router close to the Smart dongle, or add a WiFi repeater to enhance the WiFi signal. 		
5	After all configurations are completed, Smart dongle fails to connect with Server.	Restart Router and Inverter.		

11.5.2.2 Inverter fault

fault code	fault name	fault cause	Troubleshooting recommendation
F01	Grid disconnected	1. power outage 2. AC line or AC Switch disconnected.	 The alarm automatically disappears after Grid connected recovery. Check if the AC line or AC Switch is disconnected.

fault code	fault name	fault cause	Troubleshooting recommendation
F02	Grid Overvoltage	Utility gridvoltage exceeds the allowable range, or the high voltage duration surpasses the high voltage ride-through setting value.	 If it occurs occasionally, it may be due to a temporary abnormality in Utility grid. Inverter will resume normal operation after detecting that Utility grid is functioning properly, without requiring manual intervention. If it occurs frequently, check whether Utility gridvoltage is within the allowable range. If Utility gridvoltage exceeds the permissible range, please contact the local power operator. If the Utility gridvoltage is within the allowable range, it is necessary to modify the InverterGrid Overvoltage point after obtaining consent from the local power operator.HVRTEnable or disable the Grid Overvoltage function. If the issue persists for an extended period, please check whether the AC-side breaker and output cables are properly

fault code	fault name	fault cause	Troubleshooting recommendation
			connected.
F03	Grid Undervoltage	Utility gridvoltage is below the permissible range, or the low-voltage duration exceeds the low voltage ride-through setting.	 If it occurs occasionally, it may be due to a temporary anomaly in Utility grid. The Inverter will resume normal operation upon detecting that Utility grid is functioning properly, without requiring manual intervention. If it occurs frequently, check whether Utility gridvoltage is within the allowable range. If the Utility gridvoltage exceeds the permissible range, please contact the local power operator. If Utility gridvoltage is within the allowable range, it is necessary to modify the InverterGrid Undervoltage point after obtaining consent from the local power operator,LVRTor disable the Grid Undervoltage function. If the issue persists for an extended period, please check whether the

fault code	fault name	fault cause	Troubleshooting recommendation
			AC-side breaker and output cables are properly connected.
F04	Grid Rapid Overvoltage	Abnormal detection of Utility gridvoltage or ultra-high voltage triggers fault.	 If it occurs occasionally, it may be due to a temporary abnormality in Utility grid. Inverter will resume normal operation after detecting that Utility grid is functioning properly, without requiring manual intervention. If it occurs frequently, check whether Utility gridvoltage is within the allowable range. If the Utility gridvoltage exceeds the permissible range, please contact the local power operator. If the Utility gridvoltage is within the allowable range, it is necessary to modify the InverterGrid Undervoltage point after obtaining consent from the local power operator.LVRTEnable or disable the Grid Undervoltage function. If the issue persists for an extended period,

t e	Troubleshooting recommendation
	please check whether the breaker on the AC side and
	the output cables are
	properly connected.

fault code	fault name	fault cause	Troubleshooting recommendation
F05	10minOvervoltage Protection	In10minThe sliding average of Utility gridvoltage exceeds the safety regulation limits.	 If it occurs occasionally, it may be due to a temporary abnormality in Utility grid. Inverter will resume normal operation after detecting that Utility grid is functioning properly, without requiring manual intervention. Check if Utility gridvoltage is operating at a high voltage for an extended period. If this occurs frequently, verify whether Utility gridvoltage is within the allowable range. If the Utility gridvoltage exceeds the permissible range, please contact the local power operator. If the Utility grid voltage is within the permissible range, it is necessary to obtain approval from the local power operator before modifying the Utility grid.10minOvervoltage Protection point.

fault code	fault name	fault cause	Troubleshooting recommendation
F06	Grid Overfrequency	Utility grid anomaly: Utility grid actual Frequency exceeds local Utility grid standard requirements.	 If it occurs occasionally, it may be due to a temporary abnormality in the Utility grid. The Inverter will resume normal operation after detecting that the Utility grid is functioning properly, without requiring manual intervention. If it occurs frequently, check whether the Utility grid and Frequency are within the allowable range. If the Utility grid Frequency exceeds the permissible range, please contact the local power operator. If Utility gridFrequency is within the allowable range, the Grid Overfrequency point needs to be modified after obtaining approval from the local power operator.

fault code	fault name	fault cause	Troubleshooting recommendation
F07	Grid Underfrequency	Utility grid anomaly: Utility grid actual Frequency is lower than the local Utility grid standard requirement.	 If it occurs occasionally, it may be due to a temporary abnormality in Utility grid. Inverter will resume normal operation after detecting that Utility grid is functioning properly, without requiring manual intervention. If it occurs frequently, please check whether Utility grid and Frequency are within the allowable range. If Utility gridFrequency exceeds the permissible range, please contact the local power operator. If the Utility grid Frequency point needs to be modified after obtaining approval from the local power operator.

fault code	fault name	fault cause	Troubleshooting recommendation
F08	Grid Frequency Instability	Utility grid anomaly: The actual Frequency variation rate does not comply with the local Utility grid standard.	 If it occurs occasionally, it may be due to a temporary abnormality in Utility grid. Inverter will resume normal operation after detecting that Utility grid is functioning properly, without requiring manual intervention. If it occurs frequently, please check whether Utility grid and Frequency are within the allowable range. If the Utility grid Frequency exceeds the permissible range, please contact the local power operator. If the Utility grid Frequency is within the allowable range, please contact your dealer or after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F163	Grid Phase Instability	Utility grid anomaly: Utility grid voltage phase variation rate does not comply with local Utility grid standards.	 If it occurs occasionally, it may be due to a temporary abnormality in the Utility grid. The Inverter will resume normal operation after detecting that the Utility grid is normal, without requiring manual intervention. If it occurs frequently, check whether the Utility grid and Frequency are within the allowable range. If Utility gridFrequency exceeds the permissible range, please contact the local power operator. If the Utility grid Frequency is within the permissible range, please contact your dealer or after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F09	Anti-islanding Protection	Utility grid has been disconnected, maintaining Utility grid voltage due to the presence of load. According to safety regulation Protection, on-grid has been stopped.	 If it occurs occasionally, it may be due to a temporary anomaly in Utility grid. Inverter will resume normal operation after detecting that Utility grid is normal, without requiring manual intervention. If it occurs frequently, check whether Utility grid and Frequency are within the allowable range. If Utility gridFrequency exceeds the permissible range, please contact the local power operator. If the Utility gridFrequency is within the allowable range, please contact your dealer or after-sales service center.
F10	LVRT Undervoltage	Utility grid anomaly: Utility gridvoltage duration exceeds the specified highlow crossing time.	

fault code	fault name	fault cause	Troubleshooting recommendation
F11	HVRT Overvoltage	Utility grid anomaly: Utility gridvoltage duration exceeds the specified high- low crossing time.	1. If it occurs occasionally, it may be due to a temporary abnormality in Utility grid. Inverter will resume normal operation after detecting that Utility grid is functioning properly, without requiring manual intervention. 2. If it occurs frequently, please check whether Utility grid, voltage, and Frequency are within the allowable range and stable. If not, contact the local power operator; if yes, contact your dealer or after-sales service center.
F43	Grid Waveform Abnormal	Utility grid anomaly: Utility grid voltage detection triggered fault due to abnormality.	
F44	Grid Phase Loss	Utility grid anomaly: Utility grid voltage has a single-phase voltage dip.	

fault code	fault name	fault cause	Troubleshooting recommendation
F45	Grid Voltage Imbalance	The phase difference of Utility grid is too large.	1. If it occurs occasionally, it may be due to a temporary abnormality in Utility grid. Inverter will resume normal operation after detecting that Utility grid is functioning properly, without requiring manual intervention. 2. If this occurs frequently, please check whether Utility grid, voltage, and Frequency are within the permissible range and stable. If not, contact the local power operator; if yes, contact your distributor or after-sales service center.
F46	Grid Phase Sequence Failure	Inverter and Utility grid wiring abnormality: wiring is not in positive sequence	1. Check whether the wiring of Inverter and Utility grid is in positive sequence. After the wiring is corrected (e.g., by swapping any two live wires), fault will automatically disappear. 2. If the wiring is correct and fault persists, please contact the dealer or GoodWe Customer Service Center.

fault code	fault name	fault cause	Troubleshooting recommendation
F47	Grid Rapid Shutdown Protection	Quickly shut down the output upon detecting the Grid disconnected operating condition.	1. Grid connected automatically disappears after fault recovery
F48	Utility grid Neutral line loss	Split-phase Utility grid neutral loss	 The alarm automatically disappears after Grid connected recovery. Check if the AC line or AC Switch is disconnected.
F160	EMS/Forced Off-Grid	EMSIssue forced off-grid command, but the off-grid function is not enabled.	Enable off-grid function
F161	Passive Anti- islanding Protection	-	-
F162	Grid Type Fault	Actual Grid type (two-phase or split- phase) does not match the set safety regulations.	Switch the corresponding safety regulations according to the actual Grid type.

fault code	fault name	fault cause	Troubleshooting recommendation
F12	30mAGfciProtection	During operation, the input-to- ground insulation resistance becomes low.	1. If it occurs occasionally, it may be caused by temporary external line abnormalities. The system will resume normal operation after the fault is cleared, without requiring manual intervention. 2. If the issue occurs frequently or cannot be resolved for an extended period, check whether the PV String ground impedance is too low.
F13	60mAGfciProtection	During operation, the input-to- ground insulation resistance becomes low.	1. If it occurs occasionally, it may be caused by temporary abnormalities in the external circuit. It will return to normal operation after fault is cleared, without requiring manual intervention. 2. If the issue occurs frequently or cannot be resolved for an extended period, please check whether the PV String ground impedance is too low.

fault code	fault name	fault cause	Troubleshooting recommendation
F14	150mAGfciProtectio n	During operation, the input-to- ground insulation resistance becomes low.	1. If it occurs occasionally, it may be caused by temporary abnormalities in the external circuit. The fault will clear automatically and resume normal operation without manual intervention. 2. If the issue occurs frequently or cannot be resolved for an extended period, please check whether the PV String grounding impedance is too low.
F15	Gfcigradual Protection	During operation, the input-to- ground insulation resistance becomes low.	1. If it occurs occasionally, it may be caused by temporary abnormalities in the external circuit. It will return to normal operation after fault is cleared, without requiring manual intervention. 2. If the issue occurs frequently or cannot be resolved for an extended period, check whether the PV String ground impedance is too low.

fault code	fault name	fault cause	Troubleshooting recommendation
F16	DCIPrimary Protection	The DC component of the inverter output current exceeds the safety regulations or the default allowable range of the machine.	1. If the abnormality is caused by an external fault, the Inverter will automatically resume normal operation after the fault disappears, without requiring manual intervention. 2. If this alarm occurs frequently and affects the normal power generation of the power station, please contact the dealer or GoodWe after-sales service center.
F17	DCISecondary Protection	The DC component of the inverter output current exceeds the safety regulations or the default allowable range of the machine.	1. If the abnormality is caused by an external fault, the Inverter will automatically resume normal operation after the fault disappears, without requiring manual intervention. 2. If this alarm occurs frequently and affects the normal power generation of the power station, please contact the distributor or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F18	Low Insulation Resistance	1. PV String to Protection ground short circuit. 2. PV StringInstallation operates in a persistently humid environment with poor line-to-ground insulation. 3. Batteryport line- to-ground Low Insulation Resistance.	1. Check the impedance between PV String/Batteryport and ground Protection. A resistance greater than 50kΩ is normal. If the measured resistance is less than 50kΩ, locate and rectify the short circuit point. 2. Check whether the PE cable of the Inverter is properly connected. 3. If it is confirmed that the impedance is indeed lower than the default value in rainy weather conditions, please reset the Inverter "insulation resistanceProtection point" via the SolarGo App. In the Australian and New Zealand markets, when insulation resistancefault occurs, alarms can also be triggered through the following methods: 1. Inverter is equipped with a buzzer. When a fault occurs, the buzzer will sound continuously for 1 minute. If the fault is not resolved, the buzzer will

fault code	fault name	fault cause	Troubleshooting recommendation
			sound again every 30 minutes. 2. If Inverter is added to the monitoring platform and the alarm notification method is configured, the alarm information can be sent to customers via email.
F19	Grounding Abnormal	1. The PE cable of Inverter is not connected. 2. When the output of PV String is grounded, the output side of Inverter is not connected to an isolation transformer.	 Please confirm whether the PE cable of Inverter is not connected properly. In the scenario where the output of PV String is grounded, please confirm whether the output side of Inverter is connected to an isolation transformer.
F49	L-PE Short Circuit	Output phase line toPELow impedance or short circuit	Detect output phase line toPEImpedance, identify Locations with low impedance and repair them.

fault code	fault name	fault cause	Troubleshooting recommendation
F50	DCVPrimary Protection	Abnormal load fluctuation	1. If the abnormality is caused by an external fault, the Inverter will automatically resume normal operation after the fault disappears, without requiring manual intervention. 2. If this alarm occurs frequently and affects the normal power generation of the power station, please contact the dealer or GoodWe after-sales service center.
F51	DCVSecondary Protection	Abnormal load fluctuation	1. If the abnormality is caused by an external fault, the Inverter will automatically resume normal operation after the fault disappears, without requiring manual intervention. 2. If this alarm occurs frequently and affects the normal power generation of the power station, please contact the dealer or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F20	Hardware power limit Protection	Abnormal load fluctuation	1. If the abnormality is caused by an external fault, the Inverter will automatically resume normal operation after the fault disappears, without requiring manual intervention. 2. If this alarm occurs frequently and affects the normal power generation of the power station, please contact the dealer or GoodWe after-sales service center.
F21	Internal Comm Loss	Reference specific subcode reason	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault still persists, please contact the distributor or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F52	Leakage currentGFCIMultiple fault shutdowns	North American safety regulations require that after multiple fault, the system cannot automatically recover and must be manually restored or wait.24hPost-recovery	1. Please check if the ground impedance of PV String is too low.
F53	DC arcAFCIMultiple fault shutdowns	North American safety regulations require that after multiple fault, the system must not recover automatically and requires manual intervention or waiting.24hPost-recovery	 After the machine is restarted, check whether the voltage and current of each circuit are abnormally reduced to zero. Check whether the DC side terminal is securely connected.
F54	External Comm Loss	External device communication lost, possibly due to peripheral power supply issues, Communication Protocols mismatch, or unconfigured corresponding peripheral devices.	Judgment is made based on the actual model and detection enable bits. Peripherals not supported by certain models will not be detected.

fault code	fault name	fault cause	Troubleshooting recommendation
F55	Back-upport Overload fault	Prevent Inverter from continuous overload output.	1. Disconnect some offgrid loads to reduce the off-grid output power of the Inverter.
F56	Back-upport overvoltage fault	2. Prevent damage to the load caused by overvoltage in the Inverter output.	 If it occurs occasionally, it may be caused by load switching and does not require manual intervention. If it occurs frequently, please contact the dealer or GoodWe after-sales service center.
F107	On-grid PWM Sync Failure	Abnormal condition detected in carrier synchronization ongrid	1Check if the synchronization line connection is normal. 2Check if the master-slave settings are normal. 3Disconnect the AC output side switch and the DC input side switch.5 After a few minutes, close the AC output side switch and the DC input side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F57	External connectionBoxfault	Waiting for grid disconnectionBoxE xcessive relay switching time	 InspectionBoxIs it functioning properly; InspectionBoxIs the communication wiring correct?
-	Generator Failure	1. This fault will always be displayed when the generator is not connected. 2. During	1. When the generator is not connected, ignore this fault;
F22	Generator Waveform Detection Fault		2. This fault is normal when the generator
F23	Generator Abnormal Connection		experiences fault. After the generator recovers, wait for a period of time, and
F24	Generator Low Voltage		the fault will be automatically cleared.
F25	Generator High Voltage	generator operation, failure	3. The fault will not affect the normal operation of
F26	Generator Low Frequency	to meet generator safety regulations will trigger this fault.	the off-grid mode. 4. The generator and Utility grid are connected
F27	Generator High Frequency		simultaneously and meet safety requirements. Utility grid takes priority for on- grid and will operate in the Utility grid on-grid state.
F109	External connectionSTSfault	Inverter andSTSAbnormal connection cable	Check Inverter and STSIs the wiring sequence of the harness connection one-to-one corresponding in order?

fault code	fault name	fault cause	Troubleshooting recommendation
F58	CTMissing fault	CTConnection wire disconnected (Japanese safety regulation requirement)	InspectionCTWhether the wiring is correct.
F110	Export Limit Protection	 Fault report and grid disconnection meterUnstable communication Reverse power flow condition occurs 	 Check if there are any other error messages in Inverter. If so, perform targeted troubleshooting. InspectionmeterIs the connection reliable? If this alarm occurs frequently and affects the normal power generation of the power station, please contact the dealer or GoodWe after-sales service center.
F111	Bypassoverload	-	-
F112	Black Start Failure	-	-
F28	Parallel operationIOSelf- check abnormality	Parallel communication line is not securely connected or parallel operation is not synchronized.IOChi p damage	Check if the parallel communication cable is securely connected, and then inspect again.IOIs the chip damaged? If so, replace it.IOChip.

fault code	fault name	fault cause	Troubleshooting recommendation
F59	Parallel operationCANComm unication abnormality	The parallel communication cable is not securely connected or some units are offline.	Check whether all machines are power on and ensure the parallel communication cables are securely connected.
F29	Parallel Grid Line Reversed	Some machines have the Utility grid line connected in reverse with others.	Reconnect the Utility grid wiring.
F60	Parallel operationBack- upreverse connection	Partial machinesbackupLi ne connected incorrectly with others	ReconnectionbackupLine.
F61	INV Soft Start Failure	Off-grid cold start INV Soft Start Failure	Check whether the inverter module of the machine is damaged.
F113	Offgrid AC Ins Volt High	-	-
F30	AC HCT Check Abnormal	AC sensor sampling anomaly detected	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F62	AC HCT Failure	HCTSensor abnormality detected	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F31	GFCI HCT Check Abnormal	Leakage current sensor sampling anomaly detected.	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F63	GFCI HCT Failure	Leakage current sensor anomaly detected.	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F32	Relay Check Abnormal	Relay abnormality, reason: 1Relay anomaly (relay short circuit) 2Relay sampling circuit abnormality. 3Abnormal AC side wiring (possible loose connection or short circuit phenomenon)	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F64	Relay Failure	1Relay abnormality (relay short circuit) 2Relay sampling circuit abnormality. 3Abnormal AC measurement wiring (possible loose connection or short circuit)	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F164	DC arc fault (string17~32)	1DC side connection terminal loose; 2DC side connection terminal loose contact; 3Core damage and poor contact	1After the machine is re- on-grid, check whether the voltage current of each circuit is abnormally reduced to zero. 2Check if the DC-side terminal is securely connected.

fault code	fault name	fault cause	Troubleshooting recommendation
F165	DC arc fault (string)33~48)	1DC side connection terminal loose; 2DC side connection terminal loose contact; 3Core damage and poor contact	1After the machine is re- on-grid, check whether the voltage current of each circuit is abnormally reduced to zero. 2Check if the DC side terminal is securely connected.
F33	FlashRead/Write Error	Possible causes: flashContent has been modified;flashEnd of life	 Upgrade to the latest version of the program Contact the distributor or GoodWe after-sales service center.
F42	DC arc fault (string1~16)	1DC side connection terminal loose; 2DC side connection terminal loose contact; 3Core damage and poor contact	1After the machine is re- on-grid, check whether the voltage current of each circuit abnormally decreases to zero; 2Check if the DC-side terminal is securely connected.
F34	AFCI Check Failure	During the arc self- check process, the arc module failed to detect the arc fault.	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F65	AC Terminal Overtemperature	AC Terminal Overtemperature, possible causes: 1InverterInstallatio n Location not ventilated. 2Ambient temperature is too high. 3Internal fan operation abnormal.	1Check if the ventilation of Inverter Installation Location is adequate and if the ambient temperature exceeds the maximum permissible ambient temperature range. 2If there is no ventilation or the ambient temperature is too high, please improve its ventilation and heat
F35	Cabinet Overtemperature	Cabinet Overtemperature, possible causes: 1InverterInstallatio n Location non- ventilated. 2Ambient temperature is too high. 3Internal fan operation abnormal.	dissipation conditions. 3If ventilation and ambient temperature are normal, please contact the dealer or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F66	INVModule temperature too high	Inverter module temperature is too high, possible causes: 1InverterInstallatio n Location not ventilated. 2Ambient temperature is too high. 3Internal fan operation abnormal.	
F67	BoostModule temperature too high	BoostModule temperature too high, possible causes: 1InverterInstallatio n Location not ventilated. 2Ambient temperature is too high. 3Internal fan operation abnormal.	

fault code	fault name	fault cause	Troubleshooting recommendation
F68	AC Capacitor Overtemperature	Output filter capacitor temperature is too high, possible causes: 1InverterInstallatio n Location not ventilated. 2Ambient temperature is too high. 3Internal fan operation abnormal.	
F114	Relay Failure2	Relay abnormality, reason: 1Relay abnormality (relay short circuit) 2Relay sampling circuit abnormality. 3Abnormal AC side wiring (possible loose connection or short circuit phenomenon)	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F69	PV IGBT short circuit	Possible causes: 1. IGBTshort circuit 2Sampling circuit abnormality	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F70	PV IGBTOpen circuit	 Software issue causing no wave transmission Drive circuit abnormality: IGBTOpen circuit 	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F71	NTCAbnormall	NTCTemperature sensor abnormality detected	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F72	PWM Abnormal	PWMAbnormal waveform detected	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F73	CPUInterruption exception	CPUInterruption anomaly occurred	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F74	Microelectronic Failure	Functional safety detects an abnormality.	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F75	PV HCTfault	boostSensor abnormality	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F76	1. 5VBaseline anomaly	Reference circuit	Disconnect the AC output side switch and DC input
F77	0. 3VBaseline anomaly	Reference circuit	side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F78	CPLDVersion identification error	CPLDVersion identification error	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F79	CPLDCommunicatio n fault	CPLDandDSPComm unication content error or timeout	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F80	Model Type Error	Regarding the model identification error fault	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F115	SVGPrecharge failure	SVGPrecharge hardware failure	Contact the distributor or GoodWe after-sales service center.
F116	nightSVG PIDPrevention of fault	PIDPrevent hardware anomalies	Contact the distributor or GoodWe after-sales service center.
F117	DSPVersion identification error	DSPSoftware version identification error	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation		
F36	Bus Overvoltage	BUSOvervoltage, possible causes:	Disconnect the AC output side switch and DC input side switch,5 After a few		
F81	P-Bus Overvoltage	1. PVvoltage too high 2InverterBUSSampl	minutes, close the AC output side switch and the		
F82	N-Bus Overvoltage	ing anomaly 3The isolation	DC input side switch. If fault persists, please contact the dealer or		
F83	DeputyCPU1)	effect of the rear- end double-split Inverter is poor, causing mutual interference between the two Inverter on-grid. One of them reports DC	GoodWe after-sales service center.		
F84	DeputyCPU1)				
F85	DeputyCPU1)		between the two Inverter on-grid. One of them reports DC		
F86	DeputyCPU2)				
F87	DeputyCPU2)	overvoltage when Inverter on-grid.			
F88	DeputyCPU2)				
F89	P-Bus Overvoltage(CPLD)				
F90	N-Bus Overvoltage (CPLD)				

fault code	fault name	fault cause	Troubleshooting recommendation
F118	MOSContinuous overvoltage	1. Software issue causes the inverter drive to shut down earlier than the flyback drive. 2. Inverter drive circuit abnormality prevents turn-on. 3. PVvoltage too high 4. MosSampling anomaly	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F119	Bus Short Circuit	1. Hardware damage	In case of occurrenceBUSAfter a fault short circuit, the Inverter remains in an off-grid state. Please contact the dealer or GoodWe aftersales service center.
F120	Bus Sample Abnormal	1. Bussampling hardware	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F121	DCSide sampling anomaly	1. Bus sampling hardware 2. Batteryvoltage Sampling Hardware fault 3. DcrlyRelay Failure	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F37	PVInput overvoltage	PVInput voltage is too high, possible causes: Incorrect PV array configuration, with too many PV Battery panels connected in series in the string, causing the string's open-circuit voltage to exceed the maximum operating voltage of the Inverter.	Check the series configuration of the corresponding PV array strings to ensure that the open-circuit voltage of the strings does not exceed the maximum working voltage of the Inverter. Once the PV array is correctly configured, the Inverter alarm will automatically disappear.
F38	PVContinuous hardware overcurrent	 Unreasonable module configuration Hardware damage 	Disconnect the AC output side switch and DC input side switch,5After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F39	PVContinuous software overcurrent	1. Unreasonable module configuration 2. Hardware damage	
F91	FlyCap Software Overvoltage	Flying capacitor overvoltage, possible causes: 1. PVvoltage too high 2Inverter flying capacitor voltage sampling anomaly;	Disconnect the AC output side switch and DC input side switch,5After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service
F92	FlyCap Hardware Overvoltage	Flying capacitor overvoltage, possible causes: 1. PVvoltage too high 2InverterFlying CapacitorvoltageSa mpling Anomaly	center.
F93	FlyCap Undervoltage	FlyCap Undervoltage, Possible causes: 1. PVEnergy deficiency; 2Inverter flying capacitor voltage sampling anomaly	

fault code	fault name	fault cause	Troubleshooting recommendation
F94	FlyCap Precharge Failure	FlyCap Precharge Failure, possible causes: 1. PVEnergy deficiency; 2Inverter Flying Capacitor voltage Sampling Anomaly	
F95	FlyCap Precharge Abnormal	1. Unreasonable control loop parameters 2. Hardware damage	
F96	String overcurrent(String1 ~16)	Possible causes: 1. String Overcurrent	
F97	String overcurrent(String1 7~32)	2. String sensor abnormality	
F40	String reverse connection(String1~16)	PVString reverse connection	Check if the strings are reverse-connected.

fault code	fault name	fault cause	Troubleshooting recommendation
F98	String reverse connection(String17 ~32)	PVString reverse connection	Check if the strings are reverse connected.
F99	String loss(String1~16)	String fuse disconnected (if applicable)	Check if the fuse is blown.
F100	String loss(string17~32)	String fuse disconnected (if applicable)	Check if the fuse is blown.
F122	PVIncorrect access mode setting	PVThere are three access modes in total, with four channels.MPPTFor example: 1. Parallel mode: that isAAAAMode(homol ogous mode),PV1-PV4Homologous,4R oadPVConnect the same photovoltaic panel 2. Partial Parallel Mode:	InspectionPVIs the access mode correctly set?ABCD、AACC、AAAA), reset in the correct mannerPVConnection mode. 1. Confirm the actual connected circuitsPVIs the connection correct. 2. IfPVCorrectly connected, passedAPPOr check the current settings on the screen.PVCheck whether the "connection mode" corresponds to the actual

fault code	fault name	fault cause	Troubleshooting recommendation
		i.e.AACCMode,PV1a ndPV2homologous connection,PV3and PV4homologous connection 3. Stand-alone mode: i.e.ABCDMode(non- homologous),PV1、 PV2、PV3、 PV4Independent connection,4RoadP VEach connected to a photovoltaic panel IfPVThe actual connection mode and equipment configurationPVThi s fault will be reported if the access mode does not match.	connection mode. 3. If the currently setPVThe access mode does not match the actual access mode and needs to be adjusted.APPor screen willPVSet the "Access Mode" to the mode consistent with the actual situation. After the setup is completed,PVandACPower supply disconnection and restart. 4. After the setup is completed, if the currentPVThe access mode is consistent with the actual access mode, but this fault is still reported. Please contact the dealer or GoodWe after-sales service center.
_	String reverse connection(String33 ~48)	PVString reverse connection	Check if the strings are reverse-connected.

fault code	fault name	fault cause	Troubleshooting recommendation
-	String loss(String33~48)	String fuse disconnected (if applicable)	Check if the fuse is blown.
-	String overcurrent(String3 3~48)	Possible causes: 1. String Overcurrent 2. String sensor abnormality	
F123	Multi-string PV Phase Mismatch Failure	Incorrect PV input mode setting	Check whether the PV connection mode is correctly set (ABCD, AACC, AAAA) and reset it to the correct PV connection mode. 1. Verify that each connected PV string is correctly wired. 2. If the PV is correctly connected, check via the APP or screen whether the currently set "PV Connection Mode" corresponds to the actual connection mode. 3. If the currently set "PV Connection Mode" does not match the actual connection mode, it is necessary to set the "PV Connection Mode" to the mode consistent with the actual situation via the APP or screen. After completing

fault code	fault name	fault cause	Troubleshooting recommendation
			the settings, disconnect the PV and AC power supply and restart. 4. After completing the setup, if the current "PV Connection Mode" matches the actual connection mode but this fault error still occurs, please contact the dealer or GoodWe after-sales service center.
F101	Battery1Precharge resistor	Battery1Pre-Charge circuit fault (such as pre-Charge resistor burnout, etc.)	Check whether the pre- Charge circuit is in good condition. Only after Battery power on, verify whether the Battery voltage matches the busbar voltage. If they do not match, please contact the dealer or GoodWe after-sales service center.
F102	Battery1Relay Failure	Battery1The relay fails to operate normally.	After Batterypower on, check whether the Battery relay operates and if a closing sound is heard. If it does not function, please contact the dealer or GoodWe after-sales service center.
F103	Battery1overvoltage at the point of connection	Battery1Input voltage exceeds the rated range of the machine.	Verify if Batteryvoltage is within the machine's rated range.

fault code	fault name	fault cause	Troubleshooting recommendation
F104	Battery2Precharge resistor	Battery2Pre-Charge circuit fault (such as pre-Charge resistor burnout, etc.)	Check whether the pre- Charge circuit is in good condition. Only after Battery power on, verify whether the Battery voltage matches the busbar voltage. If they do not match, please contact the distributor or GoodWe after-sales service center.
F105	Battery2Relay Failure	Battery2The relay fails to operate properly.	After Battery power on, check whether the Battery relay operates and if a closing sound is heard. If it does not function, please contact the distributor or GoodWe after-sales service center.
F106	Battery2overvoltage at the point of connection	Battery2The voltage access exceeds the rated range of the machine.	Verify if Batteryvoltage is within the machine's rated range.
F124	Battery1Reverse connection fault	Battery1Reverse polarity of positive and negative terminals	Check whether the polarity of Battery and the machine terminals is consistent.
F125	Battery2Reverse connection	Battery2Reverse polarity of positive and negative terminals	Check whether the polarity of the Battery and the machine terminals is consistent.
F126	BAT Connection Abnormal	BAT Connection Abnormal	Check if the Battery is functioning properly.
-	BMS Status Bit Error	BMS Module fault	

fault code	fault name	fault cause	Troubleshooting recommendation
F127	BAT Overtemperature	Battery temperature is too high, possible causes: 1InverterInstallatio n Location not ventilated. 2Ambient temperature is too high. 3Internal fan operation abnormal.	Disconnect the AC output side switch and DC input side switch, then close the AC output side switch and DC input side switch after 5 minutes. If fault persists, please contact the distributor or GoodWe after-sales service center.
F128	Ref Voltage Abnormal	Reference circuit	Disconnect the AC output side switch and DC input
F129	Cabinet Under Temperature	Cabinet Under Temperature, Possible causes: 1. Ambient temperature is too low.	side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F130	ACsideSPDfault	ACFailure of lateral lightning protection device	ReplacementACSide lightning protection device.
F131	DCsideSPDfault	DCFailure of lateral lightning protection device	ReplacementDCLateral lightning protection device.

fault code	fault name	fault cause	Troubleshooting recommendation
F132	Internal Fan Abnormal	Internal Fan Abnormal, Possible causes: 1Abnormal fan power supply; 2mechanical fault(Locked rotor); 3Fan aging and damage.	Disconnect the AC output side switch and DC input side switch,5 After a few minutes, close the AC output side switch and the DC input side switch. If fault persists, please contact the dealer or GoodWe after-sales service center.
F133	External Fan Abnormal	External Fan Abnormal, Possible causes: 1Abnormal fan power supply; 2Mechanical fault(Locked rotor); 3Fan aging and damage.	
F134	PIDDiagnose abnormality	PIDHardware fault orPVvoltage too highPIDSuspend	PVOvervoltage caused by voltagePIDPause WARNING does not require processing.PIDHardware fault can be turned off.PIDSwitch reclosure clearingPIDfault, replacementPIDinstallatio n

fault code	fault name	fault cause	Troubleshooting recommendation
F135	Trip-Switch Trip Warning	Possible causes: Overcurrent orPVReverse connection causes the trip switch to trip.	Please contact the dealer or GoodWe after-sales service center. The reason for disconnection is due to an occurrence.PVShort circuit or reverse connection, need to check for any historical issues.PVShort circuit WARNING or historyPVReverse connection WARNING. If present, maintenance personnel should inspect the corresponding issue.PVSituation. After confirming there is no fault, the trip switch can be manually closed, and then pass throughAPPInterface Clear History fault Operation Clears This WARNING.

fault code	fault name	fault cause	Troubleshooting recommendation
F136	historyPV IGBT short circuit	Possible causes: Overcurrent caused the trip switch to open.	Please contact the distributor or GoodWe after-sales service center. Maintenance personnel should follow the historicalPVShort-circuit WARNING subcode, check for short-circuit occurrenceBoostCheck whether there is any fault in the hardware and external string; after confirming no fault, it can pass.APPInterface Clear History fault Operation Clears This WARNING.
F137	historyPVReverse polarity WARNING(string1~1 6)	Possible causes: occurrencePVRever se connection causes the trip switch to trip.	Contact the distributor or GoodWe after-sales service center. Maintenance personnel must follow the historicalPVReverse connection WARNING subcode, check whether the corresponding string has a reverse connection, inspectPVIs there a voltage difference in the panel configuration? After checking and confirming no fault, it can be passed.APPInterface Clear History fault Operation Clears This WARNING.

fault code	fault name	fault cause	Troubleshooting recommendation
F138	historyPVReverse connection(string17 ~32)	Possible causes: occurrencePVRever se connection causes the trip switch to trip.	Contact the distributor or GoodWe after-sales service center. Maintenance personnel must follow the historicalPVReverse polarity WARNING subcode, check if the corresponding string has reverse polarity, inspectPVIs there a voltage difference in the panel configuration? After checking and confirming no fault, it can proceed.APPInterface Clear History fault Operation Clears This WARNING.
F139	FlashRead/Write Error	Possible causes: flashContent has been modified;flashEnd of life	 Upgrade to the latest version of the program. Contact the distributor or GoodWe after-sales service center.

fault code	fault name	fault cause	Troubleshooting recommendation
F140	Meter Comm Loss	This WARNING may only be reported after enabling the power limit function. Possible causes: 1. Meter not connected; 2. The communication line connection between the meter and Inverter is incorrect.	Check the meter wiring and ensure it is correctly connected. If fault persists after inspection, please contact the distributor or GoodWe after-sales service center.
F141	PVPanel type identification failed	PVPanel identification hardware anomaly	Contact the distributor or GoodWe after-sales service center.
F142	PV String Mismatch	PVPV String Mismatch, same circuitMPPTThe configurations of the next two strings are different.	Check the two strings open-circuit voltage, and configure the strings with the same open-circuit voltage to the same circuit.MPPTThere are potential safety hazards with prolonged PV String Mismatch exposure.
F143	CTNot connected	CTNot connected	InspectionCTWiring.
F144	CTreverse connection	CTReverse connection	InspectionCTWiring.
F145	PE Loss/PE Loss	Ground wire not connected	Check the ground wire.

fault code	fault name	fault cause	Troubleshooting recommendation
F146	String temperature high(string1~8)	37176RegisterPVter minal temperature alarm subcode1Set	-
F147	String temperature high(string9~16)	37177registerPVter minal temperature alarm subcode2Set	-
F148	String terminal temperature high(string17~20)	37178RegisterPVter minal temperature alarm subcode3Set position	-
F149	historyPVReverse polarity WARNING(string33~ 48)	Possible causes: occurrencePVRever se connection causes the trip switch to trip.	Please contact the dealer or GoodWe after-sales service center; maintenance personnel should follow the historyPVReverse connection WARNING subcode, check whether the corresponding string is reversed, checkPVIs there a voltage difference in the panel configuration? After checking and confirming no fault, it can be passed.APPInterface Clear History fault Operation Clears This WARNING.
F150	Battery1voltage low	Batteryvoltage is below the set value	-
F151	Battery2voltage low	Batteryvoltage is below the set value	-
F152	Low Voltage of BAT Power	Battery non-Charge mode, voltage below shutdown voltage	-

fault code	fault name	fault cause	Troubleshooting recommendation
F153	BAT1 Voltage High	-	-
F154	BAT2 Voltage High	-	-
F155	On Line Low Insulation Resistance	PV String is short-circuited to ground with Protection. 2. The environment of PV StringInstallation is consistently humid, and the line-to-ground insulation is poor.	Check the impedance between PV String and Protection to ground. If a short circuit is found, rectify the short circuit point. 2. Check whether the PE cable of the Inverter is properly connected. 3. If it is confirmed that the impedance is indeed lower than the default value under rainy weather conditions, please reset the "insulation resistanceProtection point".
F156	Micro-grid Overload Warning	Excessive input at the backup end current	Occasional occurrences require no action; if this alarm appears frequently, please contact the dealer or GoodWe after-sales service center.
F157	Manual Reset	-	-
F158	Generator Phase Sequence Abnormal	-	-

fault code	fault name	fault cause	Troubleshooting recommendation
F159	Multiplexed Port Configuration Abnormal	Reuse (Generator) port configured as a microgrid or large load, but actually connected to a generator.	Use the APP to modify the reuse (generator) port configuration.
F41	Generator Port Overload	 Off-grid side output exceeds the specifications stated in the technical documentation. Off-grid side short circuit Off-grid terminal voltage too low When acting as a large load port, the load exceeds the requirements specified in the datasheet. 	By verifying the data, confirm the off-grid side output voltage, current, Power, and other parameters to identify the cause of the issue.
F108	DSP Communication Fail	-	-

fault name	fault cause	Troubleshooting recommendation
Parallel Comm Timeout Shutdown	In parallel operation, if the slave unit exceeds400No communication with the host within seconds	Check whether the parallel communication harness is securely connected and verify that there are no duplicate slave addresses.
One-click Remote Shutdown	Check if the one-touch shutdown function is enabled via SolarGo APP.	Deactivate one-touch shutdown.
Offline Shutdown	-	-
Remote Shutdown	-	-
Child Node Communicatio n Failure	Internal communication exception	Restart the machine and observe whether fault is eliminated.
DG Communicatio n Failure	Abnormal communication link between the control board and the diesel generator	1. Check the link communication harness and observe whether fault is eliminated; 2. Attempt to restart the machine and observe whether fault is eliminated; 3. If the fault persists after restarting, please contact GoodWe's aftersales service center.
Battery Over Voltage	 The voltage of a single cell is too high. Abnormal voltage collection line 	

fault name	fault cause	Troubleshooting recommendation
	Battery total pressure too high 2. Abnormal voltage collection line	Record the fault phenomenon, restart
Battery Under	 Single cell voltage too low Abnormal voltage collection line 	the Battery, wait for a few minutes, and confirm whether the
Voltage	 Battery Total pressure too low Abnormal voltage collection line 	fault disappears. If the issue persists after
Battery Over Current	Chargecurrent is too large, Battery current limiting is abnormal: sudden changes in temperature and voltage value Inverter response anomaly	restarting, please contact GoodWe after- sales service center.
	Battery dischargecurrent is too large	
Battery Over	 Ambient temperature is too high Temperature sensor abnormality 	
Temperature	 Ambient temperature too high Temperature sensor abnormality 	
Battery Under	 Ambient temperature is too low Temperature sensor abnormality 	
Temperature	 Ambient temperature is too low Temperature sensor abnormality 	
Battery Pole Over Temperature	Pole temperature too high	

fault name	fault cause	Troubleshooting recommendation
Battery Imbalance	 Excessive temperature difference at different stages. Battery will impose restrictions on BatteryPower, i.e., limit the charging of Dischargecurrent. Therefore, this issue is generally unlikely to occur. The capacity of the battery cell degrades, leading to excessive internal resistance, which causes significant temperature rise and large temperature differences during current. Poor welding of battery cell tabs, leading to excessive current and rapid temperature rise in the cell. Temperature sampling issue; power cable connection loose 	
	 Inconsistent aging levels of battery cells Issues with the board chip can also lead to excessive voltage differences between battery cells. Imbalance issues in the battery pack can also lead to excessive voltage differences between cells. Harness issue causing 	
	 Inconsistent aging levels of battery cells Issues with the board chips can also lead to excessive voltage differences between battery cells. Imbalanced cell balancing can also lead to excessive voltage differences between cells. Harness issues causing 	

fault name	fault cause	Troubleshooting recommendation
Insulation Resistance	Insulation resistance failure	Check if the ground wire is properly connected, restart the Battery. If the issue persists after restarting, please contact GoodWe aftersales service center.
Pre-charge Failure	Precharge failure	It indicates that during the precharge process, the voltage across the precharge MOS consistently exceeds the specified threshold. After restarting the system, observe whether this fault persists, and check if the wiring is correct and if the precharge MOS is damaged.
Collection Line Failure	Battery acquisition line poor contact or disconnected	Check the wiring and restart the Battery. If the issue persists after restarting, please contact GoodWe's aftersales service center.
	Single PV module collection line or disconnection	Check the wiring and restart the Battery. If
	Monomer temperature acquisition line poor contact or disconnected	the issue persists after restarting, please contact GoodWe's after-
	Dual-channel current comparison error is too large, or current acquisition line circuit is abnormal	sales service center.

fault name	fault cause	Troubleshooting recommendation
	Dual-channel voltage comparison error is too large, or MCU and AFE voltage comparison error is too large, or voltage acquisition line loop is abnormal.	
	Temperature acquisition line circuit abnormal or poor contact, disconnected	
	Overvoltage level 5 or overtemperature level 5, fuse the three-terminal fuse	To replace the three- stage fuse, please contact GoodWe's after- sales service center to replace the main control board.
Relay or MOS Over Temperature	Relay or MOS Over Temperature	The fault indicates that the MOSFET temperature has exceeded the specified threshold. Power off and let it stand for 2 hours to allow temperature recovery.
Shunt Over Temperature	Shunt Over Temperature	The fault indicates that the shunt tube temperature has exceeded the specified threshold. Power off and allow it to stand for 2 hours to wait for temperature recovery.

fault name	fault cause	Troubleshooting recommendation
BMS1 Other Failure 1 (RES)	Relay or MOSFET open circuit	1. Upgrade the software, power off and let it sit for 5 minutes, then check if fault persists after restarting. 2. If the issue persists, replace the Battery package.
	Relay or MOS short circuit	1. Upgrade the software, power off and let it sit for 5 minutes, then check if fault persists after restarting. 2. If the issue persists, replace the Battery package.
	Communication abnormality between the master cluster and slave cluster, or inconsistency of battery cells between clusters.	1. Check the Battery information and software version of the slave unit, as well as whether the communication line connection with the master unit is normal. 2. Upgrade the software
	Abnormal circuit harness of Battery system, resulting in no loop formation for interlocking signal	Check if Terminal resistorInstallation is correct

fault name	fault cause	Troubleshooting recommendation
	BMS and PCS communication abnormality	1. Verify that the communication line interface definition between Inverter and Battery is correct. 2. Please contact the GoodWe after-sales service center to check the backend data and verify whether the Inverter and Battery software are correctly matched.
	Abnormal communication harness between BMS master and slave control Communication loss between main and negative chips	 Check the wiring and restart the Battery; Upgrade the Battery. If the issue persists after restarting, please contact GoodWe's aftersales service center.
	Abnormal MCCB and shunt trip	1. Let the system remain powered off for 5 minutes, then restart and check if fault persists. 2. Check whether the blind mating at the bottom of the PACK and PCU, as well as the communication pins, are loose or misaligned.

fault name	fault cause	Troubleshooting recommendation
	MCU self-test failed	Upgrade the software and restart the Battery. If the issue persists after restarting, please contact the GoodWe after-sales service center.
	The software version is too low or the BMS board is damaged. 2. The number of Inverter parallel units is large, and the impact during precharging is excessive for Battery.	 Upgrade the software and observe whether fault persists. In the case of parallel operation, perform a black start on Battery before starting Inverter.
	Internal fault of MCU	Upgrade the software and restart the Battery. Typically, this is to detect damage to the MCU or external components. If the issue persists after restarting, please contact GoodWe's after-sales service center.
	Master control current exceeds the specified threshold	 Let the system stand idle for 5 minutes, then restart and check if fault persists. Check if the Inverter is set with an excessively large Power, causing it to exceed the bus load.

fault name	fault cause	Troubleshooting recommendation	
	Parallel cluster Battery cell inconsistency	Verify whether the cells in the cluster Battery are consistent.	
	String Battery reverse polarity of positive and negative terminals	Check whether the positive and negative poles of the string Battery are reversed.	
	Severe overheating or overvoltage triggers the fire protection system.	Contact GoodWe After- Sales Service Center.	
	Air conditioning abnormal failure	Try restarting the system. If fault persists, please contact GoodWe After-Sales Service Center.	
	Cabinet door not closed	Check whether the cabinet door is properly closed.	
Air	Power supply voltage too high	Verify that the power	
Conditioner	Insufficient power supply	supply voltage value meets the air	
Failure	No voltage input	conditioning input	
	Unstable power supply	voltage requirements, and proceed with re- power on only after confirmation.	
	Compressor instability	Try restarting the	
	Sensor poor contact or damaged	system. If the fault persists, please contact	
	Abnormal air conditioning fan	GoodWe Customer Service Center.	
	There is an abnormality in the voltage or current inside the DCDC.		

fault name	fault cause	Troubleshooting recommendation
BMS2 Other Failure 2 (RES)	DCDC overload or heat sink temperature too high	Refer to the specific DCfault content for details.
	Abnormal cell collection or inconsistent aging levels	Please contact GoodWe after-sales service center.
	Fan operation not executed properly	Please contact GoodWe after-sales service center.
	Output port screw loose or poor contact	1. BatteryShut down, check wiring and output portscrew status 2. After confirmation, restart the Battery and observe whether the fault persists. If it does, please contact the GoodWe after-sales service center.
	Battery prolonged usage or severe battery cell damage	Please contact the GoodWe after-sales service center to replace the pack.
	 The software version is too low or the BMS board is damaged. A large number of Inverter parallel units results in excessive inrush current during pre-charging of Battery. 	 Upgrade the software and observe whether fault persists. In the case of parallel operation, perform a black start on Battery first, then start Inverter.
	Heating film damaged	Please contact GoodWe after-sales service center.

fault name	fault cause	Troubleshooting recommendation
	The three-terminal fuse of the heating film is blown, rendering the heating function unusable.	Please contact GoodWe after-sales service center.
	Software model, Cell Type, hardware model mismatch	Check whether the software model, serial number (SN), Cell Type, and hardware model are consistent. If not, please contact GoodWe's aftersales service center.
	Thermal management board communication disconnection	 Let the system remain powered off for 5 minutes, then restart and check if fault persists. If the fault is not restored, contact GoodWe after-sales service to replace the pack.
	Thermal management board communication disconnection	 Let the system remain powered off for 5 minutes, then restart and check if fault persists. If the fault is not restored, contact GoodWe after-sales service to replace the pack.

fault name	fault cause	Troubleshooting recommendation
	Thermal management board communication disconnection	1. Let the system remain powered off for 5 minutes, then restart and check if fault persists. 2. If the fault is not restored, contact GoodWe after-sales service to replace the pack.
	Pack fan fault signal trigger	 Let the system remain powered off for 5 minutes, then restart and check if fault persists. If the fault is not restored, contact GoodWe after-sales service to replace the pack.
DCDC Failure	Output portvoltage too high	Check the output portvoltage. If the output portvoltage is normal and the fault still cannot be resolved after restarting Battery, please contact GoodWe after-sales service center.

fault name	fault cause	Troubleshooting recommendation
	The DCDC module detected that the Battery voltage exceeded the maximum Charge voltage.	Stop Charge and Discharge until SOC drops below 90% or remains idle for 2 hours. If the issue persists and restarting fault does not resolve it, please contact GoodWe Customer Service Center.
	Let the inverter s for 1 hour until the sink temperature. If the issue persist restarting the inverter solve please contact. GoodWe's after-service center.	
	Battery dischargecurrent is too large	Check if the load exceeds the Battery's Discharge capability. Turn off the load or stop the PCS for 60 seconds. If the issue persists after restarting the fault, please contact GoodWe's after-sales service center.
	Output port power harness positive and negative terminals are reversed with the combiner box Battery or PCS.	Turn off the Battery manual switch, check if the output port wiring is correct, and restart the Battery.

fault name	fault cause	Troubleshooting recommendation
	The Power output relay fails to close.	Check whether the output port wiring is correct and if there is a short circuit. If the issue persists after restarting fault, please contact GoodWe after-sales service center.
	Power device temperature too high	Let the Battery stand for 1 hour to allow the temperature of internal Power components to decrease. If the issue persists and restarting the fault does not resolve it, please contact GoodWe's after-sales service center.
	Relay sticking	Restart fault still exists. Please contact GoodWe Customer Service Center.
Battery Rack Circulating Current Failure 1. Cell imbalance 2. First power on undercharge correction		-

fault name	fault cause	Troubleshooting recommendation
BMS2 Other Failure 3 (LES)	Communication exception with Linux module	1. Check if the communication link is functioning properly. 2. Upgrade the software, restart the Battery, and observe whether the fault persists. If it does, please contact GoodWe's after-sales service center.
	Excessive temperature rise in battery cells	Abnormal battery cell, contact GoodWe aftersales service to replace the pack.
	SOC below 10%	Perform Charge on Battery.
	SN writing does not comply with the rules	Check if the SN digits are normal. If abnormal, please contact GoodWe After-Sales Service Center.
	Battery Intra-cluster daisy chain communication anomaly Inconsistent aging levels of battery cells between clusters	1. Check the contact condition of a single cluster Battery pack. 2. Confirm the usage of each cluster Battery, such as cumulative charge Discharge capacity, cycle count, etc. 3. Please contact GoodWe after-sales service center.

fault name	fault cause	Troubleshooting recommendation
	Excessive Humidity within the pack	-
	Fuse blown	Contact GoodWe aftersales service to replace the pack.
	Low battery level	Perform Charge on Battery.
BMS2 Other	Circuit Breaker Abnormality	Contact GoodWe aftersales service to replace the pack.
Failure 4 (LES)	External device abnormality	Contact GoodWe aftersales service to replace the pack.
Contactor Fault 1	-	-
Contactor Fault 2	-	-
Overload Protection (Jinggui)	Continuous overload (exceeding 690kVA) for 10s	Please contact GoodWe after-sales service center.
Overload (Smart Inverter)	Continuous overload (exceeding 690kVA) for 10s	Please contact GoodWe after-sales service center.
Communicatio n Abnormality Between Host and Meter When AC is Powered On in Parallel System	 The meter may not be connected to the host. Possible loose communication cable of the meter. 	 Check if the meter is connected to the main unit. Check if the meter communication cable is loose.

fault name	fault cause	Troubleshooting recommendation
Slave Power Meter in Parallel System is Abnormal	The meter is connected to the slave.	Set the meter connection machine as the master.
Slave Device in Parallel System Communicatio n Timeout with Master After AC Power-On for More Than 10 Minutes	 Incorrect slave address setting Slave communication line is loose 	 Check if the slave address is duplicated. Check if the parallel communication cable is loose.

11.5.2.3 Battery Fault (LX A5.0-30)

Alarm state

When the battery ALM indicator turns red, troubleshoot the issue by referring to the SOC indicator's display status.

No.	SOC Indicator	Fault	Solutions/measures to address the issue
1	000•	Battery overvoltage protection Battery undervoltage protection	 Check whether the Charging Current Limit of the inverter is 0 through SolarGo. If yes, please confirm whether the communication cable connection between the battery and the inverter is reliable and the communication is normal. Power off and wait for 5 minutes, then restart to confirm if the fault persists. If the fault is not restored, please contact the after-sales service center.

No.	SOC Indicator	Fault	Solutions/measures to address the issue
2	00••	Overcurrent protection	 Check if the battery model is correct through SolarGo and confirm if the real-time current of the battery is greater than the Charging/Discharging Current Limit. Please contact the after-sales service center. When it is less than the Charging/Discharging Current Limit., turn off the battery or upgrade the program, restart to confirm whether the fault persists. If the fault is not restored, please contact the after-sales service center.
3	00•0	Over temperature protection Low temperature protection Pole over temperature protection	Power off and wait for 60 minutes, wait for the temperature to recover. If the problem persists after restarting, please contact the after-sales service center.
4	0000	Balancing fault Low SOH fault	Power off and wait for 30 minutes. If the problem persists after restarting, please contact the after-sales service center.
5	• • • •	Precharge failure	 Confirm if the battery output terminal is connected in reverse to the inverter. Power off and wait for 30 minutes. If the problem persists after restarting, please contact the after-sales service center.
6	0•0•	Wire harness exception	Confirm if the battery switch is closed. If the battery switch is closed and the problem still exists. Please contact the after-sales service center.

No.	SOC Indicator	Fault	Solutions/measures to address the issue
7		Relay or MOS over temperature Diverter over temperature	Power off and wait for 30 minutes. If the problem persists after restarting, please contact the after-sales service center.
		Other BMS faults: output port over temperature fault	 Check if the battery power cable is connected tightly. Power off and wait for 5 minutes. If the problem persists after restarting, please contact the after-sales service center.
8	0 • • 0	Other protections: MOS cannot be closed	Power off and wait for 5 minutes. If the problem persists after restarting, please
9	0	Other protections: MOS adhesion	contact the after-sales service center.
10	•000	Other protections: Cluster Fault	 Confirm whether the type and installation position of the terminal resistor used are correct. Confirm whether the communication cable between batteries, the cable between batteries and inverters are reliable and the communication is normal. If the fault is not restored, please contact the after-sales service center.
11	0000	Other protections: Communication loss with inverter	 Confirm whether the communication cable between batteries, the cable between batteries and inverters are reliable and the communication is normal. If the fault is not restored, please contact the after-sales service center.

No.	SOC Indicator	Fault	Solutions/measures to address the issue
12	•00•	Other protections: BMU communication failure	 Confirm whether the type and installation position of the terminal resistor used are correct. Confirm whether the communication cable between batteries, the cable between batteries and inverters are reliable and the communication is normal. Power off and wait for 5 minutes. If the problem persists after restarting, please contact the after-sales service center.
13	•••	Other protections: Air switch adhesion fault	Power off and wait for 5 minutes. If the problem persists after restarting, please contact the after-sales service center.
14	••••	Other protections: software fault	
15	•••	Other protections: Hardware overcurrent fault	Restart the battery. If the problem persists after restarting, please contact the aftersales service center.
		Other protections: Microelectronic s fault	
16		Heating film abnormal	 Upgrade software Power off and wait for 5 minutes. If the problem persists after restarting, please contact the after-sales service center.

11.5.2.4 Batteryfault(LX A5.0-30, LX U5.0-30)

Alarm status

When the BatteryALMindicator displays red, locate and troubleshoot based on the SOCindicator status indication.

No.	SOC (State of Charge)	fault name	Solution measures
1	000•	Battery Over Voltage Battery Under Voltage	 Check via SolarGo whether the Inverter Charge current limit is 0. If it is 0, verify that the Communication cable connection between Battery and Inverter is reliable and communication is normal. Power off and let it stand for 5 minutes. After restarting, confirm whether fault persists. If fault is not restored, please contact the after-sales service center.
2	0000	Battery Over Current	 Check via SolarGo whether Batterymodel is correct, confirm if the real-time current of Battery exceeds the Chargecurrent limit or the Dischargecurrent limit value, and contact the after-sales service center. When the value is less than the threshold, shut down the Battery or upgrade the program, then restart to confirm whether the fault persists. If fault does not respond, please contact after-sales service.
3	00•0	Battery Over Temperature Battery Under Temperature Battery Pole Over Temperature	Power off and let it stand for 60 minutes to allow the temperature to recover. If the issue persists after restarting, please contact the after-sales service center.
4	0000	Battery Imbalance Low SOH fault	Power off and let it stand for 30 minutes. If the problem persists after restarting, please contact the after-sales service center.

No.	SOC (State of Charge)	fault name	Solution measures
5	•••	Pre-charge Failure	 Verify whether the output terminals of Battery and Inverter are connected in reverse. Power off and let it stand for 5 minutes. If the problem persists after restarting, please contact the after-sales service center.
6	0 • 0 •	Collection Line Failure	Check if the Battery switch is closed. If the Battery switch is already closed and the issue persists, please contact the after-sales service center.
		Relay or MOS Over Temperature Shunt Over Temperature	Power off and let it stand for 30 minutes. If the problem persists after restarting, please contact the after-sales service center.
7	7	BMS Other fault: Output port Overtemperatu re fault	 Check if the Battery power line is securely fastened. Power off and let it stand for 5 minutes. If the problem persists after restarting, please contact the after-sales service center.
8	0 • • 0	Others Protection: MOS cannot close	Power off and let it stand for 5 minutes. If the problem persists after restarting, please
9	0	Others Protection: MOS adhesion	contact the after-sales service center.

No.	SOC (State of Charge)	fault name	Solution measures
10	•000	Others Protection: Cluster Parallel fault	 Verify whether the type of Terminal resistor used and the Installation Location are correct Verify whether the connections between Battery and Battery (Communication cable), and between Battery and Inverter (Communication cable) are reliable and communication is normal. If the fault is not restored, please contact the after-sales service center.
11	0000	Other Protection: Communication lost with Inverter	 Verify whether the connections between Battery and Battery (Communication cable), and between Battery and Inverter (Communication cable) are reliable and communication is normal. If the fault is not restored, please contact the after-sales service center.
12	•00•	Other Protection: BMU communication fault	 Verify whether the type of Terminal resistor used and the Installation Location are correct Verify whether the connections between Battery and Battery, as well as between Battery and Inverter, are reliable and communication is normal. Power off and wait for 5 minutes. If the problem persists after restarting, please contact the after-sales service center.
13	•••	Other Protection: Circuit breaker adhesion fault	Power off and let it stand for 5 minutes. If the problem persists after restarting, please contact the after-sales service center.

No.	SOC (State of Charge)	fault name	Solution measures
14	••••	Other Protection: Software fault	Restart Battery. If the problem persists after restarting, please contact the after-sales service center.
15	•••0	Other Protection: Hardware Overcurrent fault	
		Other Protection: Microelectronic Failure	
16	••••	Abnormal three-terminal heating film	 Upgrade software Power off and let it stand for 5 minutes. If the problem persists after restarting, please contact the after-sales service center.

11.5.2.5 Battery Fault (GW14.3-BAT-LV-G10)

When the battery alarm indicator light turns red, the outer marquee flashes red, and the operation light turns off, combine the SOC indicator light display status to locate and troubleshoot the fault.

No.	SOC Indicator	Fault	Solutions/measures to address the issue
1		Battery overvoltage protection	

	Battery undervoltage protection	 Check whether the inverter charging current limit is 0 via SolarGo. If it is 0, confirm that the communication line between the battery and the inverter is connected reliably and that communication is normal. Shut down and leave for 5 minutes, then restart and confirm whether the fault persists. If the fault is not restored, please contact the after-sales service center.
2	Overcurrent protection	 Check the battery model through SolarGo to confirm whether the real-time current of the battery is greater than the charging current limit or discharge current limit value. If so, please contact the after- sales service center. If the current is less than the limit, shut down the battery or upgrade the program, then restart to confirm whether the fault persists. If the fault is not resolved, please contact after-sales service.
3	Over temperature protection Low temperature protection Pole over temperature protection	Power off and wait for 60 minutes, wait for the temperature to recover. If the problem persists after restarting, please contact the after-sales service center.
4	Balancing fault Low SOH fault	Power off and wait for 30 minutes. If the problem persists after restarting, please contact the after-sales service center.

5	Precharge failure	 Check whether the battery output terminal is connected to the inverter in reverse. Shut down and wait for 5 minutes. If the problem persists after restarting, please contact the after-sales service center.
6	Wire harness exception	Check whether the battery circuit breaker is closed. If the battery circuit breaker is closed and the problem persists, please contact the after-sales service center.
7	Relay or MOS over temperature Output port overheating	Power off and wait for 30 minutes. If the problem persists after restarting, please contact the after-sales service center. 1. Check whether the battery power cord is securely connected. 2. Turn off the device and leave it for 5 minutes. If the problem persists after restarting, please contact the after-sales service center.
8	MOS Open- Circuit Fault	Power off and wait for 5 minutes. If the problem persists after restarting, please
9	MOS adhesion	contact the after-sales service center.
10	Cluster Fault	 Confirm that the type and installation location of the terminal resistor are correct. Confirm that the communication lines between batteries and between batteries and inverters are connected reliably and that communication is normal. If the fault persists, please contact the after-sales service center.
11	Inconsistent software and hardware versions	Restart the battery. If the problem persists after restarting, please contact the aftersales service center.

12		BMU communicatio n fault		
13		Open contact sticking fault	Power off and wait for 5 minutes. If the problem persists after restarting, please contact the after-sales service center.	
14		Software fault	Destant the hatten of the annual lane requires	
15		Hardware overcurrent fault	Restart the battery. If the problem persists after restarting, please contact the aftersales service center.	
	Microelectroni c Fault			
16		Heating film abnormal	 Upgrade the software. Shut down the computer and leave it idle for 5 minutes. If the problem persists after restarting, please contact the after-sales service center. 	

11.5.3 Operation After Fault Clearance


In the energy conservation system, after some fault clearances complete, further operations are needed for the system to restore normal work.

11.5.3.1 Clear AFCIfaultWARNING

[Software Used]: SolarGo App

[Clearing method]:

- 1. Through[Home] >[Settings] >[Advanced Settings] >[DC Arc Detection].
- 2. Click**[Clear AFCIfault Alarm]**Button.



12 Technical Parameters

12.1 Inverter Parameters

Technical Data	GW5K-ET-L-G10 *9	GW6K-ET-L-G10	GW8K-ET-L-G10
Battery Side			
Battery Type *1	Li-Ion/Lead-acid	Li-Ion/Lead-acid	Li-Ion/Lead-acid
Nominal Battery Voltage (V)	48	48	48
Battery voltage range (V)	40~60	40~60	40~60
Start-up Voltage(V)	30	30	30
Number of Battery Input	1	1	1
Max. Continuous Charging Current (A)	125	135	175
Max. Continuous Discharging Current (A)	125	135	175
Max Charging Power (kW)	5	6	8
Max Discharging Power (kW)	5.5	6.6	8.8
PV Side			
Max. Input Power (kW)	10	12	16

Technical Data	GW5K-ET-L-G10 *9	GW6K-ET-L-G10	GW8K-ET-L-G10	
Max. Input Voltage (V) *2	1000	1000	1000	
MPPT Operating Voltage Range (V) *3	150-850	150-850	150-850	
MPPT Operating Voltage Range at Nominal Power (V)	300~850	300~850	300~850	
Start-up Voltage (V)	180	180	180	
Nominal Input Voltage (V)	620	620	620	
Max. MPPT Current (A)	20/20	20/20	20/20	
Max. MPPT Short Circuit Current(A)	26/26	26/26	26/26	
Number of MPPTs	2	2	2	
Number of Strings per MPPT	1/1	1/1	1/1	
AC Side (On-grid)				
Nominal Power (kW)	5.0	6.0	8.0	
Max. Power (kW)	5.5	6.6	8.8	
Nominal Power at 40 °C (kW)	5.0	6.0	8.0	

Technical Data	GW5K-ET-L-G10 *9	GW6K-ET-L-G10	GW8K-ET-L-G10
Max. Power at 40 °C (kW)	5.0	6.0	8.0
Nominal Apparent Power Output to Grid (kVA)	5.0	6.0	8.0
Max. Apparent Power to Utility Grid (kVA)*10	5.5	6.6	8.8
Nominal Apparent Power from Grid(kVA)	5.0	6.0	8.0
Max. Apparent Power from Grid (kVA)	48.3	48.3	48.3
Nominal Voltage (V)	400/380, 3L/N/PE	400/380, 3L/N/PE	400/380, 3L/N/PE
Voltage Range (V)	170~290	170~290	170~290
Nominal Frequency (Hz)	50/60	50/60	50/60
Frequency Range (Hz)	45~65	45~65	45~65
Max. Current to Grid (A)	7.9@230V 8.3@220V	9.6@230V 10@220V	12.8@230V 13.4@220V
Max. Current From Grid (A)	70	70	70
Nominal Current From Grid (A)	7.5@220V 7.2@230V	9.1@220V 8.7@230V	12.1@220V 11.6@230V

Technical Data	GW5K-ET-L-G10 *9	GW6K-ET-L-G10	GW8K-ET-L-G10
Max. Output Fault Current (Peak and Duration) (A)	99	99	99
Inrush Current (Peak and Duration) (A)	300A/2ms	300A/2ms	300A/2ms
Nominal Current to Grid (A)	7.5@220V 7.2@230V	9.1@220V 8.7@230V	12.1@220V 11.6@230V
Power Factor	~1 (Adjustable from0.8 leading~0.8 lagging)	~1 (Adjustable from0.8 leading~0.8 lagging)	~1 (Adjustable from0.8 leading~0.8 lagging)
THDI	<3%	<3%	<3%
Maximum Output Overcurrent Protection (A)	70	70	70
Type of voltage	a.c.	a.c.	a.c.
Back-up Side			
Nominal Output Apparent Power (kVA)	5.0	6.0	8.0
Max. Output Apparent Power(kVA)	5.5 (10.0, 10s)	6.6 (12.0, 10s)	8.8 (16.0, 10s)
Max. Output Apparent Power with Grid (kVA)	48.3	48.3	48.3

Technical Data	GW5K-ET-L-G10 *9	GW6K-ET-L-G10	GW8K-ET-L-G10
Nominal Output Current (A)	7.5@220V 7.2@230V	9.1@220V 8.7@230V	12.1@220V 11.6@230V
Max Output Current(Bypass)	70	70	70
Max. Fault Current (Peak and Duration) (A)	99 @100ms	99 @100ms	99 @100ms
Inrush Current (Peak and Duration) (A)	300 @2ms	300 @2ms	300 @2ms
Maximum Overcurrent Protection (A)	70	70	70
Nominal Output Voltage (V)	400/380, 3L/N/PE	400/380, 3L/N/PE	400/380, 3L/N/PE
Nominal Output Frequency (Hz)	50/60	50/60	50/60
Generator Side			
Nominal Apparent Power (kVA)	20.0	20.0	20.0
Max. Apparent Power (kVA)	20.0	20.0	20.0
Nominal Voltage (V)	400/380	400/380	400/380
Input Voltage Range (V)	170~290	170~290	170~290
Nominal Frequency (Hz)	50/60	50/60	50/60

Technical Data	GW5K-ET-L-G10 *9	GW6K-ET-L-G10	GW8K-ET-L-G10
Frequency Range (Hz)	45~55/55~65	45~55/55~65	45~55/55~65
Max. Current (A)	30.3	30.3	30.3
Efficiency			
Max. Efficiency	97.8%	97.8%	97.8%
European Efficiency	97.0%	97.0%	97.1%
Max. Battery to AC Efficiency	95.5%	95.5%	95.5%
MPPT Efficiency	99.9%	99.9%	99.9%
Protection		'	'
PV String Current Monitoring	Integrated	Integrated	Integrated
PV Insulation Resistance Detection	Integrated	Integrated	Integrated
Residual Current Monitoring	Integrated	Integrated	Integrated
PV Reverse Polarity Protection	Integrated	Integrated	Integrated
Battery Reverse Polarity Protection	Optional	Optional	Optional
Anti-islanding Protection	Integrated	Integrated	Integrated
AC Overcurrent Protection	Integrated	Integrated	Integrated
AC Short Circuit Protection	Integrated	Integrated	Integrated

Technical Data	GW5K-ET-L-G10 *9	GW6K-ET-L-G10	GW8K-ET-L-G10
AC Overvoltage Protection	Integrated	Integrated	Integrated
DC Switch	Integrated	Integrated	Integrated
AC Switch	NA	NA	NA
DC Surge Protection	Type II	Type II	Type II
AC Surge Protection	Type II	Type II	Type II
AFCI *7	Optional	Optional	Optional
Rapid Shutdown	Optional	Optional	Optional
Remote Shutdown	Integrated	Integrated	Integrated
General Data			
Operating Temperature Range (°C)	-35~+60	-35~+60	-35~+60
Operating Environment	Outdoor	Outdoor	Outdoor
Relative Humidity	0 ~ 95%	0 ~ 95%	0 ~ 95%
Max. Operating Altitude (m)	4000	4000	4000
Cooling Method	Smart Fan Cooling	Smart Fan Cooling	Smart Fan Cooling
User Interface	LCD	LCD	LCD
Communication with BMS	CAN	CAN	CAN
Communication	WIFI+LAN+Bluetoo th, 4G, RS485, CAN	WIFI+LAN+Bluetoo th, 4G, RS485, CAN	WIFI+LAN+Bluetoo th, 4G, RS485, CAN

Technical Data	GW5K-ET-L-G10 *9	GW6K-ET-L-G10	GW8K-ET-L-G10
Communication Ptotocols	Modbus RTU(RS485), Modbus TCP/IP(Ethernet), Sunspec Modbus RTU	Modbus RTU(RS485), Modbus TCP/IP(Ethernet), Sunspec Modbus RTU	Modbus RTU(RS485), Modbus TCP/IP(Ethernet), Sunspec Modbus RTU
Weight (kg)	42.2	42.2	42.2
Dimension(W×H×D mm)	756*551*258	756*551*258	756*551*258
Noise Emission (dB)	<45	<45	<45
Topology	Non-isolated	Non-isolated	Non-isolated
Power Self- consumption at Night (W)	<15	<15	<15
Ingress Protection Rating	IP66	IP66	IP66
Anti-corrosion Class	C4	C4	C4
DC Connector	MC4	MC4	MC4
AC Connector	Tube Terminal	Tube Terminal	Tube Terminal
Environmental Category	4K4H	4K4H	4K4H
Pollution Degree	III	III	III
Overvoltage Category	DC II / AC III	DC II / AC III	DC II / AC III
Protective Class	I	I	I
Storage Temperature (°C)	-40~70	-40~70	-40~70

Technical Data	GW5K-ET-L-G10 *9	GW6K-ET-L-G10	GW8K-ET-L-G10	
Decisive Voltage Classification (DVC)	Battery:A PV:C AC:C Com:A	Battery:A PV:C AC:C Com:A	Battery:A PV:C AC:C Com:A	
Mounting Method	Wall Mounted	Wall Mounted	Wall Mounted	
Active Anti- islanding Method	AFDPF + AQDPF *8	AFDPF + AQDPF *8	AFDPF + AQDPF *8	
Type of Electrical Supply System	Three phase Grid	Three phase Grid	Three phase Grid	
Country of Manufacture	China	China	China	
Certification				
Grid Standards	NRS 097-2-1, IEC 62116, IEC 61727, IEC 61683, IEC 62891, IEC 60068, EN50530			
Safety Regulation	IEC 62109-1, IEC 62109-2			
EMC	IEC 62920, IEC 61000 EN 62479	IEC 62920, IEC 61000, EN300328, EN 301489, EN IEC 62311, EN 62479		

Technical Data	GW10K-ET-L-G10	GW12K-ET-L-G10	GW15K-ET-L-G10
Battery Side			
Battery Type *1	Li-Ion/Lead-acid	Li-Ion/Lead-acid	Li-Ion/Lead-acid
Nominal Battery Voltage (V)	48	48	48
Battery voltage range (V)	40~60	40~60	40~60
Start-up Voltage(V)	30	30	30

Technical Data	GW10K-ET-L-G10	GW12K-ET-L-G10	GW15K-ET-L-G10
Number of Battery Input	1	1	2
Max. Continuous Charging Current (A)	220	250	165/165
Max. Continuous Discharging Current (A)	220	250	165/165
Max Charging Power (kW)	10	12	15
Max Discharging Power (kW)	11	13.2	16.5
PV Side			
Max. Input Power (kW)	20	24	30
Max. Input Voltage (V) *2	1000	1000	1000
MPPT Operating Voltage Range (V) *3	150-850	150-850	150-850
MPPT Operating Voltage Range at Nominal Power (V)	300~850	300~850	350~850
Start-up Voltage (V)	180	180	180
Nominal Input Voltage (V)	620	620	620

Technical Data	GW10K-ET-L-G10	GW12K-ET-L-G10	GW15K-ET-L-G10
Max. MPPT Current (A)	20/20/20	20/20/20	20/20/20/20
Max. MPPT Short Circuit Current(A)	26/26/26	26/26/26	26/26/26/26
Number of MPPTs	3	3	4
Number of Strings per MPPT	1/1/1	1/1/1	1/1/1/1
AC Side (On-grid)			
Nominal Power (kW)	10.0	12.0	15.0
Max. Power (kW)	11.0	13.2*4	16.5*4
Nominal Power at 40 °C (kW)	10.0	12.0	15.0
Max. Power at 40 °C (kW)	10.0	12.0	15.0
Nominal Apparent Power Output to Grid (kVA)	10.0	12.0	15.0
Max. Apparent Power to Utility Grid (kVA)*10	11.0	13.2	16.5
Nominal Apparent Power from Grid(kVA)	10.0	12.0	15.0
Max. Apparent Power from Grid (kVA)	48.3	48.3	48.3

Technical Data	GW10K-ET-L-G10	GW12K-ET-L-G10	GW15K-ET-L-G10
Nominal Voltage (V)	400/380, 3L/N/PE	400/380, 3L/N/PE	400/380, 3L/N/PE
Voltage Range (V)	170~290	170~290	170~290
Nominal Frequency (Hz)	50/60	50/60	50/60
Frequency Range (Hz)	45~65	45~65	45~65
Max. Current to Grid (A)	15.9@230V 16.7@220V	19.1@230V *5 20@220V	23.9@230V *5 25@220V
Max. Current From Grid (A)	70	70	70
Nominal Current From Grid (A)	15.2@220V 14.5@230V	18.2@220V 17.4@230V	22.7@220V 21.7@230V
Max. Output Fault Current (Peak and Duration) (A)	99	99	99
Inrush Current (Peak and Duration) (A)	300A/2ms	300A/2ms	300A/2ms
Nominal Current to Grid (A)	15.2@220V 14.5@230V	18.2@220V 17.4@230V	22.7@220V 21.7@230V
Power Factor	~1 (Adjustable from0.8 leading~0.8 lagging)	~1 (Adjustable from0.8 leading~0.8 lagging)	~1 (Adjustable from0.8 leading~0.8 lagging)
THDI	<3%	<3%	<3%
Maximum Output Overcurrent Protection (A)	70	70	70

Technical Data	GW10K-ET-L-G10	GW12K-ET-L-G10	GW15K-ET-L-G10	
Type of voltage	a.c.	a.c.	a.c.	
Back-up Side				
Nominal Output Apparent Power (kVA)	10.0	12.0	15.0	
Max. Output Apparent Power(kVA)	11.0 (20.0, 10s)	13.2 (24.0, 10s)	16.5 (30.0, 10s)	
Max. Output Apparent Power with Grid (kVA)	48.3	48.3	48.3	
Nominal Output Current (A)	15.2@220V 14.5@230V	18.2@220V 17.4@230V	22.7@220V 21.7@230V	
Max Output Current(Bypass)	70	70	70	
Max. Fault Current (Peak and Duration) (A)	99 @100ms	99 @100ms	99 @100ms	
Inrush Current (Peak and Duration) (A)	300 @2ms	300 @2ms	300 @2ms	
Maximum Overcurrent Protection (A)	70	70	70	
Nominal Output Voltage (V)	400/380, 3L/N/PE	400/380, 3L/N/PE	400/380, 3L/N/PE	

Technical Data	GW10K-ET-L-G10	GW12K-ET-L-G10	GW15K-ET-L-G10	
Nominal Output Frequency (Hz)	50/60	50/60	50/60	
Generator Side				
Nominal Apparent Power (kVA)	20.0	20.0	20.0	
Max. Apparent Power (kVA)	20.0	20.0	20.0	
Nominal Voltage (V)	400/380	400/380	400/380	
Input Voltage Range (V)	170~290	170~290	170~290	
Nominal Frequency (Hz)	50/60	50/60	50/60	
Frequency Range (Hz)	45~55/55~65	45~55/55~65	45~55/55~65	
Max. Current (A)	30.3	30.3	30.3	
Efficiency				
Max. Efficiency	97.8%	97.8%	97.9%	
European Efficiency	97.3%	97.3%	97.3%	
Max. Battery to AC Efficiency	95.5%	95.5%	95.5%	
MPPT Efficiency	99.9%	99.9%	99.9%	
Protection				
PV String Current Monitoring	Integrated	Integrated	Integrated	
PV Insulation Resistance Detection	Integrated	Integrated	Integrated	

Technical Data	GW10K-ET-L-G10	GW12K-ET-L-G10	GW15K-ET-L-G10
Residual Current Monitoring	Integrated	Integrated	Integrated
PV Reverse Polarity Protection	Integrated	Integrated	Integrated
Battery Reverse Polarity Protection	Optional	Optional *6	Optional *6
Anti-islanding Protection	Integrated	Integrated	Integrated
AC Overcurrent Protection	Integrated	Integrated	Integrated
AC Short Circuit Protection	Integrated	Integrated	Integrated
AC Overvoltage Protection	Integrated	Integrated	Integrated
DC Switch	Integrated	Integrated	Integrated
AC Switch	NA	NA	NA
DC Surge Protection	Type II	Type II	Type II
AC Surge Protection	Type II	Type II	Type II
AFCI *7	Optional	Optional	Optional
Rapid Shutdown	Optional	Optional	Optional
Remote Shutdown	Integrated	Integrated	Integrated
General Data			
Operating Temperature Range (°C)	-35~+60	-35~+60	-35~+60

Technical Data	GW10K-ET-L-G10	GW12K-ET-L-G10	GW15K-ET-L-G10
Operating Environment	Outdoor	Outdoor	Outdoor
Relative Humidity	0 ~ 95%	0 ~ 95%	0 ~ 95%
Max. Operating Altitude (m)	4000	4000	4000
Cooling Method	Smart Fan Cooling	Smart Fan Cooling	Smart Fan Cooling
User Interface	LCD	LCD	LCD
Communication with BMS	CAN	CAN	CAN
Communication	WIFI+LAN+Bluetoo th, 4G, RS485, CAN	WIFI+LAN+Bluetoo th, 4G, RS485, CAN	WIFI+LAN+Bluetoo th, 4G, RS485, CAN
Communication Ptotocols	Modbus RTU(RS485), Modbus TCP/IP(Ethernet), Sunspec Modbus RTU	Modbus RTU(RS485), Modbus TCP/IP(Ethernet), Sunspec Modbus RTU	Modbus RTU(RS485), Modbus TCP/IP(Ethernet), Sunspec Modbus RTU
Weight (kg)	45.3	45.3	49.7
Dimension(W×H×D mm)	756*551*258	756*551*258	756*551*258
Noise Emission (dB)	<45	<45	<45
Topology	Non-isolated	Non-isolated	Non-isolated
Power Self- consumption at Night (W)	<15	<15	<15
Ingress Protection Rating	IP66	IP66	IP66

Technical Data	GW10K-ET-L-G10	GW12K-ET-L-G10	GW15K-ET-L-G10
Anti-corrosion Class	C4	C4	C4
DC Connector	MC4	MC4	MC4
AC Connector	Tube Terminal	Tube Terminal	Tube Terminal
Environmental Category	4K4H	4K4H	4K4H
Pollution Degree	III	III	III
Overvoltage Category	DC II / AC III	DC II / AC III	DC II / AC III
Protective Class	I	I	I
Storage Temperature (°C)	-40~70	-40~70	-40~70
Decisive Voltage Classification (DVC)	Battery:A PV:C AC:C Com:A	Battery:A PV:C AC:C Com:A	Battery:A PV:C AC:C Com:A
Mounting Method	Wall Mounted	Wall Mounted	Wall Mounted
Active Anti- islanding Method	AFDPF + AQDPF *8	AFDPF + AQDPF *8	AFDPF + AQDPF *8
Type of Electrical Supply System	Three phase Grid	Three phase Grid	Three phase Grid
Country of Manufacture	China	China	China
Certification			
Grid Standards	NRS 097-2-1, IEC 62116, IEC 61727, IEC 61683, IEC 62891, IEC 60068, EN50530		
Safety Regulation	IEC 62109-1, IEC 62109-2		

Technical Data	GW10K-ET-L-G10	GW12K-ET-L-G10	GW15K-ET-L-G10
EMC	IEC 62920, IEC 61000, EN300328, EN 301489, EN IEC 62311,		
EIVIC	EN 62479		

Technical Data	GW20K-ET-L-G10	GW12K-ET-LL-G10 *9	
Battery Side			
Battery Type *1	Li-Ion/Lead-acid	Li-Ion/Lead-acid	
Nominal Battery Voltage (V)	48	48	
Battery voltage range (V)	40~60	40~60	
Start-up Voltage(V)	30	30	
Number of Battery Input	2	1	
Max. Continuous Charging Current (A)	208/208	250	
Max. Continuous Discharging Current (A)	208/208	250	
Max Charging Power (kW)	20	12	
Max Discharging Power (kW)	22	13.2	
PV Side			
Max. Input Power (kW)	40	24	

Technical Data	GW20K-ET-L-G10	GW12K-ET-LL-G10 *9		
Max. Input Voltage (V) *2	1000	1000		
MPPT Operating Voltage Range (V) *3	150-850	150-850		
MPPT Operating Voltage Range at Nominal Power (V)	350~850	300~850		
Start-up Voltage (V)	180	180		
Nominal Input Voltage (V)	620	620		
Max. MPPT Current (A)	20/20/20/20	20/20/20		
Max. MPPT Short Circuit Current(A)	26/26/26/26	26/26/26		
Number of MPPTs	4	3		
Number of Strings per MPPT	1/1/1/1	1/1/1		
AC Side (On-grid)				
Nominal Power (kW)	20.0	12.0		
Max. Power (kW)	22.0*4	12.0		
Nominal Power at 40 °C (kW)	20.0	12.0		

Technical Data	GW20K-ET-L-G10	GW12K-ET-LL-G10 *9
Max. Power at 40 °C (kW)	20.0	12.0
Nominal Apparent Power Output to Grid (kVA)	20.0	12.0
Max. Apparent Power to Utility Grid (kVA)*10	22.0	13.2
Nominal Apparent Power from Grid(kVA)	20.0	12.0
Max. Apparent Power from Grid (kVA)	48.3	26.7
Nominal Voltage (V)	400/380, 3L/N/PE	220, 3L/N/PE
Voltage Range (V)	170~290	170~290
Nominal Frequency (Hz)	50/60	60
Frequency Range (Hz)	45~65	55~65
Max. Current to Grid (A)	31.9@230V *5 33.3@220V	31.5@127V
Max. Current From Grid (A)	70	70
Nominal Current From Grid (A)	30.3@220V 29@230V	31.5@127V

Technical Data	GW20K-ET-L-G10	GW12K-ET-LL-G10 *9
Max. Output Fault Current (Peak and Duration) (A)	99	99
Inrush Current (Peak and Duration) (A)	300A/2ms	300A/2ms
Nominal Current to Grid (A)	30.3@220V 29.0@230V	31.5@127V
Power Factor	~1 (Adjustable from0.8 leading~0.8 lagging)	~1 (Adjustable from0.8 leading~0.8 lagging)
THDI	<3%	<3%
Maximum Output Overcurrent Protection (A)	70	70
Type of voltage	a.c.	a.c.
Back-up Side		
Nominal Output Apparent Power (kVA)	20.0	12.0
Max. Output Apparent Power(kVA)	22.0 (40.0, 10s)	13.2 (24.0, 10s)
Max. Output Apparent Power with Grid (kVA)	48.3	26.7

Technical Data	GW20K-ET-L-G10	GW12K-ET-LL-G10 *9
Nominal Output Current (A)	30.3@220V 29@230V	31.5@127V
Max Output Current(Bypass)	70	70
Max. Fault Current (Peak and Duration) (A)	99 @100ms	99 @100ms
Inrush Current (Peak and Duration) (A)	300 @2ms	300 @2ms
Maximum Overcurrent Protection (A)	70	70
Nominal Output Voltage (V)	400/380, 3L/N/PE	220, 3L/N/PE
Nominal Output Frequency (Hz)	50/60	60
Generator Side		
Nominal Apparent Power (kVA)	20.0	12.0
Max. Apparent Power (kVA)	20.0	12.0
Nominal Voltage (V)	400/380	220
Input Voltage Range (V)	170~290	170~290
Nominal Frequency (Hz)	50/60	60

Technical Data	GW20K-ET-L-G10	GW12K-ET-LL-G10 *9
Frequency Range (Hz)	45~55/55~65	55~65
Max. Current (A)	30.3	31.5
Efficiency		
Max. Efficiency	97.8%	97.8%
European Efficiency	97.4%	97.3%
Max. Battery to AC Efficiency	95.5%	95.5%
MPPT Efficiency	99.9%	99.9%
Protection		
PV String Current Monitoring	Integrated	Integrated
PV Insulation Resistance Detection	Integrated	Integrated
Residual Current Monitoring	Integrated	Integrated
PV Reverse Polarity Protection	Integrated	Integrated
Battery Reverse Polarity Protection	Optional *6	Integrated
Anti-islanding Protection	Integrated	Integrated
AC Overcurrent Protection	Integrated	Integrated
AC Short Circuit Protection	Integrated	Integrated

Technical Data	GW20K-ET-L-G10	GW12K-ET-LL-G10 *9
AC Overvoltage Protection	Integrated	Integrated
DC Switch	Integrated	Integrated
AC Switch	NA	NA
DC Surge Protection	Type II	Type II
AC Surge Protection	Type II	Type II
AFCI *7	Optional	Integrated
Rapid Shutdown	Optional	Optional
Remote Shutdown	Integrated	Integrated
General Data		
Operating Temperature Range (°C)	-35~+60	-35~+60
Operating Environment	Outdoor	Outdoor
Relative Humidity	0 ~ 95%	0 ~ 95%
Max. Operating Altitude (m)	4000	4000
Cooling Method	Smart Fan Cooling	Smart Fan Cooling
User Interface	LCD	LCD
Communication with BMS	CAN	CAN
Communication	WIFI+LAN+Bluetooth, 4G, RS485, CAN	WIFI+LAN+Bluetooth, 4G, RS485, CAN

Technical Data	GW20K-ET-L-G10	GW12K-ET-LL-G10 *9
Communication Ptotocols	Modbus RTU(RS485), Modbus TCP/IP(Ethernet), Sunspec Modbus RTU	Modbus RTU(RS485), Modbus TCP/IP(Ethernet), Sunspec Modbus RTU
Weight (kg)	51.2	45.1
Dimension(W×H×D mm)	756*551*258	756*551*258
Noise Emission (dB)	<45	<45
Topology	Non-isolated	Non-isolated
Power Self-consumption at Night (W)	<15	<15
Ingress Protection Rating	IP66	IP66
Anti-corrosion Class	C4	C4
DC Connector	MC4	MC4
AC Connector	Tube Terminal	Tube Terminal
Environmental Category	4K4H	4K4H
Pollution Degree	III	III
Overvoltage Category	DC II / AC III	DC II / AC III
Protective Class	I	I
Storage Temperature (°C)	-40~70	-40~70

Technical Data	GW20K-ET-L-G10	GW12K-ET-LL-G10 *9	
Decisive Voltage Classification (DVC)	Battery:A PV:C AC:C Com:A	Battery:A PV:C AC:C Com:A	
Mounting Method	Wall Mounted	Wall Mounted	
Active Anti-islanding Method	AFDPF + AQDPF *8	AFDPF + AQDPF *8	
Type of Electrical Supply System	Three phase Grid	Three phase Grid	
Country of Manufacture	China	China	
Certification			
Grid Standards	NRS 097-2-1, IEC 62116, IEC 61727, IEC 61683, IEC 62891, IEC 60068, EN50530		
Safety Regulation	IEC 62109-1, IEC 62109-2		
EMC	IEC 62920, IEC 61000, EN300328, EN 301489, EN IEC 62311, EN 62479		

^{*1:} The Li-lon battery usually contain two mainstream type: LFP and Ternary Lithium battery.

- *3: Please refer to the user manual for the MPPT Voltage Range at Nominal Power.
- *4: For Brazil and Chile, the Max. power is the same with the Nominal Power.
- *5: For Brazil, for GW12K-ET-L-G10, GW15K-ET-L-G10 and GW20K-ET-L-G10, the Max. Current to Grid is 18.2A@220V, 22.7A@220V and 30.3A@220V respectively.
- *6: For Brazil, for GW12K-ET-L-G10, GW15K-ET-L-G10 and GW20K-ET-L-G10, the Battery Reverse Polarity Protection is integrated.
- *7: AFCI is integrated in Brazil.
- *8: AFDPF: Active Frequency Drift with Positive Feedback, AQDPF: Active Q Drift with

^{*2:} When the input voltage is greater than 980V, the inverter will enter standby mode, and when the voltage returns to below 950V the inverter will return to normal operation.

Positive Feedback.

12.2 Battery Technical Data

12.2.1 LX A5.0-30

Technical Parameters	LX A5.0-30
Nominal Capacity (kWh)	5.12
Usable energy (kWh) * 1	5
Cell Type	LFP (LiFePO4)
Operating Voltage Range (V)	43.2~58.24
Nominal Charge Current (A) *2	60
Max. Continuous Charge Current (A) *2*3	90
Nominal Discharge Current (A) *2	100
Max. Continuous Discharge Current (A) *2*3	150
Max. Pulse Discharge Current (A)*2*3	<200A (30s)
Max. Continuous Discharge Power (W)	7200
Communication	CAN

^{*9:} GW5K-ET-L-G10 and GW12K-ET-LL-G10 are expected to be available around October2025.

^{*10:} For Chile, Max. Apparent Power to Utility Grid is same as Nominal Apparent Power Output to Grid.

Technical Parameters	LX A5.0-30
Operating Temperature Range (°C)	Charge: 0 < T ≤ 55 Discharge: -20 < T ≤ 55
Maximum Operating Altitude (m)	4000
Weight (Kg)	44
Dimensions (W x H x D mm)	442*133*520 (Excluding hanger) 483*133*559 (Including hanger)
Ingress Protection Rating	IP20
Application Method	On-grid/On-grid + Backup/ off Grid
Scalability	Max. 30 in Parallel (150kWh) (Hand to hand /Combiner box /Busbar)
Mounting Method	19-inch standard rack, Floor-mounted, Wall-Mounted
Round-trip Efficiency*1	≥96%
Safety	IEC62619、IEC63056、N140
EMC	EN IEC61000-6-1、EN IEC61000-6-2、EN IEC61000-6-3、EN IEC61000-6-4
Transportation	UN38.3、ADR
Environment	ROHS

^{*1} Test conditions: 100% DOD, 0.2C charge & discharge at 25°C± 2°C, at the beginning of life.

12.2.2 LX U5.0-30

^{*2} The system's working current and power values will be related to temperature and State of Charge (SOC)

^{*3} Max charge / discharge current and power values maybe variant with different inverter models.

Technical Data	LX U5.0-30	
Rated Battery Energy (kWh)	5.12	
Available Energy (kWh)*1	5	
Cell Type	LiFePO4	
Rated voltage (V)	51.2	
Operating Voltage range(V)	43.2~58.24	
Rated Chargecurrent (A)	60	
Maximum Continuous Chargecurrent (A) *2*3	90	
Rated Discharge current (A)	100	
Maximum continuous Dischargecurrent (A)*2*3	100	
Pulse Dischargecurrent(A)*2* 3	<200A (30S)	
Maximum Continuous Charge/Discharge Power (kW)	4.95	
Communication	CAN	
Charge Temperature Range (°C)	0 <t≤55< td=""></t≤55<>	
Discharge Temperature Range (°C)	-20 <t≤55< td=""></t≤55<>	
Ambient Temperature	$0 < T \le 40$ (Recommended: $10 < T \le 30$)	
(°C)	Optional heating: -20 < T ≤ 40 (Recommended 10 < T ≤ 30)	
Relative Humidity	5~95%	
Maximum storage time	12 months (maintenance-free)	
Max. Operating Altitude(m)	4000	
heating	Optional configuration	

Technical Data	LX U5.0-30
Fire protection function	Optional, Aerosol
Unit Weight (kg)	50
Unit dimensions (Width × Height × Thickness mm)	460*580*160
Enclosure	IP65
Application	on-grid / on-grid + Backup Power / Off-Grid
Capacity expansion	30P
Mounting method	Ground-mounted/wall-mounted
round-trip efficiency	≥96%
Cycle count	> 6000 @25±2°C 0.5C 70%SOH 90%DOD
Safety	VDE2510-50、IEC62619、IEC62040、N140、IEC63056
EMC	EN IEC61000-6-1, EN IEC61000-6-2, EN IEC61000-6-3, EN IEC61000-6-4
Transportation	UN38.3、ADR
Environmental regulations	ROHS
Safe service life (years)	≥25

^{*1:} In the factory state of Battery, the test conditions are 100% DOD, 0.2C, and charging Discharge is performed at $25^{\circ}\text{C} \pm 2^{\circ}\text{C}$.

12.2.3 GW14.3-BAT-LV-G10

Technical Data	GW14.3-BAT-LV-G10
Rated Energy (kWh)	14.3
Usable Energy (kWh)*1	≥13.8
Battery Type	LFP (LiFePO ₄)
Nominal Voltage (V)	51.2

^{*2:} The operating current and Power values of the system are related to temperature and SOC.

^{*3:} The maximum charge/discharge current value may vary depending on the specifications of different battery models.

Technical Data	GW14.3-BAT-LV-G10
Max. Continuous Charging Current (A)	224
Max. Continuous Discharging Current (A)	260
Max. Input Power (System) (kW)*2	12
Max. Output Power (System) (kW)*2	12 (13.2 @10min)
Peak Output Power (System) (kW)*2	20 @15s
Charging Temperature Range (°C)	0~55
Discharging Temperature Range (°C)	-20~55
Relative Humidity	5~85%
Max. Operating Altitude (m)	4000
Noise Emission (dB)	≤35
Communication	CAN, RS485
Weight (kg)	125
Dimensions (W×H×D mm)	530*885*246 (Without the base) 530*918.6*246 (With base included)
Optional Function Configuration	Aerosol
Ingress Protection	IP20
Storage Temperature (°C)	-20~45
Ambient Temperature (°C)	0~45 (Standard configuration) 10~35 (Recommend) -20~45 (Optional)

Technical Data		GW14.3-BAT-LV-G10
Max. Storage time		12 months (-20°C~35°C) 6 months (35°C~45°C)
Scalability		30 pcs
Mounting Method		Floor-Mounted, Wall-Mounted
Cycle Life		≥6500 (25±2°C, 0.5C, 90%DOD, 70%EOL)
Country of Man	ufacture	China
Standard and Certification	Safety	IEC 62619, IEC 63056, IEC 60730-1
	EMC	EN IEC61000-6-1, EN IEC61000-6-2, EN IEC61000-6-3, EN IEC61000-6-4
	Transportation	UN38.3, ADR, MSDS

^{*1:} Test conditions, 100% DOD (cell 2.85~3.6V voltage range), 0.2P charge & discharge at 25±2 °C for battery system at the beginning of life. Usable energy is defined by its initial design value. Actual available energy may vary depending on charge/discharge rate, environmental conditions (e.g. temperature), transport and storage factors.

12.3 Smart Meter Technical Data

12.3.1 GM330

tech	nical parameter	GM330
	Support Grid type	Three-phase, split-phase, single-phase

^{*2:} Max. Input Power /Max. Output Power/Peak.Output Power derating will occur related to Temperature and SOC.

tech	nical parameter	GM330
Measurement	voltage Range L-L (Vac)	172~817
range	voltage range L-N (Vac)	100~472
	Rated Frequency (Hz)	50/60
	CT ratio	nA:5A
Communication	Communication method	RS485
parameters	Communication distance (m/ft)	1000/3280
Accuracy.	voltage/current	Class 0.5
Accuracy parameters	active energy	Class 0.5
parameters	Reactive energy	Class 1
	Dimensions (WxHxD mm/in)	72x85x72/2.83x3.35×2.83
	Housing	4 modules
General	Weight (g/lb)	240/0.53
Parameters	Mounting method	DIN rail
rarameters	User Interface	4 LEDs, reset button
	Power Consumption (W)	≤5
	IP rating	IP20
Environmental parameters	Operating Temperature Range (°C/°F)	-30~+70/-22~+158
	Storage Temperature Range (°C/°F)	-30~70/-22~+158
	Relative Humidity (Condensation-Free)	0~95%
	Max. Operating Altitude (meters/feet)	3000/9842
Certification parameters	Certificate	UL1741/ANSI

12.4 Smart Dongle Technical Data

12.4.1 WiFi/LAN Kit-20

Technic	al Parameters	WiFi/LAN Kit-20
Output Voltage (V)		5
Power Consumption (W)		<2
Communication Ir	nterface	USB
	Ethernet	10M/100Mbps Self-adaption
Communication	Wireless	IEEE 802.11 b/g/n @2.4 GHz
Parameters	Bluetooth	Bluetooth V4.2 BR/EDR and Bluetooth LE standard
	Dimension (W×H×D mm)	48.3*159.5*32.1
Mechanical	Weight (g)	82
Parameters	Ingress Protection Rating	IP65
	Mounting Method	USB port insertion and removal
Operating Temperature Range (°C)		-30~+60
Storage Temperature Range (°C)		-40~+70
Relative Humidity		0-95%
Max. Working Altitude (m)		4000

12.4.2 4G Kit-CN-G20

Product model	4G Kit-CN-G20	
Equipment Management		
Maximum supported Inverter quantity	1	
Power supply parameters		
Input voltage (V)	5	
Power Consumption (W)	≤4	
Interface method	USB	
Communication parameters		
4G/3G/2G	LTE-FDD: B1/B3/B5/B8	
44/34/24	LTE-TDD: B34/B39/B40/B41	
GNSS positioning	/	
Bluetooth	Bluetooth V5.0	
Mechanical parameters		
Dimensions (W×H×D mm)	48.3*95.5*32.1	
Weight (g)	87	

Product model	4G Kit-CN-G20		
indicator	LED* 2		
Mounting method	Plug and Play		
SIM card size	Micro sim,15mm*12mm		
Environmental parameters			
Operating Temperature Range (°C)	-30~+65		
Storage temperature Range (°C)	-40~+70		
Relative Humidity	0-100%		
IP rating	IP66		
Max. Operating Altitude (m)	4000		
Safe service life (years)	5		

13 Appendix

13.1 FAQ

13.1.1 How to Conduct Auxiliary Detection for Smart Meters/CT?

Meter detection function, which can detect whether the CT of the meter is connected correctly and the current operation status of the meter and CT.

- Approach 1:
- 1. Access the detection page through **Home** > **Settings** > **Electricity Meter/ CT** Auxiliary Detection.
- 2. Click "Start Detection" and wait for the detection to complete. Then, view the detection results.
- Approach 2:
- 1. Access the detection page through > [System Setup] > [Quick Setting] > [Meter/CT Assisted Test].
- 2. Click "Start Detection" and wait for the detection to complete. Then, view the detection results.

13.1.2 How to Upgrade the Device Version

Through the firmware information, you can view or upgrade the DSP version, ARM version, BMS version, and smart dongle software version of the inverter. Some smart dongles do not support software version upgrade via SolarGo App, and the actual situation shall prevail.

Upgrade prompt:

When the user opens the APP, an upgrade prompt will pop up on the homepage, and the user can choose whether to upgrade or not. If you choose to upgrade, you can complete the upgrade by following the prompts on the interface.

Regular upgrade:

Access the firmware information viewing interface through "Home" > "Settings" > "Firmware Information"

Click "Check for Updates". If there is a new version, complete the upgrade according to the prompts on the interface.

Forced Upgrade:

The APP will push upgrade information, and users need to upgrade according to the prompts to continue using the app. You can complete the upgrade by following the prompts on the interface.

Inverter Software Version Upgrade

- To connect USB flash drive for local software upgrading.
- Before upgrading the device using a USB flash drive, please contact the after-sales service center to obtain the software upgrade package and upgrade method.

13.2 Abbreviations

Abbreviation	English Description	Chinese Description		
Ubatt	Battery Voltage Range	电池电压范围		
Ubatt,r	Nominal Battery Voltage	额定电池电压		
Ibatt,max (C/D)	Max. Charging Current Max. Discharging Current	最大充/放电电流		
EC,R	Rated Energy	额定能量		
UDCmax	Max. Input Voltage	最大输入电压		
UMPP	MPPT Operating Voltage Range	MPPT 电压范围		
IDC,max	Max. Input Current per MPPT	每路 MPPT 最大输入电流		
ISC PV	Max. Short Circuit Current per MPPT	每路 MPPT 最大短路电流		
PAC,r	Nominal Output Power	额定输出功率		
Sr (to grid)	Nominal Apparent Power Output to Utility Grid	额定并网输出视在功率		
Smax (to grid)	Max. Apparent Power Output to Utility Grid	最大并网输出视在功率		
Sr (from grid)	Nominal Apparent Power from Utility Grid	从电网买电额定输出视在功率		
Smax (from grid)	Max. Apparent Power from Utility Grid	从电网买电最大输出视在功率		
UAC,r	Nominal Output Voltage	额定输出电压		

Abbreviation	English Description	Chinese Description	
FAC,r	Nominal AC Grid Frequency	输出电压频率	
IAC,max(to grid)	Max. AC Current Output to Utility Grid	最大并网输出电流	
IAC,max(from grid)	Max. AC Current From Utility Grid	最大输入电流	
P.F.	Power Factor	功率因数	
Sr	Back-up Nominal apparent power	离网额定视在功率	
Smax	Max. Output Apparent Power (VA) Max. Output Apparent Power without Grid	最大输出视在功率	
IAC,max	Max. Output Current	最大输出电流	
UAC,r	Nominal Output Voltage	最大输出电压	
FAC,r	Nominal Output Frequency	额定输出电压频率	
Toperating	Operating Temperature Range	工作温度范围	
IDC,max	Max. Input Current	最大输入电流	
UDC	Input Voltage	输入电压	
UDC,r	DC Power Supply	直流输入	
UAC	Power Supply/AC Power Supply	输入电压范围/交流输入	
UAC,r	Power Supply/Input Voltage Range	输入电压范围/交流输入	
Toperating	Operating Temperature Range	工作温度范围	
Pmax	Max Output Power	最大功率	
PRF	TX Power	发射功率	
PD	Power Consumption	功耗	
PAC,r	Power Consumption	功耗	
F (Hz)	Frequency	频率	
ISC PV	Max. Input Short Circuit Current	最大输入短路电流	
Udcmin-Udcmax Range of input Operating Voltage		工作电压范围	
UAC,rang(L-N)	Power Supply Input Voltage	适配器输入电压范围	
Usys,max	Max System Voltage	最大系统电压	

Abbreviation	English Description	Chinese Description	
Haltitude,max	Max. Operating Altitude	最高工作海拔高度	
PF	Power Factor	功率因数	
THDi	Total Harmonic Distortion of Current	电流谐波	
THDv	Total Harmonic Distortion of Voltage	电压谐波	
C&I	Commercial & Industrial	工商业	
SEMS	Smart Energy Management System	智慧能源管理系统	
MPPT	Maximum Power Point Tracking	最大功率点跟踪	
PID	Potential-Induced Degradation	电位诱发衰减	
Voc	Open-Circuit Voltage	开路电压	
Anti PID	Anti-PID	防PID	
PID Recovery	PID Recovery	PID修复	
PLC	Power-line Commucation	电力线载波通信	
Modbus TCP/IP	Modbus Transmission Control / Internet Protocol	基于TCP/IP层的modbus	
Modbus RTU	Modbus Remote Terminal Unit	基于串行链路的modbus	
SCR	Short-Circuit Ratio	短路比	
UPS	Uninterruptable Power Supply	不间断电源	
ECO mode	Economical Mode	经济模式	
TOU	Time of Use	使用时间	
ESS	Energy Stroage System	储能系统	
PCS	Power Conversion System	电能转换系统	
RSD	Rapid shutdown	快速关断	
EPO	Emergency Power Off	紧急关断	
SPD	Surge Protection Device	防雷保护	
	zero injection/zero export		
ARC Power Limit / Export Power Limit		防逆流	
DRED Demand Response Enabling Device		命令响应设备	
RCR	Ripple Control Receiver	-	
AFCI	AFCI	AFCI直流拉弧保护	

Abbreviation	English Description	Chinese Description	
GFCI	Ground Fault Circuit Interrupter	接地故障分断器	
RCMU	Residual Current Monitioring Unit	残余电流监控装置	
FRT	Fault Ride Through	故障穿越	
HVRT	High Voltage Ride Through	高电压穿越	
LVRT	Low Voltage Ride Through	低电压穿越	
EMS	Energy Management System	能量管理系统	
BMS	Battery Management System	电池管理系统	
BMU	Battery Measure Unit	电池采集单元	
BCU	Battery Control Unit	电池控制单元	
SOC	State of Charge	电池的荷电状态	
SOH	State of Health	电池健康度	
SOE	State Of Energy	电池剩余能量	
SOP	State Of Power	电池充放电能力	
SOF	State Of Function	电池的功能状态	
SOS	State Of Safety	安全状态	
DOD	Depth of discharge	放电深度	

13.3 Explanation of Terms

Overvoltage Category Definition

- **Category I**: applies to equipment connected to a circuit where measures have been taken to reduce transient overvoltage to a low level.
- **Category II**: applies to fixed downstream equipment. For example, appliances, portable tools and other plug-connected equipment; Voltage category III is used if there are special requirements for the reliability and suitability of such equipment.
- Category III: applies to fixed downstream equipment, including the main distribution board. For example, switchgear and other equipment in an industrial installation
- Category IV: applies to the upstream equipment in the power supply of the distribution device, including measuring instruments and upstream over-current protection devices.

• Definition of Types of Damp Places

Environmental Parameters	Level				
	3K3	4K4H			
Temperature Range	0~+40°C	-33~+40°C	-33~+40°C		
Humidity Range	5% to 85%	5% to 85%	4% to 100%		

Definition of Environmental Category:

- **Outdoor Inverter**: The ambient air temperature range is -25 to +60°C, and it is suitable for environments with pollution degree 3.
- **Indoor Type II Inverter:** The ambient air temperature range is -25 to +40°C, and it is suitable for environments with pollution degree 3.
- **Indoor Type I Inverter:** The ambient air temperature range is 0 to +40°C, and it is suitable for environments with pollution degree 2.

• Definition of Pollution Degree Categories:

- **Pollution Degree 1**: No pollution or only dry non-conductive pollution.
- **Pollution Degree 2:** In general, there is only non-conductive pollution, but the transient conductive pollution caused by occasional condensation must be taken into account.
- **Pollution Degree 3:** There is conductive pollution, or the non-conductive pollution becomes conductive pollution due to condensation.
- **Pollution Degree 4:** Persistent conductive pollution, such as pollution caused by conductive dust or rain and snow.

13.4 Battery SN Code Meaning



LXD10DSC0002

Bits 11-14 of the product SN code are the production time code. The above picture has a production date of 2023-08-08

• The 11th and 12th digits represent the last two digits of the year of manufacture,

- e.g., 2023 is represented by 23.
- The 13th digit is the month of production, e.g., August is represented by 8; as follows:

Month	1~9	10	11	12
Month	1~9	А	В	С

• The 14th digit is the date of production, e.g., the 8th day is indicated by 8; priority is given to the use of numerical representation, e.g., 1~9 indicates the 1st~9th day, A indicates the 10th day, and so on. The letters I and O are not used to avoid confusion. The details are as follows:

		_	_	_					
Production Date	1	2	3	4	5	6	7	8	9
Code	1	2	3	4	5	6	7	8	9
Production Date	10	11	12	13	14	15	16	17	18
Code	А	В	С	D	Е	F	G	Н	J
Production Date	21	22	23	24	25	26	27	28	29
Code	М	N	Р	Q	R	S	Т	U	V

13.5 Safety Country

No.	Safety Code	No.	Safety Code			
Europ	Europe					
1	IT-CEI 0-21	43	CZ-C			
2	IT-CEI 0-16	44	CZ-D			
3	DE LV with PV	45	RO-A			
4	DE LV without PV	46	RO-B			
5	DE-MV	47	RO-D			
6	ES-A	48	GB-G98			
7	ES-B	49	GB-G99-A			
8	ES-C	50	GB-G99-B			

No.	Safety Code	No.	Safety Code
9	ES-D	51	GB-G99-C
10	ES-island	52	GB-G99-D
11	BE	53	NI-G98
12	FR	54	IE-16/25A
13	FR-island-50Hz	55	IE-72A
14	FR-island-60Hz	56	IE-ESB
15	PL-A	57	IE-EirGrid
16	PL-B	58	PT-D
17	PL-C	59	EE
18	PL-D	60	NO
19	NL-16/20A	61	FI-A
20	NL-A	62	FI-B
21	NL-B	63	FI-C
22	NL-C	64	FI-D
23	NL-D	65	UA-A1
24	SE-A	66	UA-A2
25	SE MV	67	EN 50549-1
26	SK-A	68	EN 50549-2
27	SK-B	69	DK-West-B-MVHV
28	SK-C	70	DK-East-B-MVHV
29	HU	71	DK-West-C-MVHV
30	СН	72	DK-East-C-MVHV
31	CY	73	DK-West-D-MVHV
32	GR	74	DK-East-D-MVHV
33	DK-West-A	75	FR-Reunion
34	DK-East-A	76	BE-LV (>30kVA)
35	DK-West-B	77	BE-HV
36	DK-East-B	78	CH-B
37	AT-A	79	NI-G99-A
38	AT-B	80	NI-G99-B
39	BG	81	NI-G99-C

No.	Safety Code	No.	Safety Code
40	CZ-A-09	82	NI-G99-D
41	CZ-B1-09	83	IE-LV
42	CZ-B2-09	84	IE-MV
Globl	e		
1	60Hz-Default	5	IEC 61727-50Hz
2	50Hz-Default	6	IEC 61727-60Hz
3	127Vac-60Hz-Default	7	Warehouse
4	127Vac-50Hz-Default		
Amer	rica		
1	Argtina	30	US-ISO-NE-480Vac
2	US-208Vac	31	US-ISO-NE-208Vac-3P
3	US-240Vac	32	US-ISO-NE-220Vac-3P
4	Mexico-220Vac	33	US-ISO-NE-240Vac-3P
5	Mexico-440Vac	34	PR-208Vac
6	US-480Vac	35	PR-240Vac
7	US-208Vac-3P	36	PR-480 Vac
8	US-220Vac-3P	37	PR-208Vac-3P
9	US-240Vac-3P	38	PR-220Vac-3P
10	US-CA-208Vac	39	PR-240Vac-3P
11	US-CA-240Vac	40	Cayman
12	US-CA-480Vac	41	Brazil-220Vac
13	US-CA-208Vac-3P	42	Brazil-208Vac
14	US-CA-220Vac-3P	43	Brazil-230Vac
15	US-CA-240Vac-3P	44	Brazil-240Vac
16	US-HI-208Vac	45	Brazil-254Vac
17	US-HI-240Vac	46	Brazil-127Vac
18	US-HI-480Vac	47	Brazil-ONS
19	US-HI-208Vac-3P	48	Barbados
20	US-HI-220Vac-3P	49	Chile-BT
21	US-HI-240Vac-3P	50	Chile-MT
22	US-Kauai-208Vac	51	Colombia

No.	Safety Code	No.	Safety Code
23	US-Kauai-240Vac	52	Colombia<0.25MW 1P
24	US-Kauai-480Vac	53	Colombia<0.25MW 3P
25	US-Kauai-208Vac-3P	54	IEEE 1547-208Vac
26	US-Kauai-220Vac-3P	55	IEEE 1547-20Vac
27	US-Kauai-240Vac-3P	56	IEEE 1547-240Vac
28	US-ISO-NE-208Vac	57	IEEE 1547-230/400Vac
29	US-ISO-NE-240Vac		
Ocea	nia		
1	Australia-A	4	Newzealand
2	Australia-B	5	Newzealand:2015
3	Australia-C	6	NZ-GreGrid
Asia			
1	China A	25	JP-420Vac-50Hz
2	China B	26	JP-420Vac-60Hz
3	China's high pressure	27	JP-480Vac-50Hz
4	China's highest pressure	28	JP-480Vac-60Hz
5	China Power Station	29	Sri Lanka
6	China 242 Shandong	30	Singapore
7	China 242 Hebei	31	Israel-OG
8	China PCS	32	Israel-LV
9	Taiwan	33	Israel-MV
10	Hongkong	34	Israel-HV
11	China 242 Northeast	35	Vietnam
12	Thailand-MEA	36	Malaysia-LV
13	Thailand-PEA	37	Malaysia-MV
14	Mauritius	38	DEWA-LV
15	Korea	39	DEWA-MV
16	India	40	Saudi Arabia
17	India-CEA	41	JP-690Vac-50Hz
18	Pakistan	42	JP-690Vac-60Hz

No.	Safety Code	No.	Safety Code
19	Philippines	43	Srilanka
20	Philippines-127Vac	44	IEC 61727-127Vac-50Hz
21	JP-50Hz	45	IEC 61727-127Vac-60Hz
22	JP-60Hz	46	JP-550Vac-50Hz
23	JP-440Vac-50Hz	47	JP-550Vac-60Hz
24	JP-440Vac-60Hz	48	India-Higher
Africa			
1	South Africa-LV	4	Ghana
2	South Africa-B-MV	5	Ghana-HV
3	South Africa-C-MV		

Contact Details

GoodWe Technologies Co., Ltd.
No. 90 Zijin Rd., New District, Suzhou, China
400-998-1212
www.goodwe.com
service@goodwe.com